

**Autonics**

**MOTOR DRIVER  
(5 PHASE STEPPING MOTOR DRIVER)  
KR-5MC**

**M A N U A L**



Thank you very much for selecting Autonics products.  
For your safety, please read the following before using.

**Caution for your safety**

- Please keep these instructions and review them before using this unit.
- Please observe the cautions that follow:
  - Warning** Serious injury may result if instructions are not followed.
  - Caution** Product may be damaged, or injury may result if instructions are not followed.
- The following is an explanation of the symbols used in the operation manual.
  - Caution:** Injury or danger may occur under special conditions.

**Warning**

- In case of using this unit with machinery(Nuclear power control, medical equipment, vehicle, train, airplane, combustion apparatus, entertainment or safety device etc), is require to instal fail-safe device, or contact us for information on type required. It may result serious damage, fire or human injury.
- Installation, connection, operation, control, maintenance should be executed by person who has been qualified. It may cause a fire or human injury, give an electric shock.
- Please use reinforced insulation DC power for DC type input product. It may give an electric shock.
- Please install this unit after considering counterplan against power failure. It may cause human injury or damage to product by releasing holding torque of motor.
- Do not use this unit outdoors or place where there are flammable, corrosive gas, water, big vibration etc. It may cause a fire or give an electric shock.
- Do not disassemble and modify this unit, when it is required, please contact us. It may cause a fire or give an electric shock, damage to product.
- Please install board type product with protection equipment. It may cause a fire.

**Caution**

- Power input voltage must be used within the rated specification and power line should be over than AWG NO. 18(0.75mm<sup>2</sup>). It may cause a fire or give an electric shock.
  - Please check the connection before inserting the power. It may cause a fire or give an electric shock, damage to product.
  - Please turn off power when power is failed. It may cause human injury or damage to product due to sudden movement when recovering power failure.
  - Do not touch this unit during it is operating or after stopping. It may cause a burn due to high temperature in surface.
  - The emergency stop should be available during operating. It may cause human injury or damage to product.
  - Please supply power after checking control input signal. It may cause human injury or damage to product by sudden movement.
  - Do not turn on the HOLD OFF signal input while it is maintaining vertical position. It may cause human injury or damage to product by releasing holding torque of motor.
  - Please install a safety device when requiring to maintain the vertical position after turn off the power. It may cause human injury or damage to product by releasing holding torque of motor.
  - Please check if HOLD OFF signal input is ON when setting the output manually. It may cause human injury by sudden movement.
  - Do not touch the terminal when testing insulation dielectric strength or measuring insulation resistance. It may give an electric shock.
  - Please observe rating specification. It may cause human injury give an electric shock or damage to product.
  - In cleaning the unit, do not use water or an oil-based detergent. It may cause a fire or give an electric shock.
  - Please separate as industrial scrapped material when disuse this unit.
- \*The above specification are changeable without notice anytime.

**Features**


- It is upgraded in Oct. 2006.
- Self-diagnosis, micro step function(Resolution: ×1, ×2, ×10, ×20).
- Bipolar constant current pentagon drive method.
- Built-in stop/run current adjustment function.
- Photo coupler input insulation method to minimize the effects from external noise.
- Available 20-35VDC of power supply range.

**Specifications**



Model	KR-5MC
Power supply	20-35VDC(3A Max.)
Drive current	1.4A/Phase(Max.)
Drive method	Bipolar constant current pentagon drive
Resolution(Rotating angle)	×1(0.72°), ×2(0.36°), ×10(0.072°), ×20(0.036°)
Pulse width	Min. 0.5μs
Pulse interval	Min. 0.5μs
Rising/Falling time	Max. 1μs
Max. input pulse frequency	280kpps
Pulse input voltage	High:4-8VDC, Low:0-0.5VDC
Input resistor	390Ω(CW, CCW, HOLD OFF)
Ambient temperature	0 ~ 40°C(at non-freezing status)□
Ambient humidity	35-85%RH
Unit weight	Approx. 120g

\*Please mount the product in ventilative place due to too much heat of driver when using over 30VDC.

**Dimensions**




**Signal input circuit and time charts**




Note)When using 2 pulse input method, do not input CW and CCW signal at the same time. When one of the CW and CCW signals is [ON], it may not be worked normally.


**Connections**




**Input · Output circuit an connection diagram**



(\*) To use +5V output, solder(ON) JP1 terminal on a PCB after detaching the case.



**Function S/W**



**RUN current setting**

In order to adjust run current for controlling temperature rise and vibration of motor and driver, change it using RUN CURRENT volume. To change the Run current, connect the CP- to the (-) terminal of the voltmeter and the CP+ to the (+) terminal of the voltmeter then adjust RUN CURRENT S/W. (Factory specification of Run current is 1.4A/Phase)  
Phase current change :  
Setting current(A) =  $\frac{CP \text{ measurement voltage}(V)}{2}$   
(Note)Run current should be changed during the operating of motor.

**Motor STOP current setting**

In order to reduce the heat adjusting the current, change it using STOP CURRENT volume. The setting value of STOP CURRENT volume is a percentage of the setting volume of RUN CURRENT.  
Ex)After setting 1.0A for Run current then put STOP CURRENT volume at 50%, the Stop current will be 0.5A.  
(Note)Run current should be changed during the operating of motor.

**Caution for using**

- For signal input
  - When using 2 pulse input method, do not input CW and CCW signal at the same time. When one of the CW and CCW signal it [ON], it may not be worked normally.
  - When the power for pulse operation is exceeded +5V, please connect resistance and use from the external.
- For supplying power
  - Use the power enough to supply the run current when turn on the power.
  - The current value indicated on power supply is the max. input of driver.
  - Please check the polarity of power before using.
- For cable connection
  - Use Twist pair(Over 0.2mm<sup>2</sup>) for the signal cable should be shorter than 2m.
  - Please use over than AWG No.18(0.75mm<sup>2</sup>) wire for motor and power connection(when it is required to be extended) and power line.
- For installation
  - Please mount a heating panel on metal surface closely.
  - Please mount this product in ventilative place in order to increase the heating efficiency of heating panel.
- Installation environment
  - It shall be used indoor
  - Altitude max. 2000m
  - Pollution degree 2
  - Installation category II

\*It may cause malfunction if above instructions are not followed.

**Major products**

- PROXIMITY SENSOR
- PHOTOELECTRIC SENSOR
- AREA SENSOR
- FIBER OPTIC SENSOR
- DOOR/DOOR SIDE SENSOR
- PRESSURE SENSOR
- ROTARY ENCODER
- COUNTER
- TIMER
- TEMPERATURE CONTROLLER
- TEMPERATURE/HUMIDITY TRANSDUCER
- POWER CONTROLLER
- PANEL METER
- TACHO/LINE SPEED/PULSE METER
- DISPLAY UNIT
- SENSOR CONTROLLER
- SWITCHING POWER SUPPLY
- GRAPHIC PANEL
- 5-PHASE STEPPING MOTOR & DRIVER & CONTROLLER
- LASER MARKING SYSTEM

**Autonics Corporation**  
http://www.autonics.com

**Satisfiable Partner For Factory Automation**

**HEADQUARTERS :**  
41-5, Yongdang-ro, Ungsang-eup, Yangsan-si, Gyeongsang, 626-847, Korea

**OVERSEAS SALES :**  
Bldg. 402 3rd Fl., Bucheon Techno Park, 193, Yakdae-dong, Wonmi-gu, Bucheon-si, Gyeonggi-do, 420-734, Korea  
TEL:82-32-610-2780 / FAX:82-32-329-0728  
E-mail : sales@autonics.com