

|  |           |
|--|-----------|
| <b>Manual Guideline.....</b>                                       | <b>1</b>  |
| <b>Chapter 1 Shihlin inverter introduction .....</b>               | <b>3</b>  |
| <b>1-1 Inverter specification .....</b>                            | <b>3</b>  |
| <b>1-2 General Specification (Inverter Characteristic) .....</b>   | <b>4</b>  |
| <b>1-3 Outline Dimension Drawing.....</b>                          | <b>6</b>  |
| 1-3-1 0.75K~3.7K (1HP~5HP) .....                                   | 6         |
| 1-3-2 5.5K~15K (7.5HP~20HP) .....                                  | 7         |
| 1-3-3 18.5K~22K (25HP~30HP) .....                                  | 8         |
| 1-3-4 Operation panel DU01(Range 5.5K~22K).....                    | 9         |
| 1-3-5 Operation panel DU02 (Range0.75K~3.7K).....                  | 9         |
| <b>1-4 Component Name.....</b>                                     | <b>10</b> |
| 1-4-1 Nameplate and Model Number .....                             | 10        |
| 1-4-2 0.75K~3.7K (1HP~5HP) .....                                   | 10        |
| 1-4-3 5.5K~15K (7.5HP~20HP) .....                                  | 11        |
| 1-4-4 18.5K~22K (25HP~30HP) .....                                  | 12        |
| <b>1-5 Installation and wiring.....</b>                            | <b>13</b> |
| 1-5-1 Installation Requirement .....                               | 13        |
| 1-5-2 Terminals Wiring: 0.75K to 3.7K (1HP to 5HP) Series .....    | 14        |
| 1-5-3 Terminal wiring 5.5K to 22K (7.5HP to 30HP) Series .....     | 17        |
| 1-5-4 Wiring Information .....                                     | 20        |
| 1-5-5 Single phase power supply .....                              | 21        |
| <b>1-6 Peripherals Selection.....</b>                              | <b>23</b> |
| 1-6-1 No-fuse breaker .....  | 23        |
| 1-6-2 Cable specification / Terminal receptacle specification..... | 24        |
| 1-6-3 Wave filters .....   | 25        |
| 1-6-4 Brake resistor .....   | 26        |
| <b>Chapter 2 Basic operation .....</b>                             | <b>27</b> |
| <b>2-1 Operation Mode .....</b>                                    | <b>27</b> |
| <b>2-2 Flow chart of operation mode switchover .....</b>           | <b>28</b> |
| <b>2-3 Operation procedure.....</b>                                | <b>29</b> |
| 2-3-1 PU Mode, Operation Procedures (Pr79 = 0 or 1).....           | 29        |
| 2-3-2 External Mode, Operation Procedure (Pr79 = 0 and 2 )         | 29        |
| 2-3-3 Combined Mode 1, Operation Procedures ( Pr79=3 ) .....       | 30        |
| 2-3-4 Combined Mode 2, Operation Procedures ( Pr79=4 ) .....       | 30        |

|   |                |
|---|----------------|
| 2-3-5 Combined Mode 3, Operation Procedures ( Pr79=5) .....                     | 31             |
| 2-3-6 Combined mode 4 , Basic operation procedure(Pr79=6) .....                 | 31             |
| 2-3-7 Combined mode 5 , Basic operation procedure (Pr79=7) .....                | 32             |
| 2-3-8 Combined mode 6 , Basic operation procedure (Pr79=8) .....                | 32             |
| 2-3-9 JOG Mode, Operation Procedures (Pr 79 = 0 or 1) .....                     | 33             |
| 2-3-10 External JOG Mode, Operation Procedures .....                            | 33             |
| (Pr79=2 or 3 or 5, multi-functional input terminal is set as JOG function)..... | 33             |
| <b>2-4 Operation mode of control panel.....</b>                                 | <b>34</b>      |
| 2-4-1 Operation mode switching procedure drawing.....                           | 34             |
| 2-4-2 Operation mode switching procedure drawing.....                           | 35             |
| 2-4-3 Frequency setting mode operation procedure drawing .....                  | 36             |
| (▲ ▼ Button to rated frequency) .....   | 36             |
| 2-4-4 Frequency setting mode and operation procedure drawing.....               | 36             |
| (Pressing ,mode to enter frequency setting mode).....                           | 36             |
| 2-4-5 Parameter setting mode operation procedure drawing .....                  | 37             |
| <br><b>Chapter 3 Parameter .....</b>  | <br><b>38</b>  |
| 3-1 Parameter information .....   | 38             |
| 3-2 Parameter function information.....   | 44             |
| <br><b>Chapter 4 Maintenance and Troubleshooting.....</b>                       | <br><b>100</b> |
| 4-1 Daily Inspection Items .....  | 100            |
| 4-2 Regular Inspection (OFF-LINE inspection) ITEMS .....                        | 100            |
| 4-3 Periodic Parts Replacement .....  | 101            |
| <br><b>APPENDIX .....</b>   | <br><b>102</b> |
| Appendix 1 Communication Protocol 〈 Communication sequence 〉 .....              | 102            |
| Appendix 2 Motor Parameter Auto-Tuning Procedures .....                         | 117            |
| Appendix 3 Alarm Code.....  | 118            |
| Appendix 4 Troubleshooting and Solution.....                                    | 121            |
| Appendix 5 PID Parameter adjustment Principle .....                             | 122            |
| Appendix 6 European Standardized compatibility introduction.....                | 123            |
| Appendix 7 MODBUS Parameter list .....  | 125            |
| Appendix 8 Sensorless Vector Control Setting Procedures .....                   | 125            |
| Appendix 9 Manual change record list .....                                      | 125            |

## Manual Guideline

Shihlin universal electronic inverter is designed for various parameter functions in order to cater most application requirements in the market. The inverter with this massive parameters and complex functions may cause user confused, especially for the first time user, therefore, please carefully read every part of the manual to master how to use the inverter. Should anything to be further explained, please call us, Thank you.

The first chapter lists in detail about the specification of all series Shihlin universal electronic inverter. However, Section 1-5 instructs users the methods to install the inverters and highlights the safety matters which should be attended.

The second chapter explains how to use the inverter, and section 2-1 outlined **operating mode of the inverter**. Section 2-2 instructs the methods to shift the operating mode; Section 2-3 lists the operating procedure steps for every operating mode; Section 2-4 instructs the methods to use operation panel to shift operating mode, setting frequency and setting parameters so that users can enable the motor run easily by inverter. After users are familiar with basic operation above, users can begin chapter 3, and please literally read every parameter function.

1. The actual output current frequency from inverter is **“Output Frequency”**. The frequency set by users (it can be set from operation panel, multi-speed terminals, voltage signal, current signal) is **“Setting Frequency”**. After motor starts, the output frequency will gradually accelerate to Setting Frequency Value and then motor rotates stably as Frequency Setting given value, the output frequency now is called **“Stable Output Frequency”**.
2. There is detailed description in chapter 3 about inverter parameter setting. If the user isn't familiar with parameter setting, and the user randomly adjusts the parameter setting value, this may cause malfunction. Parameter Pr998 can be used to restore all parameters back to default value.
3. In order to maximize the inverter's function, there are 2 major operation modes designed for inverter: Inverter's operation mode (operation mode) and the Digital Unit operation mode (working mode). The operation mode of inverter is used to decide **reference source of running frequency** and **the source of start signal**. There are 9 operation modes totally for inverter, as **PU mode**(Pr79=0、1), **External mode**(Pr79=0、2), **JOG mode**(Pr79=0、1), **Combined mode 1**(Pr79=3), **Combined mode 2**(Pr79=4), **Combined mode 3**(Pr79=5), **Combined mode 4**(Pr79=6), **Combined mode 5**(Pr79=7), **Combined mode 6**(Pr79=8), and there are 3 types of operation mode for operation panel as **Surveillance mode**, **Parameter Setting mode**, and **Frequency setting mode**.

4. The differences between “Terminals Name” and “Terminal Function”:  
Near the terminals of the control board or the main-circuit board, printed letters can be found. These letters are used to differentiate each terminal. They are called Terminal name. Besides understanding “input terminal” and “output terminal”, we have to define its functional name. Function name is the actual application of its terminal. When we explain the functions of terminals, the name we used are called **Function Name**.
5. The difference between 「on」 and 「turn on」 :  
For the description of [input terminal], we usually use [on] and [turn on]. [On] is used to describe the external switch of terminal is closed; this word is about the status description. [Turn on] is usually used to describe the external switch of terminal shifting from open to closed, it belongs to operation status description.

# Chapter 1 Shihlin inverter introduction

## 1-1 Inverter specification

### 220V class series

| Model # : SH020-□□□K      |                                    | 0.75K   | 1.5K               | 2.2K | 3.7K | 5.5K | 7.5K | 11K  | 15K  | 18.5K | 22K |
|---------------------------|------------------------------------|---|--------------------|------|------|------|------|------|------|-------|-----|
| Applicable Motor Capacity | HP                                 | 1   | 2                  | 3    | 5    | 7.5  | 10   | 15   | 20   | 25    | 30  |
|                           | kW                                 | 0.75  | 1.5                | 2.2  | 3.7  | 5.5  | 7.5  | 11   | 15   | 18.5  | 22  |
| Output                    | Rated Capacity kVA (Note)          | 1.9   | 3                  | 4.2  | 6.7  | 9.2  | 12.6 | 17.6 | 23.3 | 29    | 34  |
|                           | Rated Current A(Note)              | 5   | 8                  | 11   | 17.5 | 24   | 33   | 46   | 61   | 76    | 90  |
|                           | Overload Current Rating            | 150% 60 seconds ; 200% 0.5 seconds (inverse-time characteristics) |                    |      |      |      |      |      |      |       |     |
|                           | Voltage                            | Three-Phase 200 to 230V   |                    |      |      |      |      |      |      |       |     |
| Power Supply              | Rated Input AC Voltage, Frequency  | Three-Phase 200 to 230V 50Hz / 60Hz                               |                    |      |      |      |      |      |      |       |     |
|                           | Permissible AC Voltage Fluctuation | 180 to 253V 50Hz / 60Hz   |                    |      |      |      |      |      |      |       |     |
|                           | Permissible Frequency Fluctuation  | ±5%   |                    |      |      |      |      |      |      |       |     |
|                           | Power Supply kVA                   | 2.5   | 4.5                | 5.5  | 9    | 12   | 17   | 20   | 28   | 34    | 41  |
| Protective Structure      |                                    | Enclosed type   |                    |      |      |      |      |      |      |       |     |
| Cooling System            |                                    | Self Cooling  | Forced air cooling |      |      |      |      |      |      |       |     |
| Weight (kg)               |                                    | 1.3   | 1.5                | 2.2  | 2.2  | 5.6  | 5.6  | 8.3  | 8.3  | 20    | 20  |

### ● 440V class series

| Model # : SH040-□□□K      |                                    | 0.75K   | 1.5K | 2.2K               | 3.7K | 5.5K | 7.5K | 11K  | 15K  | 18.5K | 22K  |
|---------------------------|------------------------------------|---|------|--------------------|------|------|------|------|------|-------|------|
| Applicable Motor Capacity | HP                                 | 1   | 2    | 3                  | 5    | 7.5  | 10   | 15   | 20   | 25    | 30   |
|                           | kW                                 | 0.75  | 1.5  | 2.2                | 3.7  | 5.5  | 7.5  | 11   | 15   | 18.5  | 22   |
| Output                    | Rated Capacity kVA (Note)          | 2   | 3    | 4.6                | 6.9  | 9.1  | 13   | 17.5 | 23.6 | 29    | 32.8 |
|                           | Rated Current A(Note)              | 2.6   | 4    | 6                  | 9    | 12   | 17   | 23   | 31   | 38    | 44   |
|                           | Overload Current Rating            | 150% 60 seconds ; 200% 0.5 seconds (inverse-time characteristics) |      |                    |      |      |      |      |      |       |      |
|                           | Voltage                            | Three-Phase 380 to 460V   |      |                    |      |      |      |      |      |       |      |
| Power Supply              | Rated Input AC Voltage, Frequency  | Three-Phase 380 to 460V 50Hz / 60Hz                               |      |                    |      |      |      |      |      |       |      |
|                           | Permissible AC Voltage Fluctuation | 323 to 506V 50Hz / 60Hz   |      |                    |      |      |      |      |      |       |      |
|                           | Permissible Frequency Fluctuation  | ±5%   |      |                    |      |      |      |      |      |       |      |
|                           | Power Supply kVA                   | 2.5   | 4.5  | 5.5                | 9    | 12   | 17   | 20   | 28   | 34    | 41   |
| Protective Structure      |                                    | Enclosed type   |      |                    |      |      |      |      |      |       |      |
| Cooling System            |                                    | Self-cooling  |      | Forced air cooling |      |      |      |      |      |       |      |
| Weight kg                 |                                    | 1.3   | 1.5  | 2.5                | 2.5  | 5.6  | 5.6  | 8.3  | 8.3  | 20    | 20   |

(Note) The test condition of rated output current, rated output capacity: the carrier frequency (Pr72) is 2 kHz the inverter output voltage is 220V / 440V; the output frequency is 60Hz; and the ambient temperature is 40°C.


## 1-2 General Specification (Inverter Characteristic)

|                         |  |                              |  |
|-------------------------|--|------------------------------|--|
| Control Specification   | Control System                         |                              | SPWM control 、 V/F control 、 Sensorless vector control (motor parameter auto tuning).  |
|                         | Output frequency range                 |                              | 0.2 to 400Hz (Starting Frequency Range is 0 to 60Hz).  |
|                         | Frequency Setting resolution           | Digital input                | Rated frequency within 100Hz, resolution is 0.01Hz.<br>Rated frequency above 100Hz, resolution is 0.1Hz.                     |
|                         |  | Analog input                 | Set Signal DC 0 to 5V, resolution is 1/500.<br>Set Signal DC 0 to 10V or 4 to 20mA, resolution is 1/1000.                    |
|                         | Output Frequency accuracy              | Digital input                | Within $\pm 0.01\%$ of maximum.  |
|                         |  | Analog input                 | Within $\pm 0.5\%$ of maximum.   |
|                         | Voltage/frequency characteristics      |                              | Base voltage (Pr19), base frequency (Pr3) can be set as required.<br>Load Pattern Selection (Pr14).                          |
|                         | Starting torque                        |                              | 120%/0.5Hz 、 150%/3Hz.   |
|                         | Torque boost(V/F control)              |                              | Range from 0 to 30% (Pr0).   |
|                         | Acceleration/deceleration time setting |                              | Setting range from 0 to 3600sec (Pr7, Pr8).<br>Different pattern of “acceleration/deceleration mode” can be selected (Pr29). |
|                         | DC injection brake                     |                              | Operation frequency 0 to 120Hz (Pr10), Operation time 0 to 10sec (Pr11), Operation ability 0 to 30% (Pr12).                  |
|                         | Stall prevention operation level       |                              | Stall prevention operation level 0 to 200% (Pr22).   |
| Operation Specification | Frequency Setting                      |                              | Digital Unit, DC 0 to 5V, DC 0 to 10V, DC 4 to 20mA, Multi-speed setting.  |
|                         | Input Terminals                        | Motor Starting Signal        | Use external signal or Digital Unit to start rotation.   |
|                         |  | Second function              | Second acceleration time (Pr44), Second deceleration time (Pr45), Second torque boost (Pr46), Second base frequency (Pr47).  |
|                         |  | External thermal relay input | Can use external thermal relay to protect motor.   |

|                             |                     |                               |  |
|-----------------------------|---------------------|-------------------------------|--|
|                             |                     | Emergency stop                | Use external switch for emergency stop. It will instantaneous shut-off of the inverter output.   |
|                             |                     | Reset                         | Use external switch or Digital Unit to reset inverter.   |
|                             | Output<br>Terminals | Operation status              | Motor running detection, output frequency detection, overload detection, zero current detection, PID alarm detection, Permitting loading DC 24V, 0.1A.   |
|                             |                     | Alarm relay                   | When warning occurred, Alarm Relay start to operate detection alarm signal to detect alarm. Permitting loading DC 24V, 0.1A.   |
|                             |                     | Meter                         | Allow to connect with external meter: Frequency counter or 1mA full-scale meter is used to indicate output frequency or output current.<br>Allowable load current 1mA, 1440pulse/sec at 60Hz.                    |
| Indication                  | Operation<br>Penal  | Operating status surveillance | Monitor output frequency, output current, output voltage, 4 alarm records can be restored.( Max accumulation records: 4 sets)  |
|                             |                     | Motor running indicate        | LED indicator for motor forward or reverse rotation  |
|                             | Inverter            | LED indicator                 | Power indicator (Power), Alarm indicator (Alarm).  |
| Protective/warning function |                     |                               | Overcurrent, Regenerative overvoltage protection, Motor overheat protection (Pr9), IGBT overhead protection, Brake-transistor alarm, Cooling fan fail alarm, Leakage current protection. Low voltage protection. |
| Environment                 | Ambient temperature |                               | -10 to +50 °C (non-freezing)   |
|                             | Ambient humidity    |                               | 90%Rh Max. (non-condensing)  |
|                             | Storage temperature |                               | -20 to +65 °C  |
|                             | Atmosphere          |                               | Indoor, without corrosive gas, flammable gas, oil mist, dust, and dirt etc.  |
|                             | Vibration           |                               | 5.9m/sec <sup>2</sup> (0.6G) or less ( Accord to standard JIS C0911 )  |

# 1-3 Outline Dimension Drawing




## 1-3-1 0.75K~3.7K (1HP~5HP)



| Model #     | W<br>(mm) | W1<br>(mm) | H<br>(mm) | Model #     | W<br>(mm) | W1<br>(mm) | H<br>(mm) |
|-------------|-----------|------------|-----------|-------------|-----------|------------|-----------|
| SH020-0.75K | 105       | 93         | 117       | SH040-0.75K | 140       | 128        | 128       |
| SH020-1.5K  | 140       | 128        | 128       | SH040-1.5K  | 200       | 188        | 138       |
| SH020-2.2K  | 200       | 188        | 138       | SH040-2.2K  | 200       | 188        | 138       |
| SH020-3.7K  | 200       | 188        | 138       | SH040-3.7K  | 200       | 188        | 138       |




## 1-3-2 5.5K~15K (7.5HP~20HP)




| Model #        | L<br>(mm) | L1<br>(mm) | W<br>(mm) | W1<br>(mm) | H<br>(mm) |
|----------------|-----------|------------|-----------|------------|-----------|
| SH020/040-5.5K | 323       | 303        | 200       | 186        | 186       |
| SH020/040-7.5K | 323       | 303        | 200       | 186        | 186       |
| SH020/040-11K  | 350       | 330        | 230       | 214        | 195       |
| SH020/040-15K  | 350       | 330        | 230       | 214        | 195       |

1-3-3 18.5K~22K (25HP~30HP)



| Model #         | L<br>(mm) | L1<br>(mm) | W<br>(mm) | W1<br>(mm) | H<br>(mm) |
|-----------------|-----------|------------|-----------|------------|-----------|
| SH020/040-18.5K | 379       | 348        | 271       | 236        | 248       |
| SH020/040-22K   | 379       | 348        | 271       | 236        | 248       |


### 1-3-4 Operation panel DU01 (Range 5.5K~22K)



LNKSSCBL0XT\*<sup>1</sup> series extension line is optional for range 5.5K~22K.

\*1. 0X means that 01 : the line length is 1.5m , 02 : the line length is 3m , 03 : the line length is 5m.

***1-3-5 Operation panel DU02 (Range0.75K~3.7K)***





LNKCBL0XT\*2 series extension line is optional for range 0.75K~3.7K.

\*2. 0X means that 01 : the line length is 1.5m , 02 : the line length is 3m , 03 : the line length is 5m.


## 1-4 Component Name

### 1-4-1 Nameplate and Model Number

|  |             |  |                 |
|--|-------------|--|-----------------|
| Inverter type  | MODEL :     | <b>SH-020-5.5KBC</b>   | <b>INVERTER</b> |
| Applicable motor capacity  | POWER :     | 5.5KW  | <b>CE</b>       |
| Rated input  | INPUT :     | 35.5A 3PH AC200~230V 50/60Hz   |                 |
| Rated output   | OUTPUT :    | 24A MAX 3PH AC200~230V   |                 |
| (Rated output current,max. output voltage,<br>permissible frequency range) |             | 0.2~400Hz  |                 |
| Working number (Bar code)  | MFG. NO :   |  | L2L0072         |
| Serial number  | SERIAL NO : | HA000001   | MADE IN TAIWAN  |


Version 

### 1-4-2 0.75K~3.7K (1HP~5HP)




1. Push the latch of top cover and pull the cover toward you to remove.
2. 『Wiring outlet hole』 is designed for fixing and protecting the lead wire. When wiring, lead wire must pass through 『Wiring outlet hole』 and then connects with terminals, please use cable tie to tie the wires in a bundle.
3. To use the switch for the AM/FM functions、FU/10X jump and RS485 communication interface, you must remove the operation panel and the top cover first. Please contact the qualified electrical engineer for configuring.

### 1-4-3 5.5K~15K (7.5HP~20HP)



1. Loosen the installation screw of the front cover, Push the top cover latch and pull the cover toward you to remove.
2. 『Wiring outlet hole』 is designed for fixing and protecting the lead wire. When wiring, lead wire must pass through 『Wiring outlet hole』 and then connects with terminals, please use cable tie to tie the wires in a bundle.
3. The inverter of 5.5K~15K (7.5HP~20HP) series, there is a pair of jumper connector provided for users to set the control logic. (shown on the chart) When jumper connector is set on sink logic (SINK) , it default the input terminals as sink input. When jumper connector is set on source logic (SOURCE), then the default of input terminals is source input. The output signals may be used in either the sink or source logic independently of the jumper connector position ,Otherwise there will be possible damage to the inverter.





### 1-4-4 18.5K~22K (25HP~30HP)



1. Loosen the installation screw of the front cover, Pull the cover to remove.
2. 『Wiring outlet hole』 is designed for fixing and protecting the lead wire. When wiring, lead wire must pass through 『Wiring outlet hole』 and then connects with terminals, please use cable tie to tie the wires in a bundle.
3. The inverter of 18.5K~22K (25HP~30HP) series, there is a pair of jumper connector provided for users to set the control logic. (shown on the chart) When jumper connector is set on sink logic (SINK) , it default the input terminals as sink input. When jumper connector is set on source logic (SOURCE), then the default of input terminals is source input. The output signals may be used in either the sink or source logic independently of the jumper connector position ,Otherwise there will be possible damage to the inverter.

## 1-5 Installation and wiring


### 1-5-1 Installation Requirement

|  |  |
|--|--|
| <p>1. Vertical mount</p>    | <p>2. Please make sure there is enough space around the inverter.</p>    |
| <p>3. Keep ambient temperature lower than rated value.</p>  <p>Temperature measuring point</p>   | <p>4. Install inverter on right location with protection chassis.</p>  <p>Ventilation fan</p> <p>Ventilation hole</p> |
| <p>5. Do not install the inverter on excessive vibration working platform (such as lathe, milling machine etc).</p> <p>6. Do not install the inverter on wooden material and other combustile surface.</p> <p>7. Do not install near the explosive, inflammable gas, dust and dirt environment.</p> <p>8. Do not install near oil mist, dust and dirt environment.</p> <p>9. Do not install near corrosive gas, salted air environment.</p> <p>10. Do not install the inverter in a place subject to high temperature, high humidity.</p> <p>11. Installed in the Distribution Box, Please be sure to install ventilation fan to prevent excessive temperature</p> |  |

(Note 1) Only certified electrician is allowed to perform installation, wiring, disassembly, and maintenance.

(Note 2) Please do follow the installation requirement to install inverter. Equipment damaged or serious jeopardized to public security can result from failure to follow above mentioned installation requirement, under the circumstance our company will be free from any legal responsibility. If there is any doubt on installation, please call for assistance and information.

## 1-5-2 Terminals Wiring: 0.75K to 3.7K (1HP to 5HP) Series




(Note 1) On above diagram, main circuit is with thicker lines and control circuit is with thin lines.


(Note 2) Please refer to Pr59 in chapter 3 (page 52) for using external thermal relay.

(Note 3) For inverter of 0.75K to 3.7K (1HP to 5HP) series, input terminals are Sink Input. As for wiring not matter what kind of control type of input terminals, the external wiring can be used as simple switch connection. When it is "ON", input current drive photo coupler of inverter and then photo coupler transmits signal into CPU.






Sink input



Sink input and open collector output is used.

(Note 4) Definition of main circuit terminals:


| Symbol  | Description  |
|---|--|
| R- S- T   | Connect to commercial power supply.  |
| U-V-W   | Output to three-phases squirrel cage motor.  |
| P- PR   | Connect to brake resistor.   |
| P- N  | Connect to brake unit (Optional).  |
|  | For grounding the inverter case. The third type of grounding shall be adopted for 220V series. Special type of grounding shall be adopted for 440V series. |

1. In order to improve the brake for deceleration, it is better to install optional [brake unit] between terminals P-N. [Brake unit] can effectively absorb the energy from inverter when decelerate. If there is any question for buying [brake unit], please call us for assistance.
2. 0.75K~3.7K (1HP~5HP) series inverters can be installed AC reactor but DC reactor not allowed to install.

(Note 5) Definition of control circuit terminals

| Terminals of Control Circuit           |                 |                   |   |                              |
|--|-----------------|-------------------|---|------------------------------|
| Type                                   | Terminal Symbol | Terminal Function | Description   |                              |
| Sink input or Source input             | PC              | PC                | Common point for external power input terminals.  |                              |
|  | STF             | STF               | Turn on STF to start forward rotation   | Refer to Pr74 (page 69)      |
|  | STR             | STR               | Turn on STR to start reverse rotation   |                              |
|  | RES             | RES               | Turn on RES for more than 0.1sec to reset the inverter.   |                              |
|  | RL/OH           | Selectable        | These are “Multifunctional input terminals”. User can define its function name by setting different value into Pr59.(page 52)   |                              |
|  | RM/AU           |                   |   |                              |
|  | RH              |                   |   |                              |
|  | MRS/RT          |                   |   |                              |
|  | SD              | SD                | Common point to the contact input terminals.  |                              |
| Analog signal input terminals          | 10              | -----             | Frequency setting power supply. DC 5V, permissible maximum load current: 10mA.  |                              |
|  | 2               | -----             | Input terminals of DC 0 to 5V or 0 to 10V, this voltage signal can be used for rated frequency setting .Variable resistor 1KΩ / 2W  | Refer to Pr38,Pr73 (page 59) |
|  | 4               | -----             | Terminals of 4 to 20mA, this current signal can be used for rated frequency setting.  | Refer to Pr39 (page 59)      |
|  | 5               | -----             | Reference source for analog signal input.   |                              |
| Relay output Terminals                 | A               | Selectable        | 1.Can be used as Alarm Terminal.<br>2.Can be used as Multifunctional output terminals.<br>Alarm: Continuity across A-C, Discontinuity across B-C.<br>(Note) inner relay contact capacity: DC 30V / AC 230V 0.3A.                    |                              |
|  | B               |                   |   |                              |
|  | C               |                   |   |                              |
| Output terminals (Open collector mode) | RUN             | Selectable        | The terminal is “Multifunctional output terminals” user can define its function of these terminals by setting different value figures into Pr40 (page 60), permissible load DC 24V, 0.1A.   |                              |
|  | FU/10X          | Selectable        |   |                              |
|  | SE              | SE                | Common terminal of output terminals.  |                              |
| Pulse /Analog output                   | FM/AM           | ---               | Selection FM function can use “Frequency meter” or “1mA full-scale meter” to indicate the output frequency or the output current. Use AM function can use a 0 ~ 5V Voltage Meter .<br>Refer to Pr54, Pr55, Pr56 and Pr192.(page 63) |                              |
| Communication interface                | RS485           | ---               | Serial communication interface.   |                              |


### 1-5-3 Terminal wiring 5.5K to 22K (7.5HP to 30HP) Series




(Note 1) On above diagram, main circuit is with thicker lines and control circuit is with thin lines.

(Note 2) Please refer to Pr59 in chapter 3 (page 52) for using external thermal relay.


(Note 3) In inverter series of 5.5K to 22K (7.5HP to 30HP) use jump to set input terminal as Sink Input or Source Input. As for wiring please refer to following diagram. No matter what control type of input terminal, the external wiring is only a simple switch wiring connection. When switch is on, photo coupler of inverter is driving by input current and then the signal is transferring to CPU through photo coupler.




Sink input



Sink input and open collector output is used.




Sink input



Source input and open collector output is used.

(Note 4) Definition of main circuit terminals:

| Description   |  |
|---|--|
| R- S- T   | Connect to commercial power supply   |
| U-V-W   | Output to three-phase squirrel cage motor  |
| P- PR.  | Connect to brake resistor (11K~22K optional)   |
| P- P1   | Connect to DC reactor (Optional)   |
| P- N  | Connect to brake Unit (Optional)   |
|  | For grounding the inverter case. The third type of grounding shall be adopted for 220V series. Special type of grounding shall be adopted for 440V series. |

1. There is a standard brake resistor already built-in for 5.5K to 7.5K (7.5HP to 10HP) series. If inverter is operating with frequent acceleration/deceleration or short deceleration time ( $Pr8 < 5\text{sec}$ ), a high-duty brake resistor is needed to be used between P-PR terminals. Please remove the built-in brake resistor and replace the high duty brake resistor. (Only certified technician is allowed to perform replacement and remove brake resistor).
2. For the motors above 7.5K, please do not run them without brake resistor, for the motors above 25HP; please do not run them without brake resistor or brake unit. Otherwise, there may be the damage to inverter.

3. There is a brake transistor built-in for 5.5K to 15K (7.5HP to 20HP) series. User only needs to install brake resistor (7.5HP~10HP built-in). There is no a brake transistor already built-in for 18.5K~22K (25HP~30HP) series. In order to increase brake capability during deceleration, install a brake unit between terminals P-N is suggested. The brake unit is able to consume the regenerative power efficiently. If there is any question about brake unit procurement, please feel free to call for assistance.
4. To use DC /AC reactor is one way to increase input power factor and to do better control in inrush current harmonic. In the inverter series of 5.5K to 15K (7.5HP to 20HP), between P-P1 terminals there is a jumper. If a DC reactor is planning to use, please remove the jumper first and then to wire P-P1 terminals with DC reactor.

(Note 5) Definition of control circuit terminals


| Terminals of Control Circuit     |        |                   |  |                                    |
|----------------------------------|--------|-------------------|--|------------------------------------|
| Type                             | Symbol | Terminal Function | Description  |                                    |
| Sink input<br>or<br>Source input | PC     | PC                | Common point for external power input terminals.   |                                    |
|                                  | STF    | STF               | Turn on STF to start forward rotation  | Refer to<br>Pr74.<br>(page 69)     |
|                                  | STR    | STR               | Turn on STR to start reverse rotation  |                                    |
|                                  | RES    | RES               | Turn on RES for more than 0.1sec to reset the inverter.  |                                    |
|                                  | MRS    | MRS               | Turn on MRS for more than 20ms to shut down the output voltage of inverter.  |                                    |
|                                  | AU     | AU                | If the inverter operation mode is under external mode or combination mode 2,and AU terminal is on, the rated frequency of inverter is set by current signal. |                                    |
|                                  | RL     | Selectable        | These are “Multifunctional input terminals”. User can define its function name by setting different value into Pr59.(page 52)                                |                                    |
|                                  | RM     |                   |  |                                    |
|                                  | RH     |                   |  |                                    |
|                                  | RT     |                   |  |                                    |
|                                  | SD     | SD                | Common point of the contact input terminals.   |                                    |
| Analog signal<br>input terminals | 10     | -----             | Frequency setting power supply. DC 5V, permissible maximum load current: 10mA.   |                                    |
|                                  | 2      | -----             | Input terminals of DC maybe 0 to 5V or 0 to10V,and this voltage signal can be used for frequency setting. Variable Resistors 1KΩ/ 2W                         | Refer to<br>Pr38,Pr73<br>(page 59) |
|                                  | 4      | -----             | Terminals of 4 to 20mA, this current signal can be used for frequency setting.   | Refer to<br>Pr39.<br>(page 59)     |
|                                  | 5      | -----             | Reference source for analog signal input.  |                                    |

|  |        |            |  |
|--|--------|------------|--|
| Relay output Terminals                 | A      | Selectable | 1. Can be used as Alarm Terminal.<br>2. Can be used as Multifunctional output terminals.<br>Alarm: Continuity across A-C, Discontinuity across B-C.<br>(Note)Contact capacity: DC 30V / AC 230V 0.3A.                                |
|  | B      |            |  |
|  | C      |            |  |
| Output terminals (open collector mode) | RUN    | Selectable | The terminal is “Multifunctional output terminals”, user can define its function of these terminals by setting different value into Pr40(page 60), permissible load DC 24V, 0.1A.  |
|  | FU/10X | Selectable |  |
|  | SU     | Selectable |  |
|  | SE     | SE         | Common terminal of output terminals.   |
| Pulse /Analog output                   | FM/AM  | ---        | Selection FM function can use “Frequency meter” or “1mA full-scale meter” to indicate the output frequency or the output current. Use AM function can use a 0 ~ 10V Voltage Meter .<br>Refer to Pr54, Pr55, Pr56 and Pr192.(page 63) |
| Communication interface                | RS485  | ---        | Serial communication interface.  |

## 1-5-4 Wiring Information


### Main circuit wiring:

- Do not connect power cable with motor U-V-W terminals to avoid possible damage to inverter.
- Do not try to use phase filtering capacitors (PFC), harmonic filter, and electromagnetic contactor to connect to inverter power output as right sided diagram display.
- Do not use electromagnetic contactor or no-fuse breaker to start or stop the motor.
- Please make sure grounding the wire to the case of inverter and to motor to avoid possible electric shock.
- Please refer to section 1-6 (page 23) for the specification of cable gauge, circuit rout, receptacles terminal, no- fuse breaker, and electromagnetic contactor for main circuit wiring. If the installation location between inverter and motor is distant from each other, please use wider cable gauge with pressure drop in 2%. (Please keep total wiring length in 500 meters).
- The wire used in power supply side and load side must use insulated sleeves receptacles terminal.
- After disconnected with power supply, please do not touch terminal of P-N to avoid electric shock, because there is remaining high voltage power.



## Control wiring diagram

1. The wire used for analog input terminal must be insulated wire and wire and metal netted must be with terminal 5.
2. It is suggested to use  $0.75\text{mm}^2$  cable gauges for control circuit wiring. Please refer to following instruction for insulated sleeve stripped.
3. Please keep safe distance of control circuit wiring with main circuit wiring. It is strictly forbidden to tight the wiring cable of control circuit with main circuit together.
4. Terminals of SD, SE, 5, and PC are from separately power supply system, please do not wire them together.



(Note 1) Please make sure the screw is closed tightly with terminal. Do not leave any cable remains in the inverter.

(Note 2) Only certified technicians is allowed to perform the installation, and wiring, disassembly, and maintenance.


(Note 3) Please do follow wiring requirement when install inverter. If wiring without following above instruction and result in damage the inverter or offending against public security. Under such circumstance, Shihlin Electrics will be free from any legal responsibility for such incident. If there is any question, please call for professional assistance.

## 1-5-5 Single phase power supply

In 220V series of inverter when input power from single phase power supply, the inrush current of all rectifiers component is higher, temperature is also increased. Therefore the rated current must be decreased when single-phase AC Power is used. Please refer to below table for more detail.

| Model #              | SH020-□□□K                            |        |        |       |
|----------------------|---------------------------------------|--------|--------|-------|
|                      | 0.75K                                 | 1.5K   | 2.2K   | 3.7K  |
| Rated Output Current | 3A                                    | 4A     | 5A     | 7A    |
| Rated Output Voltage | Three-Phase AC200 to 230V             |        |        |       |
| Voltage              | Single Phase AC200 to 230V 50 to 60Hz |        |        |       |
| Capacity             | 2.5kVA                                | 4.5kVA | 5.5kVA | 9kVA  |
| Input Current        | 7.6A                                  | 11.2A  | 12.9A  | 17.4A |


(Notes) Please do not use single phase power supply with 5.5K and above of inverters.



(Note) When inverter is operating with single phase power supply, please make sure to connect it with R and S terminals. Make sure the capacity of power supply is able to handle such operation.



## 1-6 Peripherals Selection



### 1-6-1 No-fuse breaker

| Model #     | Motor Capacity | Power Capacity (kVA) | Recommended No-fuse breaker (Shihlin Electrics) | Recommended Magnetic Contactor (Shinlin Electrics) |
|-------------|----------------|----------------------|---|--|
| SH020-0.75K | 220V 1HP       | 2.5                  | NF30 10A  | S-P11/ S-P12                                       |
| SH020-1.5K  | 220V 2HP       | 4.5                  | NF30 15A  | S-P11/ S-P12                                       |
| SH020-2.2K  | 220V 3HP       | 5.5                  | NF30 20A  | S-P11/ S-P12                                       |
| SH020-3.7K  | 220V 5HP       | 9                    | NF30 30A  | S-P30T   |
| SH020-5.5K  | 220V 7.5HP     | 12                   | NF50 50A  | S-P30T   |
| SH020-7.5K  | 220V 10HP      | 17                   | NF100 60A                                       | S-P40T   |
| SH020-11K   | 220V 15HP      | 20                   | NF100 75A                                       | S-P50T   |
| SH020-15K   | 220V 20HP      | 28                   | NF225 125A                                      | S-P60T   |
| SH020-18.5K | 220V 25HP      | 34                   | NF225 150A                                      | S-P80T   |
| SH020-22K   | 220V 30HP      | 41                   | NF225 175A                                      | S-P100T  |
| SH040-0.75K | 440V 1HP       | 2.5                  | NF30 5A   | S-P11/ S-P12                                       |
| SH040-1.5K  | 440V 2HP       | 4.5                  | NF30 10A  | S-P11/ S-P12                                       |
| SH040-2.2K  | 440V 3HP       | 5.5                  | NF30 15A  | S-P11/ S-P12                                       |
| SH040-3.7K  | 440V 5HP       | 9                    | NF30 20A  | S-P11/ S-P12                                       |
| SH040-5.5K  | 440V 7.5HP     | 12                   | NF30 30A  | S-P21  |
| SH040-7.5K  | 440V 10HP      | 17                   | NF30 30A  | S-P21  |
| SH040-11K   | 440V 15HP      | 20                   | NF50 50A  | S-P30T   |
| SH040-15K   | 440V 20HP      | 28                   | NF100 60A                                       | S-P40T   |
| SH040-18.5K | 440V 25HP      | 34                   | NF100 75A                                       | S-P40T   |
| SH040-22K   | 440V 30HP      | 41                   | NF100 100A                                      | S-P50T   |

### 1-6-2 Cable specification / Terminal receptacle specification

| Model #     | Recommended Cable          |                            | Crimping Terminals |         |
|-------------|----------------------------|----------------------------|--------------------|---------|
|             | R, S, T (mm <sup>2</sup> ) | U, V, W (mm <sup>2</sup> ) | R, S, T            | U, V, W |
| SH020-0.75K | 2                          | 2                          | 2 - 4              | 2 - 4   |
| SH020-1.5K  | 2                          | 2                          | 2 - 4              | 2 - 4   |
| SH020-2.2K  | 2                          | 2                          | 2 - 4              | 2 - 4   |
| SH020-3.7K  | 3.5                        | 3.5                        | 5.5 - 4            | 5.5 - 4 |
| SH020-5.5K  | 5.5                        | 5.5                        | 5.5 - 5            | 5.5 - 5 |
| SH020-7.5K  | 14                         | 8                          | 14 - 5             | 8 - 5   |
| SH020-11K   | 14                         | 14                         | 14 - 5             | 14 - 5  |
| SH020-15K   | 22                         | 22                         | 22 - 6             | 22 - 6  |
| SH020-18.5K | 38                         | 38                         | 38 - 8             | 38 - 8  |
| SH020-22K   | 38                         | 38                         | 38 - 8             | 38 - 8  |

| Model #     | Recommended Cable             |                               | Crimping Terminals |         |
|-------------|-------------------------------|-------------------------------|--------------------|---------|
|             | R, S, T<br>(mm <sup>2</sup> ) | U, V, W<br>(mm <sup>2</sup> ) | R, S, T            | U, V, W |
| SH040-1.5K  | 2                             | 2                             | 2 - 4              | 2 - 4   |
| SH040-2.2K  | 2                             | 2                             | 2 - 4              | 2 - 4   |
| SH040-3.7K  | 2                             | 2                             | 2 - 4              | 2 - 4   |
| SH040-5.5K  | 3.5                           | 2                             | 5.5 - 4            | 2 - 4   |
| SH040-7.5K  | 3.5                           | 3.5                           | 5.5 - 4            | 5.5 - 4 |
| SH040-11K   | 5.5                           | 5.5                           | 5.5 - 6            | 5.5 - 6 |
| SH040-15K   | 14                            | 8                             | 14 - 6             | 8 - 6   |
| SH040-18.5K | 14                            | 8                             | 14 - 6             | 8 - 6   |
| SH040-22K   | 22                            | 14                            | 22 - 6             | 14 - 6  |

**1-6-3 Wave filters (SCHAFFNER filters are only applying for manufacturer inner test, if the user uses other brands, please apply the same specification.)**

| Model       | Filter specification | Model       | Filter specification |
|-------------|----------------------|-------------|----------------------|
| SH020-0.75K | FN3258-7-45          | SH040-0.75K | FN3258-7-45          |
| SH020-1.5K  | FN3258-16-45         | SH040-1.5K  | FN3258-7-45          |
| SH020-2.2K  | FN3258-16-45         | SH040-2.2K  | FN3258-7-45          |
| SH020-3.7K  | FN3258-30-47         | SH040-3.7K  | FN3258-16-45         |
| SH020-5.5K  | FN3258-30-47         | SH040-5.5K  | FN3258-16-45         |
| SH020-7.5K  | FN3258-42-47         | SH040-7.5K  | FN3258-30-47         |
| SH020-11K   | FN3258-55-52         | SH040-11K   | FN3258-30-47         |
| SH020-15K   | FN3258-75-52         | SH040-15K   | FN3258-42-47         |
| SH020-18.5K | FN3258-100-35        | SH040-18.5K | FN3258-42-47         |
| SH020-22K   | FN3258-100-35        | SH040-22K   | FN3258-55-52         |

### 1-6-4 Brake resistor

| Shihlin Inverter Braking Resistor / Braking Unit |                  |              |              |
|--|------------------|--------------|--------------|
| Model  | Braking Resistor |              | Braking Unit |
|  | Specification    | Order Number | Order Number |
| SH020-0.75K                                      | 150W / 100Ω      | ABR150W100   | —            |
| SH020-1.5K                                       | 250W / 60Ω       | ABR300W60    | —            |
| SH020-2.2K                                       | 250W / 60Ω       | ABR300W60    | —            |
| SH020-3.7K                                       | 400W / 40Ω       | —            | —            |
| SH020-5.5K                                       | 1000W / 25Ω      | ABRH1000W25  | —            |
| SH020-7.5K                                       | 1200W / 20Ω      | ABR1500W20   | —            |
| SH020-11K  | 2400W / 13.6Ω    | ABR2400W13R  | —            |
| SH020-15K  | 3000W / 10Ω      | ABR3000W10   | —            |
| SH020-18.5K                                      | 4800W / 8Ω       | ABR4800W8    | BR2022B      |
| SH020-22K  | 4800W / 6.8Ω     | ABR4800W6R8  | BR2022B      |
| SH040-0.75K                                      | 80W / 700Ω       | ABRH80W700   | —            |
| SH040-1.5K                                       | 150W / 350Ω      | ABRH150W350  | —            |
| SH040-2.2K                                       | 250W / 250Ω      | ABR300W250   | —            |
| SH040-3.7K                                       | 400W / 150Ω      | —            | —            |
| SH040-5.5K                                       | 1000W / 75Ω      | ABRH1000W75  | —            |
| SH040-7.5K                                       | 1200W / 75Ω      | —            | —            |
| SH040-11K  | 2400W / 50Ω      | ABR2400W50   | —            |
| SH040-15K  | 3000W / 40Ω      | ABR3000W40   | —            |
| SH040-18.5K                                      | 4800W / 32Ω      | ABR4800W32   | BR4030B      |
| SH040-22K  | 4800W / 27.2Ω    | ABR4800W32   | BR4030B      |

(Note1) For the mentioned capacity of brake resistor is based on 10% of “Special Regenerative Brake Duty” (Pr70). Operating 5 sec stop 45 sec for cooling. This brake is a braking capacity utilization rather than the braking duty cycle representation.

(Note2) When making high frequency start/stop operation, high special regenerative brake duty (Pr70 refer to page 56) is demanded. Please use higher capacity resistor to increase the regenerative brake ability.

(Note 3) Only 5.5K~7.5K (7.5HP~10HP) series production have built-in brake resistor, Other series have no built-in resistor, 0.75~15K refer to above-mentioned resistor specification 18.5~22K required to choose the braking units and braking resistors if there is a need to make outside equipment connection , please refer to above specification and the wire connection method:









0.75K~15K (1HP~20HP): Connect braking resistor to P-PR terminals of the main circuit.



18.5K~22K (25HP~30HP): Connect braking unit to P-N terminals of the main circuit, then connect braking resistor to brake unit's P-PR terminals. If there is any doubt about braking unit selection, please call for assistance.

## Chapter 2 Basic operation

### 2-1 Operation Mode


The operation mode of inverter is related to **reference of rated running frequency** and **Signal of starting motor**. There are 9 operation modes of SH type inverter: PU mode (Pr79=0), JOG mode(Pr79=1), External mode(Pr79=2), Combined mode 1(Pr79=3), Combined mode 2(Pr79=4), Combined mode 3(Pr79=5), Combined mode 4 (Pr79=6), Combined mode 5(Pr79=7), Combined mode 6(Pr79=8).

| Relate Parameters                        | Setting Value | Description   |  |
|--|---------------|---|--|
| Operation Mode Pr79                      | 0             | PU Mode, External Mode and JOG Mode enable switchover operation.                            |  |
|  | 1             | PU Mode and JOG Mode enable switchover operation.   |  |
|  | 2             | External Mode.(external frequency and start up)   |  |
|  | 3             | Combined Mode 1. ( inner PU frequency and external start up)                                |  |
|  | 4             | Combined Mode 2. ( external frequency and inner start up)                                   |  |
|  | 5             | Combined Mode 3 ( inner PU frequency and external multi-speed frequency, external start up) |  |
|  | 6             | Combined Mode 4 (RS485 Frequency RS485 start up)  |  |
|  | 7             | Combined Mode 5 (RS485 Frequency External start up)   |  |
|  | 8             | Combined Mode 6 (External Frequency or multi-speed RS485 start up)                          |  |
| Pr79 setting value                       |               | Reference of rated frequency  | Reference value for starting signal  |
| 0<br>(switch over PU,external, Jog,mode) | PU Mode       | Inner PU  | Inner PU  ,  |
|  | External mode | External current,voltage signal or external multi-speed                                     | External STF,STR terminals   |
|  | JOG Mode      | Setting by parameter Pr15   | Inner PU  ,  |
| 1<br>(switchable PU,Jog,mode)            | PU Mode       | Inner PU  | Inner PU  ,  |
|  | JOG Mode      | Setting by parameter Pr15   | Inner PU  ,  |
| 2<br>(External mode)                     |               | External current,voltage signal or external multi-speed                                     | External STF,STR terminals   |
| 3<br>(Combined Mode 1)                   |               | Inner PU  | External STF,STR terminals   |


| Pr79 setting value    | Reference of rated frequency                                | Reference value for starting signal  |
|-----------------------|---|--|
| 4<br>(Combined Mode2) | External current, voltage signal<br>or external multi-speed | Inner PU  ,  |
| 5<br>(Combined Mode3) | Inner PU or external<br>multi-speed                         | External STF,STR terminals   |
| 6<br>(Combined Mode4) | RS485 communication<br>interface                            | RS485 communication interface<br>activated, the motor rotate forward or<br>reversely rotate  |
| 7<br>(Combined Mode5) | RS485 communication<br>interface                            | External STF, STR terminals  |
| 8<br>(Combined Mode6) | External current, voltage signal<br>or external multi-speed | RS485 communication interface<br>activated, the motor rotate forward or<br>reversely rotate  |

## 2-2 Flow chart of operation mode switchover

When Pr79=0:



When Pr79=1:








(Note 1)






1. In "PU Mode", indicator of "PU" on Digital Unit is lit. Pr79=0.
2. In "External Mode", indicator of "EXT" on Digital Unit is lit. Pr79=2.
3. In Combined Mode 1~6, indicator of "PU" and "EXT" on Digital Unit are lit. Pr79=3~8.
4. In "JOG Mode", indicator of "PU" is lit, and the screen will display **J00** when inverter is not in operation. Pr79=1.

## 2-3 Operation procedure







### 2-3-1 PU Mode, Operation Procedures (Pr79 = 0 or 1)

| Procedures | Description  |
|------------|--|
| 1          | Switch operation mode to PU mode, indicator of <b>PU</b>  is lit.<br><br>(Note) 1.When Pr79=0, Inverter will be in external mode after turn on power or restart inverter.<br>2.When Pr79=1, Inverter will be continuously in PU mode after turn on power or restart the inverter.   |
| 2          | Enter frequency setting mode, and enter desired frequency into CPU.<br>(Note) Operation procedures of frequency setting model please refer to 2-4-3. 2-4-4 (page 36)   |
| 3          | After pressing <b>FWD</b> or <b>REV</b> , motor starts to operate. At the same time indicator of <b>FWD</b>  and <b>REV</b>  is flickering, indicating motor in operation and it will enter “Monitoring Mode” automatically.<br>(Note) During motor operation it is allowed to enter frequency setting mode to rewrite frequency into CPU and vary motor rotation speed on line. |
| 4          | After pressing <b>STOP RESET</b> , motor would decelerate until stop. The indicator <b>FWD</b>  or <b>REV</b>  would be turn off, after stop inputting voltage.  |








### 2-3-2 External Mode, Operation Procedure (Pr79 = 0 and 2 )

| Procedures | Description  |
|------------|--|
| 1          | Switchover operation mode to External Mode, at the same time <b>EXT</b>  is lit.<br>(Note)1.When Pr79=0, after start the power or retry the inverter, inverter is in external mode.<br>2.When Pr79=2, inverter will be continuously in external mode. |
| 2          | Rated frequency is entered into multi-speeded parameter or the voltage for rated frequency is set to 2-5 terminals or the current for rated frequency is set to 4-5 terminals.   |
| 3          | Turn on STF or turn on STR is to activate motor operation. Indicator of <b>FWD</b>  or <b>REV</b>  will be flickering, it indicates the motor is in rotation.      |
| 4          | After turn off STF and STR, motor would decelerate until stop. The indicator <b>FWD</b>  or <b>REV</b>  would be turn off, after stop inputting voltage.             |

### 2-3-3 Combined Mode 1, Operation Procedures ( Pr79=3 )

| Procedures | Description  |
|------------|--|
| 1          | When Combined Mode 1 is in operation, indicator of <b>PU</b>  and <b>EXT</b>  are both lit.  |
| 2          | Enter frequency setting mode, and write rated frequency into CPU.<br>(Note) Operation procedure of frequency setting mode, please refer to 2-4-3. 2-4-4. (Page 36)   |
| 3          | STF turn on and STR turn on, start motor rotation..<br>Indicator of <b>FWD</b>  and <b>REV</b>  is flickering, it indicates that motor is on rotation.<br>(Note) During motor operation it is allowed to enter frequency setting mode to rewrite frequency into CPU and vary motor rotation speed on line. |
| 4          | After turn off STF and STR, motor would decelerate until stop. The indicator <b>FWD</b>  or <b>REV</b>  would be turn off, after stop inputting voltage.   |

### 2-3-4 Combined Mode 2, Operation Procedures ( Pr79=4 )

| Procedures | Description   |
|------------|---|
| 1          | When Combined Mode 2 is in operation, indicator of <b>PU</b>  and <b>EXT</b>  are both lit.   |
| 2          | Rated frequency is entered into multi-speeded parameter or the voltage for rated frequency is set to 2-5 terminals or the current for rated frequency is set to 4-5 terminals.  |
| 3          | Pressing button of <b>FWD</b> or <b>REV</b> , the motor start rotation. In the meantime indicator of <b>FWD</b>  or <b>REV</b>  is flickering, it indicates the motor is in operation and operation panel is entered monitoring mode automatically. |
| 4          | After pressing  , motor would decelerate until stop. The indicator <b>FWD</b>  or <b>REV</b>  would be turn off, after stop inputting voltage.                 |









### 2-3-5 Combined Mode 3, Operation Procedures ( Pr79=5)

| Procedures | Description  |
|------------|--|
| 1          | When Combined Mode 3 is in operation, indicator of <b>PU</b> and <b>EXT</b> are both lit.  |
| 2          | Enter Frequency Setting Mode, and write rated frequency into CPU.<br>If rated frequency is referred to multi-speeded terminal, please set the frequency as Pr4~ Pr6、Pr24~ Pr27、Pr126~ Pr133(Page 46)   |
| 3          | STF turn on and STR turn on, start motor rotation..<br>Indicator of <b>FWD</b> and <b>REV</b> is flickering, it indicates that motor is on rotation.<br>(Note) The frequency setting mode is assessable during the rotation of motor, and the rated frequency is changeable in the CPU so that the speed of motor is changeable. |
| 4          | After turn off STF and STR, motor would decelerate until stop. The indicator <b>FWD</b> or <b>REV</b> would be turn off, after stop inputting voltage.   |







### 2-3-6 Combined mode 4, Basic operation procedure(Pr79=6)

| Procedures | Description  |
|------------|--|
| 1          | Under Combined mode 4, indicator <b>PU</b> and <b>EXT</b> will be lit.   |
| 2          | Utilize RS485 communication interface, input the rated frequency into CPU.   |
| 3          | Under RS485 operation interface, input the order code of rotating forwards or backwards, motor begins to rotate. Meanwhile indicator <b>FWD</b> or <b>REV</b> will flickering, indicating motor is rotating. Operation panel will automatically switch into surveillance mode. |
| 4          | Under RS485 operation interface, input the order code of stop, then the motor decelerates until it stops.<br>The indicator <b>FWD</b> or <b>REV</b> of inverter will be off after the electricity shuts down.  |










### 2-3-7 Combined mode 5, Basic operation procedure (Pr79=7)

| Procedures | Description  |
|------------|--|
| 1          | Under Combined mode 5, indicator <b>PU</b>  and <b>EXT</b>  will be lit.   |
| 2          | Utilize RS485 communication interface, input the rated frequency into CPU.   |
| 3          | If STF turn on or STR turn on, the motor will begin to rotate.<br>At the same time, indicator <b>FWD</b>  or <b>REV</b>  will flickering, which indicates the motor is working. |
| 4          | If STF turn off or STR turn off, motor will decelerate until stop.<br>The indicator <b>FWD</b>  or <b>REV</b>  of inverter will be off after the electricity shuts down.         |

### 2-3-8 Combined mode 6, Basic operation procedure (Pr79=8)





| Procedures | Description   |
|------------|---|
| 1          | Under Combined mode 6, indicator <b>PU</b>  and <b>EXT</b>  will be lit.  |
| 2          | Input rated frequency into multi-speed parameter or into the counterpart voltage of rated frequency to terminals 2-5 or to 4-5.   |
| 3          | Under RS485 operation interface, input forwards or backwards order code, the motor begins to rotate. Meanwhile indicator <b>FWD</b>  or <b>REV</b>  will flickering, which indicates motor is rotating. Operation panel will automatically switch into surveillance mode. |
| 4          | Under RS485 operation interface, input the order code of stop, then the motor decelerates until stop.<br>The indicator <b>FWD</b>  or <b>REV</b>  of inverter will be off after the electricity shuts down.   |

### 2-3-9 JOG Mode, Operation Procedures (Pr 79 = 0 or 1)

| Procedures | Description   |
|------------|---|
| 1          | Switch operation mode to JOG Mode, in the meantime indicator of <b>PU</b>  is lit and monitor display <b>u00</b> when motor is not rotating.   |
| 2          | <p>1. Press keys of <b>REV</b>  or <b>FWD</b> , the motor start rotation. Indicator of <b>FWD</b>  or <b>REV</b>  is flickering, stands for motor is in rotation.</p> <p>2. Lose keys of <b>FWD</b>  or <b>REV</b> , motor will decelerate till stop. Indicator of <b>FWD</b>  or <b>REV</b>  will go off after stopping voltage output from inverter.</p> <p>(Note) In the JOG Mode, if the rated frequency is the value of Pr15, acceleration/deceleration time will be the value in Pr16. Please refer to Chapter 3 Pr15 and Pr16. (page 51)</p> |

### 2-3-10 External JOG Mode, Operation Procedures


(Pr79=2 or 3 or 5, multi-functional input terminal is set as JOG function)

| Procedures | Description  |
|------------|--|
| 1          | When the operation of motor is stopped, chose one or more multi-function input terminals and set as JOG.(Refer to page 52, Pr59)   |
| 2          | Turn on the input terminal, which named of JOG.  |
| 3          | <p>1. When STF terminal or terminal is in “Turn on”, motor starts to operate. This moment, indicator light <b>FWD</b>  or <b>REV</b>  would be glittered which means motor is on operation.</p> <p>2. After turn off STF and STR, motor would decelerate until stop. The indicator <b>FWD</b>  or <b>REV</b>  of transformer would be turn off, after stop inputting voltage.</p> <p>(Note) In the mode of JOG, rated frequency is Pr15, acceleration time is Pr16 value.(page 51)</p> |

## 2-4 Operation mode of control panel

You may use operation panel to survey output frequency, output current, output voltage, and alarm message, parameter setting, operation frequency setting etc. Therefore, there are three operation modes for operation panel, Surveillance mode (surveillance figure), parameter setting mode (parameter setting), frequency setting mode (operation frequency setting).

### 2-4-1 Operation mode switching procedure drawing




|                   | Frequency setting mode | Parameter setting mode | Surveillance mode |
|-------------------|------------------------|------------------------|-------------------|
| PU Mode           | Y                      | Y                      | Y                 |
| External mode     | Y                      | Y                      | Y                 |
| JOG mode          | N                      | Y                      | Y                 |
| Combined mode 1、3 | Y                      | Y                      | Y                 |
| Combined mode 2   | N                      | Y                      | Y                 |
| Combined mode 4   | N                      | Y                      | Y                 |
| Combined mode 5   | N                      | Y                      | Y                 |
| Combined mode 6   | N                      | Y                      | Y                 |

Note1: In the mode of external, combined mode 2 or JOG mode, the operation panel only can switch between parameter setting mode and surveillance mode.

Note2: Inverter in the external mode and the operation device in the frequency setting mode, the frequency set by an external terminal ,can not be set by the operation device, operation device only can display setting frequency (with Pr64 function used)

## 2-4-2 Operation mode switching procedure drawing




(Note1)

1. 「Surveillance output frequency」, indicator **MON** and **Hz** will be lit, the monitor will show the output frequency.
2. 「Surveillance output current」, indicator **MON** and **A** will be lit, the monitor will show the output current.
3. 「Surveillance output voltage」, indicator **MON** and **V** will be lit, the monitor will show the output voltage.
4. 「Browsing alarm record」, indicator **MON** will be lit, the monitor will show the alarm code record. Maximum record set is 4


(Note 2) Alarm code, Refer to appendix 3.(page 118)

### 2-4-3 Frequency setting mode operation procedure drawing (▲ ▼ Button to rated frequency)



(Note) Under the frequency setting mode, indicator **Hz** will lit, indicator **MON** will not lit.


### 2-4-4 Frequency setting mode and operation procedure drawing (Pressing ,mode to enter frequency setting mode)




(Note 1) Under parameter setting mode, indicator **Hz** will lit, indicator **MON** will not lit.

(Note 2) If after setting frequency without pressing SET button for 1 second, operation panel will remain in the frequency setting mode, until pressing MODE button ,it will go back to parameter setting mode and surveillance mode.

## 2-4-5 Parameter setting mode operation procedure drawing



(Note1) Under parameter setting mode, indicator Hz and MON will not be lit.

(Note2) Parameter is set as 99999 and the actual counterpart of CPU value is 65535, therefore if setting the value below 99999, CPU value will drop from 65535 gradually, if so, the operation panel should show as 65534、65533.....。

(Note3) As setting the parameter, button ▼ ▲ is used to select above or below option,  
When the parameter reaches 99999(0), the panel will stop at this figure, if there is a  
need to surpass this value, the user must press ▼ ▲ button, and parameter value will  
go back to 0 or drop to 99999 gradually.

(Note4) When parameter setting is 9999, for SH-PU series operation panel, they will show “9999”, For DU series operation panel, it will show “99999”.

## Chapter 3 Parameter

### 3-1 Parameter information

| Function           | Pr Number | Name   | Setting Range | Min Setting unit | Initial Value        | User Setting | Refer to page |
|--------------------|-----------|--|---------------|------------------|----------------------|--------------|---------------|
| Basic function     | Pr0       | Manual Torque Boost                            | 0~30%         | 0.1%             | 6% ( Note7)          |              | 45            |
|                    | Pr1       | Maximum frequency                              | 0~120Hz       | 0.01Hz           | 120Hz                |              | 46            |
|                    | Pr2       | Minimum frequency                              | 0~120Hz       | 0.01Hz           | 0Hz                  |              | 46            |
|                    | Pr3       | Base Frequency                                 | 0~400Hz       | 0.01Hz           | 60Hz                 |              | 45            |
|                    | Pr4       | 1(High Speed )                                 | 0~400Hz       | 0.01Hz           | 60Hz                 |              | 46            |
|                    | Pr5       | 2(middle speed)                                | 0~400Hz       | 0.01Hz           | 30Hz                 |              | 46            |
|                    | Pr6       | 3(low speed)                                   | 0~400Hz       | 0.01Hz           | 10Hz                 |              | 46            |
|                    | Pr7       | Acceleration Time                              | 0~3600sec     | 0.1s             | 5sec (Note1)         |              | 48            |
|                    | Pr8       | Deceleration Time                              | 0~3600sec     | 0.1s             | 5sec (Note1)         |              | 48            |
|                    | Pr9       | Electronic thermal O/L replay                  | 0~300A        | 0.01A            | Rated Output current |              | 50            |
| DC injection brake | Pr10      | DC injection brake operation frequency         | 0~120Hz       | 0.01Hz           | 3Hz                  |              | 50            |
|                    | Pr11      | DC injection brake operation time              | 0~10sec       | 0.1s             | 0.5sec               |              | 50            |
|                    | Pr12      | DC injection brake operation ability           | 0~30%         | 0.1%             | 6%(Note8)            |              | 50            |
| Deceleration       | Pr13      | Starting Frequency                             | 0~60Hz        | 0.01Hz           | 0.5Hz                |              | 51            |
| ---                | Pr14      | Load Pattern selection                         | 0~3           | 1                | 0                    |              | 45            |
| JOG rotation       | Pr15      | JOG frequency                                  | 0~400Hz       | 0.01Hz           | 5Hz                  |              | 51            |
|                    | Pr16      | JOG Acceleration/ Deceleration time            | 0~3600 sec    | 0.1s             | (Note 2)             |              | 51            |
| Basic function     | Pr17      | External electronic thermal replay selection   | 0~2           | 1                | 0                    |              | 52            |
|                    | Pr18      | High speed maximum frequency                   | 120~400Hz     | 0.01Hz           | 120Hz                |              | 46            |
|                    | Pr19      | Base frequency voltage                         | 0~1000V、9999  | 0.1V             | 9999                 |              | 45            |
| Acceleration       | Pr20      | Acceleration/ Deceleration reference frequency | 1~400Hz       | 0.01Hz           | 60Hz                 |              | 48            |



| Function                   | Pr Number | Name   | Setting Range  | Min Setting unit | Initial Value | User Setting | Refer to page |
|----------------------------|-----------|--|----------------|------------------|---------------|--------------|---------------|
| Preventing lost speed      | Pr21      | Stall deceleration time during running                               | 0~3600sec      | 0.1sec           | 2sec          |              | 54            |
|                            | Pr22      | Stall prevention operation level                                     | 0~200%         | 0.1%             | 185%          |              | 54            |
|                            | Pr23      | Stall prevention operation level compensation factor at double speed | 0~200%         | 0.1%             | 200%          |              | 54            |
| Multi-speed setting        | Pr24      | 4th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          |              | 46            |
|                            | Pr25      | 5th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          |              | 46            |
|                            | Pr26      | 6th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          |              | 46            |
|                            | Pr27      | 7th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          |              | 46            |
| ---                        | Pr28      | Limitation for alarm reset times                                     | 0、1~10         | 1                | 3             |              | 55            |
| AC/<br>Deceleration        | Pr29      | Acceleration/<br>Deceleration curve pattern selection                | 0、1、2          | 1                | 0             |              | 48            |
| Regenerative brake         | Pr30      | Regenerative brake function selection                                | 0、1            | 1                | 0             |              | 56            |
| Shihlin<br>Communication   | Pr32      | Communication speed (baud rate)                                      | 0、1、2 (Note 3) | 1                | 1             |              | 56            |
|                            | Pr36      | Station number   | 0~31           | 1                | 0             |              | 56            |
| ---                        | Pr37      | Speed Display  | 0、1~9998       | 1                | 0             |              | 58            |
| ---                        | Pr38      | Frequency/5V(10V)  | 1~400Hz        | 0.01Hz           | 60Hz          |              | 59            |
| ---                        | Pr39      | Frequency /20mA  | 1~400Hz        | 0.01Hz           | 60Hz          |              | 59            |
| ---                        | Pr40      | Multifunction terminal selection                                     | 0~6666         | 1                | 5102          |              | 60            |
| Output frequency detection | Pr41      | Output frequency detection   | 0~100%         | 0.1%             | 10%           |              | 61            |
|                            | Pr42      | Output frequency detection for forward rotation                      | 0~400Hz        | 0.01Hz           | 6Hz           |              | 61            |
| Output frequency detection | Pr43      | Output frequency detection for reverse rotation                      | 0~400Hz、9999   | 0.01Hz           | 9999          |              | 61            |

| Function              | Pr Number | Name                              | Setting Range    | Min Setting unit | Initial Value        | User Setting | Refer to page |
|-----------------------|-----------|-----------------------------------|------------------|------------------|----------------------|--------------|---------------|
| Second function       | Pr44      | 2nd acceleration time             | 0~3600sec、9999   | 0.1s             | 9999                 |              | 62            |
|                       | Pr45      | 2nd deceleration time             | 0~3600sec、9999   | 0.1s             | 9999                 |              | 62            |
|                       | Pr46      | 2nd torque boost                  | 0~30%、9999       | 0.1%             | 9999                 |              | 62            |
|                       | Pr47      | 2nd base frequency                | 0~400Hz、9999     | 0.01Hz           | 9999                 |              | 62            |
| Shihlin Communication | Pr48      | Data length                       | 0、1              | 1                | 0                    |              | 56            |
|                       | Pr49      | Stop bit length                   | 0、1              | 1                | 0                    |              | 56            |
|                       | Pr50      | Parity check presence/absence     | 0、1、2            | 1                | 2                    |              | 56            |
|                       | Pr51      | CR、LF presence/absence            | 1、2              | 1                | 1                    |              | 56            |
|                       | Pr52      | Number of communication retries   | 0~10             | 1                | 0                    |              | 56            |
|                       | Pr53      | Communication check time interval | 0、0.1~999.8、9999 | 0.1s             | 9999                 |              | 56            |
| Surveillance function | Pr54      | FM/AM function selection          | 0~6              | 1                | 1                    |              | 63            |
|                       | Pr55      | Frequency Monitoring reference    | 0~400Hz          | 0.01Hz           | 60Hz                 |              | 63            |
|                       | Pr56      | Current monitoring reference      | 0~500A           | 0.01A            | Rated Output Current |              | 63            |
| Reboot                | Pr57      | Restart coasting time             | 0~5sec、9999      | 0.1s             | 9999                 |              | 65            |
|                       | Pr58      | Restart cushion time              | 0~60sec          | 0.1s             | 0.5sec               |              | 65            |
| ---                   | Pr59      | Multifunction terminals selection | 0~9999           | 1                | 9999                 |              | 52            |
| Wave filter Figure    | Pr60      | Input filter time constant        | 1~16             | 1                | 1                    |              | 65            |
| Tone change           | Pr61      | Key Tone Selection                | 0、1              | 1                | 0                    |              | 65            |
| Output frequency test | Pr62      | Zero current detection level      | 0~200%、9999      | 0.1%             | 5%                   |              | 61            |
|                       | Pr63      | Zero current detection time       | 0.05~1sec、9999   | 0.01s            | 0.5sec               |              | 61            |

| Function           | Pr Number | Name  | Setting Range | Min Setting unit | Initial Value | User Setting | Refer to page |
|--------------------|-----------|---|---------------|------------------|---------------|--------------|---------------|
| ---                | Pr64      | Remote function selection                               | 0、1、2、3       | 1                | 0             |              | 66            |
| Function recovery  | Pr65      | Retry Selection   | 0、1、2、3       | 1                | 0             |              | 67            |
| Stall prevention   | Pr66      | Stall prevention operation reduction starting frequency | 0~400Hz       | 0.01Hz           | 60Hz          |              | 54            |
| Function recovery  | Pr67      | Number of retries at alarm occurrence                   | 0、1~10、11~20  | 1                | 0             |              | 67            |
|                    | Pr68      | Retry waiting time                                      | 0~360sec      | 0.1s             | 1sec          |              | 67            |
|                    | Pr69      | Retry count display erase                               | 0             | 1                | 0             |              | 67            |
| Regenerative brake | Pr70      | Special regenerative brake duty                         | 0~30%         | 0.1%             | 0%            |              | 56            |
| ---                | Pr71      | Brake method selection                                  | 0、1           | 1                | 1             |              | 69            |
| ---                | Pr72      | Load Frequency  | 0.7~15kHz     | 0.1KHz           | 5kHz          |              | 69            |
| ---                | Pr73      | Voltage Signal Selection                                | 0、1           | 1                | 0             |              | 59            |
| ---                | Pr74      | Starting terminal function selection                    | 0、1           | 1                | 0             |              | 69            |
| ---                | Pr75      | Reset   | 0~7           | 1                | 4             |              | 70            |
| ---                | Pr77      | Parameter writing prevention selection                  | 0、1、2         | 1                | 0             |              | 71            |
| ---                | Pr78      | Prevention forward/reverse rotation selection           | 0、1、2         | 1                | 0             |              | 71            |
| ---                | Pr79      | Operation Mode selection                                | 0~8           | 1                | 0             |              | 71            |
| ---                | Pr80      | FM/AM output terminal selection                         | 0、1           | 1                | 0             |              | 63            |
| ---                | Pr81      | AM Signal output magnification                          | 0~20          | 0.01             | 1             |              | 63            |
| ---                | Pr82      | Set frequency gain                                      | 0、1~100%      | 1                | 0             |              | 72            |
| ---                | Pr84      | FU/10 times output terminals selection                  | 0、1~10        | 1                | 0             |              | 75            |
| ---                | Pr88      | Auto voltage Boost selection                            | 0、1           | 1                | 0             |              | 76            |
| ---                | Pr89      | Slip Compensation                                       | 0~3%          | 0.1%             | 0%            |              | 76            |
| ---                | Pr90      | Grounding Leakage Selection                             | 0、1           | 1                | 1             |              | 76            |

| Function            | Pr Number | Name                                   | Setting Range | Min Setting unit | Initial Value      | User Setting | Refer to page |
|---------------------|-----------|--|---------------|------------------|--------------------|--------------|---------------|
| Avoid frequency     | Pr91      | Frequency Jump 1A                      | 0~400Hz、9999  | 0.01Hz           | 9999               |              | 76            |
|                     | Pr92      | Frequency Jump 1B                      | 0~400Hz、9999  | 0.01Hz           | 9999               |              | 76            |
|                     | Pr93      | Frequency Jump 2A                      | 0~400Hz、9999  | 0.01Hz           | 9999               |              | 76            |
|                     | Pr94      | Frequency Jump 2B                      | 0~400Hz、9999  | 0.01Hz           | 9999               |              | 76            |
|                     | Pr95      | Frequency Jump 3A                      | 0~400Hz、9999  | 0.01Hz           | 9999               |              | 76            |
|                     | Pr96      | Frequency Jump 3B                      | 0~400Hz、9999  | 0.01Hz           | 9999               |              | 76            |
| ---                 | Pr99      | Motor operation mode selection         | 0~4           | 1                | 0                  |              | 77            |
| Motor constants     | Pr100     | Motor capacity                         | 0~30KW        | 0.01             | Depend on Capacity |              | 78            |
|                     | Pr101     | Motor Pole number                      | 2~12          | 1                | 4                  |              | 78            |
|                     | Pr102     | Rated Motor Voltage                    | 0~1000V       | 1V               | 220/440 V          |              | 78            |
|                     | Pr103     | Rated Motor frequency                  | 0~ 400 Hz     | 0.01 Hz          | 60 Hz              |              | 78            |
|                     | Pr105     | Motor excitation current               | 0~150 A       | 0.01 A           | Depend on Capacity |              | 78            |
|                     | Pr106     | Motor constant R1                      | 0.01~60Ω      | 0.01Ω            | Depend on Capacity |              | 78            |
|                     | Pr107     | Motor constant R2                      | 0.01~60Ω      | 0.01Ω            | Depend on Capacity |              | 78            |
|                     | Pr108     | Motor constant L1                      | 0.1~1500mH    | 0.1 mH           | Depend on Capacity |              | 78            |
|                     | Pr109     | Motor constant L2                      | 0.1~1500mH    | 0.1 mH           | Depend on Capacity |              | 78            |
|                     | Pr110     | Motor constant Lm                      | 0.1~1500mH    | 0.1 mH           | Depend on Capacity |              | 78            |
| Protective function | Pr113     | Overvoltage stall protection selection | 0、1           | 1                | 0                  |              | 79            |
|                     | Pr114     | Overvoltage stall protection voltage   | 110~140%      | 0.1%             | 120%               |              | 79            |
| Torque control      | Pr115     | Torque command source selection        | 0~2           | 1                | 0                  |              | 80            |
|                     | Pr116     | Speed limit selection                  | 0~4           | 1                | 0                  |              | 80            |
|                     | Pr117     | Torque command value                   | 0~100%        | 0.1%             | 50%                |              | 80            |
|                     | Pr118     | Forward rotation speed limit           | 0~120Hz       | 0.01Hz           | 60Hz               |              | 80            |

| Function             | Pr Number | Name   | Setting Range | Min Setting unit | Initial Value | User Setting | Refer to page |
|----------------------|-----------|--|---------------|------------------|---------------|--------------|---------------|
|                      | Pr119     | Reverse rotation speed limit                   | 0~120Hz       | 0.01Hz           | 60Hz          |              | 80            |
|                      | Pr120     | Torque command gain                            | 0~180%        | 0.1%             | 100%          |              | 80            |
| ---                  | Pr125     | Digital Unit key tone selection                | 0、1           | 1                | 1             |              | 81            |
| Multi-speed setting  | Pr126     | 8th Speed                                      | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr127     | 9th Speed                                      | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr128     | 10th Speed                                     | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr129     | 11th Speed                                     | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr130     | 12th Speed                                     | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr131     | 13th Speed                                     | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr132     | 14th Speed                                     | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
|                      | Pr133     | 15th Speed                                     | 0~400Hz、9999  | 0.01Hz           | 9999          |              | 46            |
| PID performance      | Pr160     | PID operation selection                        | 0、1~8         | 1                | 0             |              | 81            |
|                      | Pr161     | PID ratio increase                             | 0、0.1~600%    | 0.1%             | 90%           |              | 81            |
|                      | Pr162     | PID integral increase                          | 0、0.1~600%    | 0.1%             | 10%           |              | 81            |
|                      | Pr163     | PID differential increase                      | 0、0.1~600%    | 0.1%             | 0%            |              | 81            |
|                      | Pr164     | PID digital target value                       | 0~100%        | 0.1%             | 0%            |              | 81            |
|                      | Pr165     | PID Output order limit                         | 0~100%        | 0.1%             | 50%           |              | 81            |
|                      | Pr166     | PID Alert value limit                          | 0、0.1~100%    | 0.1%             | 0%            |              | 81            |
|                      | Pr167     | PID Alarm detection time                       | 0、0.1~3600s   | 0.1s             | 0s            |              | 81            |
|                      | Pr168     | PID Alarm solution                             | 0~2           | 1                | 0             |              | 81            |
| MODBUS Communication | Pr170     | Communication Protocol                         | 0、1           | 1                | 0             |              | 83            |
|                      | Pr171     | Communication Address                          | 1~247         | 1                | 1             |              | 83            |
|                      | Pr172     | MODBUS Transmission Speed of the Communication | 0、1、2         | 1                | 1             |              | 83            |
|                      | Pr173     | MODBUS Data Format                             | 0~5           | 1                | 0             |              | 83            |
| Vector Control       | Pr180     | Proportional Gain of Speed Controller          | 0~100%        | 1%               | 50%           |              | 94            |
|                      | Pr181     | Integral Gain of Speed Controller              | 0~100%        | 1%               | 50%           |              | 94            |
|                      | Pr182     | Slip Compensation                              | 0~50%         | 0.1%             | 35%           |              | 95            |
|                      | Pr183     | Speed Compensation Coefficient                 | 0~100%        | 0.1%             | 50%           |              | 95            |

| Function              | Pr Number | Name                                       | Setting Range |         | Min Setting unit | Initial Value |      | User Setting | Refer to page |
|-----------------------|-----------|--|---------------|---------|------------------|---------------|------|--------------|---------------|
| Vector Control        | Pr184     | Low Speed Excited Rate                     | 0~100%        |         | 0.1%             | 50%           |      |              | 96            |
|                       | Pr185     | High Speed Excited Rate                    | 0~100%        |         | 0.1%             | 100%          |      |              | 96            |
|                       | Pr186     | High Speed Excited Curve                   | 0、1、2         |         | 1                | 1             |      |              | 96            |
|                       | Pr187     | Bandwidth of Speed Controller              | 20~120        |         | 1                | 60            |      |              | 94            |
| ---                   | Pr189     | 50Hz/60Hz system switchover                | 0、1           |         | 1                | 0             |      |              | 97            |
| ---                   | Pr191     | AM terminal output revision                | 0~50          |         | 1                | 25            |      |              | 63            |
| Calibration functions | Pr192     | FM Terminal calibration                    | 0~9998        |         | 1                | 166           |      |              | 63            |
|                       | Pr194     | Voltage setting Bias                       | 0~10V         | 0~60Hz  | 0.01Hz           | 0V            | 0Hz  |              | 97            |
|                       | Pr195     | Voltage setting Gain                       | 0~10V         | 1~400Hz | 0.01Hz           | 5V            | 60Hz |              | 97            |
|                       | Pr196     | Current setting Bias                       | 0~20mA        | 0~60Hz  | 0.01Hz           | 4mA           | 0Hz  |              | 98            |
|                       | Pr197     | Current setting Gain                       | 0~20mA        | 1~400Hz | 0.01Hz           | 20mA          | 60Hz |              | 98            |
| ---                   | Pr199     | Software version                           | Viewing only  |         | —                | (Note 6)      |      |              | 98            |
| Parameter copy        | Pr994     | Parameter copy/read                        | —             |         | —                | (Note 4)      |      |              | 98            |
|                       | Pr995     | Parameter copy/write                       | —             |         | —                | (Note 4)      |      |              | 98            |
| Alert record clear    | Pr996     | Alarm history clear                        | —             |         | —                | —             |      |              | 99            |
| Parameter reset       | Pr997     | Reset                                      | —             |         | —                | —             |      |              | 99            |
| Parameter recovery    | Pr998     | All parameter recover to initial value     | —             |         | —                | —             |      |              | 99            |
|                       | Pr999     | Partial parameter recover to initial value | —             |         | —                | —             |      |              | 99            |

(Note1) Factory default value of Parameter Pr7、Pr8: 0.75K~7.5K (1HP~10HP) product series is 5sec , 11K~15K (15HP~20HP) product series is 10sec, 18.5K~22K (25HP~30HP) product series is 15sec.

(Note2) Factory default value of Parameter Pr16: 0.75K~3.7K (1HP~5HP) product series is 0.5sec , 5.5K~15K (7.5HP~20HP) product series is 1sec. 18.5K~22K (25HP~30HP) product Series is 1.5sec.

(Note3) When Pr32=0, the Baud Rate is 4800bps; when Pr32=1, the Baud Rate is 9600bps; when Pr32=2, the Baud Rate is 19200bps.

(Note 4) The function related to parameter copy in Pr994 and Pr995 is only available in Digital Unit of SH-PU.

(Note 5) When parameter value is 9999, the operation panel of SH-PU series shows as “9999”, but for DU series shows as “99999”.

(Note 6) For massive quantity manufacture versions are all standardized, parameter functions all apply to market demand. For the reason of special demand, other exclusive version will be made.

(Note7) Factory default value of Parameter Pr0: 0.75K(1HP) product series is 6%, 1.5K~3.7K (2HP~5HP) product series is 4%, 5.5K~7.5K (7.5HP~10HP) product series is 3%, 11K~22K (15HP~30HP) product series is 2%.

(Note8) Factory default value of Parameter Pr12: 0.75K~3.7K (1HP~5HP) product series is 6%, 5.5K~7.5K (7.5HP~10HP) product series is 4%, 11K~22K (15HP~30HP) product series is 2%.

## 3-2 Parameter function information





### Pr0 Manual Torque Boost

### Pr3 Base Frequency

### Pr14 Load Pattern Selection

### Pr19 Base Voltage

1. The maximum output voltage of inverter is Base Voltage which is determined by Pr19.
2. With V/F control, output voltage and output frequency is corresponding with each other positively, when the value of output frequency is lower than the value of base frequency (Pr3). Output voltage is also reaching base voltage when output frequency is reaching value of Pr3. If the output frequency exceeds the base frequency and increase continuously, the output voltage will be fixed to the base voltage. Please refer to the following figures for the V/F curves (output voltage vs. output frequency).
3. With V/F control, when in low frequency operation, but output frequency is 0, the Pr0 setting will be invalid due to under load of output voltage that caused low motor torque. Consider to adjust value of torque boost (Pr0) to increase the starting output voltage to obtain better motor torque.

| Parameter Number | Pr14  |   |  |   |
|------------------|---|---|--|---|
| Setting          | 0   | 1   | 2  | 3   |
| V/F Pattern      |  |  |  |  |
| Description      | 1. Constant-torque load.<br>2. Application for cart, Conveyor, etc.                 | 1. Variable-torque load.<br>2. Application for fan, pump, etc.                      | Vertical lift loads.   | Vertical lift loads.  |

(Note)

1. If set value of Pr0 is too high, it will caused over current when start the inverter, therefore inverter can not be started.
2. When Pr19=9999, the maximum output voltage of inverter is decided by the voltage of power supply.
3. When Pr99=3, Sensor-less vector control, the parameter setting value of Pr0 is invalid.

## Pr1 Maximum Frequency

## Pr2 Minimum Frequency

## Pr18 High Speed Maximum Frequency

Maximum frequency is the highest frequency that inverter can run.

Minimum frequency is the lowest frequency that inverter can run.

Setting range of running frequency:

$Pr2 \leq \text{running frequency} \leq Pr1 (Pr18)$ .


1 “Maximum Frequency” and “High Speed Maximum Frequency” is corresponding with each other. When Pr1 is set, at the same time Pr18 is set. Vice Versa, when Pr18 is set, Pr1 is also set. Therefore Pr1 is equal to Pr18 forever.

2. When the maximum frequency is in the range of 0 to 120 Hz, Pr1 must be used.

When maximum is in the range of 120 to 400 Hz, Pr18 must be used.

3. The running frequency write in will not allow when: (1) Running Frequency < Pr2,

(2) Running Frequency > Pr1, or (3) Pr1 < Pr2.



## Pr4 to Pr6 , Pr24 to Pr27, Pr126 to Pr133 Multi-speed

When inverter is in **External Mode** or **Combined Mode 2**, the running frequency can be set by the combination of input terminal. This function is Multi-speed operation.


| Parameter Number | Description  |
|------------------|--|
| Pr4 to Pr6       | Pr4→speed 1(high speed), Pr5→speed 2 (middle speed), Pr6→speed 3 (low speed).      |
| Pr24 to Pr27     | Speed 4 to speed 7. When the value is 9999(default), speed setting is unavailable. |
| Pr126 to Pr133   | Speed 8 to 15. When the value is 9999(default), speed setting is unavailable.      |

(Note)

1. When the initial value of Pr24 to Pr27 and Pr126 to Pr133 is 9999, it stands for 3 multi-speed operations. No matter what kind of combination among RL、RM、RH、REX, maximum multi-speed is 3. Please refer to following :
  - 1) When RL is ON, the initial value of Pr6 is frequency set.
  - 2) When RM is ON, the initial value of Pr5 is frequency set.
  - 3) When RH is ON, the initial value of Pr4 is frequency set.
  - 4) When RL and RM are both ON, the initial value of Pr6 is frequency set (low speed prioritized).



- 5) When RL and RH are both ON, the initial value of Pr6 is frequency set (low speed prioritized).
  - 6) When RM and RH are both ON, the initial value of Pr5 is frequency set (middle speed prioritized).
  - 7) When RL, RM, and RH are both ON, the initial value of Pr6 is frequency set (low speed prioritized).
2. When the initial value of Pr24 to Pr27 and Pr126 to Pr133 is not 9999, it stands for multi-speed operation. There are 16 speed combinations of RL、RM、RH、REX and voltage, current.



3. When the partial value setting of Pr24 to Pr27 and Pr126 to Pr133 is 9999, for example if Pr27=9999(speed 7), then speed 7 is unavailable. Therefore, when feeding signal into RH, RM, RL, inverter is switchover to speed 3 and the value of Pr6 is setting frequency.
4. The terminals of RL、RM、RH、REX mentioned in this chapter, please refer to Pr59 for function selection.(Page 52)

## Pr7 Acceleration Time

## Pr8 Deceleration Time

## Pr20 Acceleration/Deceleration Reference Frequencies

## Pr29 Acceleration/Deceleration Curve Pattern Selection

### When Pr29=0: Linear Acceleration/Deceleration Pattern

The time for output frequency to accelerate from 0Hz to Pr20 is Acceleration Time (Pr7).


The time for output frequency to decelerate from Pr20 to 0Hz is Deceleration Time (Pr8).

The meantime to start motor is Starting Frequency.

Pr7、Pr20 are collocated and formed a acceleration slope. Pr8 and Pr20 are collated and formed a deceleration slope.

The output frequency is making linear increased based on acceleration slope during acceleration.

The output frequency is making linear decreased based on deceleration slope during deceleration.



(Note1) On above diagram it displayed the detail information of Linear Acceleration/Deceleration Pattern. It includes Acceleration Slope, Deceleration Slope, Starting Frequency (Pr13), DC Injection Brake (Pr10), etc. All these parameters should be considered to use together when it comes to perform parameter setting for inverter.

(Note 2) Please refer to Pr10 for DC Injection Brake.


(Note 3) If the operation frequency of inverter is lower than initial value of Pr13, after motor start. The indicator of “FWD” or “REV” is flickering. But there is no voltage output and motor is not in operation.

### When Pr29=1: S-Pattern Acceleration/Deceleration Curve

The special feature of this pattern is to accelerate from slow to high Speed, and is ramping up to high speed zone in a short period of time.

(Note 1)

Though in right-side diagram, there is no information about starting frequency (Pr13), and DC Injection Brake (Pr10), but in operation they are still valid for operation.



### When Pr29=2: S-Pattern Acceleration/Deceleration Curve

Pr7 and Pr20 are collocated and making a acceleration slope.


Pr8 and Pr20 are collocated and making a deceleration slope.

Whenever there is a change in rated frequency, acceleration curve is attached with acceleration slope to make S Pattern Ramp up. On the contrary, deceleration curve is attached with deceleration slope to make a S pattern ramp down.

As right sided diagram, rated frequency adjustment is from  $f_0$  to  $f_1$ , one S shifting is made on S Acceleration Pattern. Again rated frequency adjustment from  $f_1$  to  $f_2$ , again one S shifting is made.

(Note 1) This pattern is able to smooth the impact that generated by the phase of deceleration. It will prevent product dropping from conveyor.

(Note 2) Though Starting Frequency Pr13 and DC injection brake frequency Pr10 is not mentioned on right-sides diagram, but they are still functional during operation.



## Pr9 Electronic thermal relay volume


1. “Electronic Thermal Relay” is to use inverter program to simulate if motor is overload (overheat) and to prevent motor from overheat.
2. If “mouse cage” mode sensor motor is used, the set value of Pr9 is as rated current when motor is operation at 60Hz.
3. When Pr9=0, the function of Electronic Thermal Relay is invalid.
4. When TH-RY calculates that there are too much heat accumulated during motor operation, inverter generates ALARM (indicator of ALARM is lit), inverter stop output and **Err** display on screen of Digital Unit.
5. After inverter reset for restart, the history of accumulated heat reading from TH-RY will be erased and reset it to “zero”. Please do take extra attention on this.
6. If multiple Motors are wired to inverter, TH-RY can not be used as overheat protection for motor. Please mount an external TH-RY for individual motor.
7. When a special motor is in use, do not use built-in TH-RY, please install external TH-RY. The operation and wiring method for external TH-RY, please refer to Pr59.(page 52)

## Pr10 DC injection brake operation frequency

## Pr11 DC injection brake operation time


## Pr12 DC injection brake ability

1. When stop signal turns on, the output frequency of inverter is dropping gradually. When output frequency is lowered than DC injection brake frequency (Pr10), DC injection brake will active.
2. When DC injection brake is in operation, inverter will output DC voltage to lock the rotor. The larger value of Pr12 is, more the braking power is.
3. The operation of DC injection brake will last a short period of time (Pr11 setting value) to smooth away physics inertia of Motor rotation operation. User must set appreciate value setting for Pr11 & Pr12 in order to achieve proper holding torque attained.



### Pr13 Starting Frequency

1. You can set the starting frequency at which the start signal is turned on.
2. Frequency at start can be set in the range 0 to 60Hz.




(note1)The inverter will not start if the frequency setting signal is less than the value set in Pr. 13.

For example, when 5Hz is set in Pr. 13, the motor will not start running until the frequency setting signal reaches 5Hz.

### Pr15 JOG frequency

#### Pr16 JOG Acceleration/Deceleration time

In JOG Mode, the rated frequency is the set value of Pr15. The initial value of Pr16 is Acceleration/Deceleration Time. And Pr20 is Acceleration/Deceleration reference frequency




## Pr17 External Thermal relay selection


### Pr59 Multifunction input terminal function selection

In order to prevent motor overheat, motor wiring is added Thermal Relay. External Thermal Relay function selection must refer to Pr59 parameter, for instance Pr59=3459(5.5K~22K for example), means 「terminal name RL correspond to RL function」, 「terminal name RM correspond to OH function」, 「terminal name RH correspond to STOP function」, 「terminal name RT correspond to REX function」.

Medium capacity inverter series of 5.5K to 22K (7.5HP to 30HP), there are 4 digits in Pr59, individual digit is stand for different function setup. Relevant positions as following :



Small capacity inverter series of 0.75K to 3.7K (1HP to 5HP), there are 4 digits in Pr59, individual digit is Stand for different function setup. Relevant positions as following :




| Parameter | Setting value | Function name | Description  |                         |
|-----------|---------------|---------------|--|-------------------------|
| P59       | 0             | AU            | When in External Mode or Combined Mode 2, and AU is ON, the rated frequency is assigned by current signal. | Refer to Pr39 (page 59) |
|           | 1             | RH            | Multi-speed control( high speed)   | Refer to Pr4 (page 46)  |
|           | 2             | RM            | Multi-speed control( medium speed)   |                         |
|           | 3             | RL            | Multi-speed control (low speed)  |                         |
|           | 4             | OH            | External Thermal Relay(External TH-RY)   | Refer to Note 1,4       |
|           | 5             | STOP          | Self-Holding Function  | Refer to Note 2         |
|           | 6             | MRS           | Turn on MRS more than 20ms to stop the inverter output.  | ---                     |

|  |   |     |  |                               |
|--|---|-----|--|-------------------------------|
|  | 7 | RT  | When RT is on to select 2 <sup>nd</sup> functions. | Refer to Pr44 (page 62)       |
|  | 8 | JOG | Jog operate  | Refer to Pr15, Pr16 (page 51) |
|  | 9 | REX | Multi-speed control                                | Refer to Pr4 (page 46)        |

(Note 1) The wiring for External TH-RY:

The traditional motor wiring in the usual Condition , it is to mount a Thermal Relay during wiring to avoid motor rotates under overheat condition. When Shilin Inverter is in use, feature of an external Thermal Relay function is also provided (Illustrated only by Sink Input). When the External Thermal Relay is overload, Inverter is going to generate Overload Alarm. Monitor screen **OHF** is displayed.



(Note 2) Self-Holding Function Description:

”When in “External Mode” or “Combined Mode 1,3”, STOP terminal is ON, and then Press STF or STR (switch “off” to “on” and then back to “off”) one time. It will keep motor operation, if try to stop Motor Operation, Press STOP to turn off. STOP terminal is off. If you are trying to keep motor in operation, STF and STR terminal must be ON.

(Note 3) Inverter of 5.5K to 22K (7.5HP to 30HP) series:

1. When Pr59=9999 (initial value) 「terminal name RL correspond to RL function」, 「terminal name RM correspond to RM function」, 「terminal name RH correspond to RH function」, 「terminal name RT correspond to RT function」.
2. Inverter of 0.75K to 3.7(1HP to 5HP) series:  
When Pr59=9999 (initial value) and Pr17=0 (initial value), Pr44=9999 (initial value). 「terminal name RL/OH correspond to RL function」, 「terminal name RM/AU correspond to RM function」, 「terminal name RH correspond to RH function」, 「terminal name MRS/RT correspond to MRS function」.
3. When Pr59=9999 (initial value), Pr44=9999 (initial value), then 「terminal name MRS/RT correspond to MRS function」.  
When Pr59=9999 (initial value), Pr44≠9999 (initial value), then 「terminal name MRS/RT correspond to RT function」.

Example:

When Pr59≠9999, Pr59=3459, then 「terminal name RL/OH correspond to RL function」, 「terminal name RM/AU correspond to OH function」, 「terminal name RH correspond to STOP function」, 「terminal name MRS/RT correspond to REX function」.

(Note 4) Parameter of Pr59 and Pr17

| Necessary condition          | Value  | Description   |
|------------------------------|--------|---|
| Pr59=9999<br>(initial value) | Pr17=0 | Terminal RL , Function RL.                          |
|                              | Pr17=1 | Terminal RL , Function OH , NC status input.        |
|                              | Pr17=2 | Terminal RL , Function OH ,NO status input.         |
| Pr59≠9999                    | Pr17=0 | External Thermal relay functions as NC status input |
|                              | Pr17=1 |   |
|                              | Pr17=2 | External Thermal relay functions as NO status input |

## Pr21 Stall deceleration time during running

## Pr22 Stall prevention operation level


## Pr66 Stall prevention level reduction starting frequency

## Pr23 Stall prevention operation level compensation factor at double speed (offset coefficient)

1. When Induction Motor is in reducing load state, its rotation speed is closed to synchronous speed; therefore its rotation torque is small. When the load is increased, rotation speed is dropping but the output rotation torque is higher (The output current from inverter is also making a direct Proportion increased), this is to smooth load. If input load is increased and makes the motor output rotation torque exceed Max. Rotation Torque, instead the increased load lowers motor rotation torque. The phenomenon is STALL.


### 2. Stall Prevention Function:

During acceleration of output frequency, motor rotation speed is slower than output frequency of inverter. In the meantime output current is increased, if output current is higher than pattern shown below. Inverter is automatically varies to reduce the output frequency in order to wait motor rotation speed to keep up with output frequency. (Output current will also slow down), and then to increase output frequency.





The inverter will start decreasing when the current reach the stall prevention level. The decreasing time will depend on Pr21 until the output current is lower than stall prevention level. After that the inverter will restart accelerating to the target frequency by acceleration time pr7.



3. When output frequency is lower than Pr66, Stall presentation Operation level is Pr22.  
 When output frequency is higher than Pr66, Enter stall prevention reduction section.  
 Stall prevention Operation Level is decided as the formula below:

$$\text{Stall presentation operation level} = A + B \times \frac{\text{Pr } 22 - A}{\text{Pr } 22 - B} \times \frac{\text{Pr } 23 - 100}{100}$$

$$A = \frac{\text{Pr } 66 \times \text{Pr } 22}{\text{Output frequency}} \quad B = \frac{\text{Pr } 66 \times \text{Pr } 22}{400}$$

(Note 1) If stall prevention operation is performed a long period of time, the inverter is stopped because of ALARM. Display on Operation Panel show message of **OL**.

(Note 2) When Pr22=0, stall prevention function is invalid.

### Pr28 Alarm reset times limitation

| Parameter value | Setting value | Description   |
|-----------------|---------------|---|
| Pr28            | 0             | Unlimited for reset   |
|                 | 1-10          | After maximally used the reset times, only reboot can make alarm status back to normal. |

## **Pr30 Regenerative function selection**

### **Pr70 Special regenerative brake duty**

1. When the output frequency of inverter has shifted from high frequency to low frequency (during deceleration). Due to inertia load, a momentary motor torque is higher than output frequency of inverter, and caused generator effect, it also creates voltage regenerated between terminals of P-N in main circuit, the regenerative may caused possible damage to inverter. Therefore to install suitable brake resistor between terminals of P & PR. in order to consume regenerated voltage.
2. There is one transistor in inverter (called Brake transistor). Time ratio when transistor is on, called Regenerative Brake Duty). If regenerative brake setting value is higher, brake resistor is consumes more regenerative load, but actual brake resistor watt value must be considered.

| Pr Number | Setting  | Description  |
|-----------|----------|--|
| Pr30      | 0        | Regeneration brake using rate 3%( Initial Value), Pr70 Invalid |
|           | 1        | Regeneration brake using rate is Pr70 setting value            |
| Pr70      | 0 to 30% | Regeneration brake using rate.                                 |

(Note 1)When often make starts/stops, must use the high-power brake resistor to increase the regenerative brake using rate

(Note 2)Please refer to 1-6-4 (page 26) as reference for purchasing brake resistor.



5.5KW/7.5KW built-in brake resistor and it is only good for regeneration function 3% as factory default value. If higher regeneration function is desired, please remove built-in brake resistor and replace with high-power brake resistor.

## **Pr32 Communication speed**

### **Pr36 Station number**

### **Pr48 Data length**

### **Pr49 Stop bit length**

### **Pr50 Parity check presence/absence**

### **Pr51 CR、 LF presence/absence**

### **Pr52 Number of communication retries**


### **Pr53 Communication check time interval**

Through interface RS485, the required parameters that inverter needs to communicate can be obtained. Users can perform parameter setting and monitoring, etc, by using the Shihlin communication software, please refer to communication Protocol in appendix 1.(page102)


| Pr Number | Setting          | Description   |
|-----------|------------------|---|
| Pr32      | 0                | The Baud Rate is 4800 bps   |
|           | 1                | The Baud Rate is 9600 bps   |
|           | 2                | The Baud Rate is 19200 bps  |
| Pr36      | 0 to 31          | When several inverters connect to 1 PC, different station number is required.               |
| Pr48      | 0                | 8 Data bit  |
|           | 1                | 7 Data bit  |
| Pr49      | 0                | 1 Stop bit  |
|           | 1                | 2 Stop bit  |
| Pr50      | 0                | No parity check   |
|           | 1                | Odd parity check  |
|           | 2                | Even parity check   |
| Pr51      | 1                | Available only CR   |
|           | 2                | CR, LF available  |
| Pr52      | 0 to 10          | Allowable Number of Communication ALARM between PC or Control Panel                         |
| Pr53      | 0 、 0.1 to 999.8 | After communication, and move to next communication time interval. Pr53=0, No communication |
|           | 9999             | No Time Interval Setting  |

(Note) Communication connection graph:

For only one inverter connecting to computer



For multi-inverter connecting to computer



## Pr37 Speed Display

| Pr Number   | Setting                                 | Description   |
|-------------|---|---|
| <b>Pr37</b> | 0                                       | Under monitoring output frequency mode in control panel, The display screen is display the value of output frequency of inverter.   |
|             | 1 to 9998<br>(Actual linear speed unit) | <p>DU Operator is in monitoring output frequency mode, the screen show the corresponding mechanical speed when inverter is in operation. The setting value of Pr37 is corresponding mechanical speed when set inverter's output frequency at <b>60Hz</b>.</p> <p>Propose Setting value could be presented as conversion formula</p> $\frac{\text{Pr } 37 \times \text{Pr } 1}{60} \leq 9998$ <p>Example: The rotation speed of conveyor is 950 meter/min when set inverter's output frequency at 60Hz, so set value in Pr37=950. The screen on digital unit is display the speed 950 meter/minute of conveyor belt under monitoring output frequency.</p> |

## Pr38 Rated Frequency at 5V (10V)

### Pr73 Voltage signal selection

When inverter is in External Mode or Combined Mode 2, in Analog input Terminals 2-5, input voltage can be selected and set the rated frequency.


| Pr Number | Setting    | Description  |
|-----------|------------|--|
| Pr73      | 0          | Input voltage valid range 0 to 5V.                               |
|           | 1          | Input voltage valid range 0 to 10V.                              |
| Pr38      | 1 to 400Hz | The value of Pr38 is rated frequency of input voltage as 5V(10V) |

(Note1)

When in External Mode or Combined Mode 2, AU terminal is “On”, and RL、RM、RH、REX are all in” off” status. Rated frequency of vector control is assigned by voltage signal.

(Note 2)

In this paragraph there are RL, RM, RL, RH, REX,AU mentioned as terminal function. The function and its selection, please refer to Pr59(page 52)



## Pr39 Rated frequency at 20mA

When inverter is in External Mode or Combined Mode 2, in Analog input Terminals 4-5, input current can be selected and set the rated frequency.


| Pr Number | Setting    | Description  |
|-----------|------------|--|
| Pr39      | 1 to 400Hz | Pr39 value setting is the rated frequency when current signal is 20mA. |

(Note1)

When in External Mode or Combined Mode 2, AU terminal is “On”, and RL、RM、RH、REX are all in” off” status. Rated frequency of vector control is assigned by current signal.

(Note2)


In this paragraph there are RL, RM, RH, REX, AU mentioned as terminal function. The function and its selection, please refer to Pr59 (page 52)




## Pr40 Multifunction output terminals function selection

Medium capacity product series of 5.5K to 22K (7.5HP to 30HP), Pr40 has 4-digits.

Counterpart details as below :



Small capacity product series of 0.75K to 3.7K (1HP to 5HP), Pr40 has 4-digit and there will be 3 digit set for different function, Counterpart details as below :



| Parameter | Setting value | Function name                          | Description  |
|-----------|---------------|--|--|
| Pr40      | 0             | RUN<br>Motor<br>in operation           | When there is voltage output, set "RUN" as "OUTPUT Terminal". The output signals are given for indicating motor in operation.  |
|           | 1             | SU<br>Frequency<br>detection range     | When output frequency reached closer range to rated frequency (range value is defined by Pr41), Output terminal "SU" will transmit signal.   |
|           | 2             | FU<br>Output<br>frequency<br>detection | When Forward rotation frequency output is higher than Pr42 setting, or reverse rotation frequency output is higher than Pr43, Output terminal "FU" will transmit signal.   |
|           | 3             | OL<br>Overload alert                   | When % of output current is higher than Pr22 setting, Output terminal "OL" will transmit signal.   |
|           | 4             | OMD<br>Zero current<br>detection       | When % of output current is lower than Pr62 setting for a period of time (the length of time is assigned thru Pr63 setting), Output terminal "OMD" will transmit signal.   |
|           | 5             | ABC<br>Alert output                    | Alarm Detection Faction.<br>When operate normally, NO, point A-C, NC , point B-C.<br>When malfunction occurs (Alarm Indicator is lit) NC point A-C, NO, point B-C.   |
|           | 6             | PID<br>PID alert<br>detection          | Under control of PID mode, the inverter got feedback that alarm detective function is operating, and when feedback frequency is more than or equal to rated value (Pr166) and sustain for a while (Pr167), the terminal function name as PID will transmit signal. |

(Note 1) Except ABC relay point, all other input terminals inner structure is Open Collector mode.

(Note 2) When unit's , ten's, hundred's digit of Pr40 is set in "5", when alarm occurs the alarm message will be output from open collector.

**Pr41 Output frequency detection (SU terminal)**


**Pr42 Output frequency detection for forward rotation (FU terminal)**

**Pr43 Output frequency detection for reverse rotation (FU terminal)**

**Pr62 Zero current detection level**

**Pr63 Zero current detection time**

| Parameter | Setting Range | Description   |
|-----------|---------------|---|
| Pr41      | 0 to 100%     |   |
| Pr42      | 0 to 400Hz    |   |
| Pr43      | 0 to 400Hz    |   |
| Pr43      | 0 to 400Hz    | <ol style="list-style-type: none"> <li>1. When Pr41=5%, and Output Frequency is ramping closer to “set frequency” in the range of 5%, SU is set as Output terminal and it will output signal. For example, if rated frequency at 60Hz, Pr41=5%, and output frequency is in the range of <math>60 \pm 60 \times 5\% = 63\text{Hz}</math> and 57Hz, SU terminal is going to output signal.</li> <li>2. If Pr42=30 and Pr43=20, when the output frequency of forward rotation is exceeds 30Hz or output frequency of reverse rotation is exceeds 20Hz, FU terminal is set as output terminal and it will output signal.</li> <li>3. If Pr42=30 and Pr43=9999(factory default initial value), when the output frequency of forward or reverse rotation is exceeds 30Hz, FU terminal is set as output terminal and it will output signal.</li> </ol> |

|      |              |   |
|------|--------------|---|
| Pr62 | 0-200%       |   |
| Pr63 | 0.05-0.1 sec | <p>1. To presume the rated current of inverter is 20A, Pr62=5% and Pr63=0.5sec, when output current is smaller than <math>20 \times 5\% = 1\text{A}</math> and run over 0.5sec. OMD terminal is going to output signal as diagram below:</p> <p>2. When the value of Pr62 or Pr63 is set at 9999, zero current detection function is invalid.</p> |

#### **Pr44 Second acceleration/deceleration time**

#### **Pr45 Second deceleration time**

#### **Pr46 Second torque boost**

#### **Pr47 Second V/F (base frequency)**

1. The terminals RT is on, 2<sup>nd</sup> function is valid. The feature of motor operation, please refer to 2<sup>nd</sup> function. The initial value of Pr44 is acceleration time, The initial value of Pr45 is deceleration Time. The initial value of Pr46 is torque boost and the initial value of Pr47 is base frequency.
2. If Pr44=9999 (initial value), all the 2<sup>nd</sup> function is invalid. Also when RT is on, acceleration time is the initial value of Pr7. Deceleration time is the initial value of Pr8. Initial value of Pr0 is torque boost. The initial value of Pr3 is base frequency.
3. When Pr44≠9999 and Pr45=9999, and when RT is on, deceleration time is as Pr44 initial value.
4. When Pr44≠9999 and Pr46=9999, and RT is on, torque boost is increased as Pr0 initial value.
5. When Pr44≠9999 and Pr47=9999, and RT is on, base frequency is as Pr3 initial value.



**Pr80 FM/AM Output terminal selection (require hardware switch SW1)****Pr54 FM/AM Function selection****Pr55 Frequency display model****Pr56 Current display model****Pr81 AM Signal output magnification****Pr191 AM Output terminal revision****Pr192 FM Output terminal revision**

When Pr80=0, External terminal "FM/AM" is AM, Terminal name FM/AM—5 could output 0~10V voltage, which is used to conduct to PLC A/D model or to provide Inverter 0~10V DC Input.

When Pr80=1, External terminal "FM/AM" is FM, Terminal name FM/AM—SD could be connected a current meter (The whole scale is current meter of 1mA or frequency meter), which can indicate output frequency of or output current of inverter. Functions of FM and AM share the same terminal, if functions change (Value of Pr80 changes) meanwhile, SW1 on the control panel is switching, initial value is AM.

| Parameter   | Value | Description   |
|-------------|-------|---|
| <b>Pr80</b> | 0     | Analog output, FM/AM—5 terminal outputs 0~10V DC voltage.(Note2)          |
|             | 1     | Pulse output, FM/AM—SD terminal outputs pulse of 0~2300Hz.                |
| <b>Pr54</b> | 0     | No output.  |
|             | 1     | Output frequency of inverter (relating to setting of Pr55).               |
|             | 2     | Output current of inverter (relating to setting of Pr56).                 |
|             | 3     | DC voltage of DC Bus (1000V=10V).(Note 2)                                 |
|             | 4     | Heat sink temperature (25°C~100°C =0~10V).(Note 2 、 3)                    |
|             | 5     | 2-5 terminal could be input the switching voltage (0~10V=0~10V).(Note 2)  |
|             | 6     | 4-5 terminal could be input the switching voltage (4~20mA=0~10V).(Note 2) |

(Note) 1. Inverter's AM function of 0.75K~3.7K can only output 0~5V DC voltage.

2. When Pr80=0, functions of Pr54=1~6 are all valid, when Pr80=1, functions of Pr54=3~6 are invalid.

3. 0.75K ~ 3.7K series inverter without the temperature feedback signal, therefore Pr54 = 4 is failure.

| Parameter | Value   | Description  |   |
|-----------|---------|--|---|
| Pr55      | 0~400Hz | Pr80=0<br>Pr54=1   | When the output frequency of inverter is value of Pr55, terminal name FM/AM will output 10V DC voltage. |
|           |         | Pr80=1<br>Pr54=1   | When the output frequency of inverter is value of Pr55, terminal name FM/AM will output 1440Hz pulse.   |
| Pr56      | 0~500A  | Pr80=0<br>Pr54=2   | When the output frequency of inverter is value of Pr56, terminal name FM/AM will output 10V DC voltage. |
|           |         | Pr80=1<br>Pr54=2   | When the output frequency of inverter is value of Pr56, terminal name FM/AM will output 1440Hz pulse.   |
|           |         | <div><div><p>AM</p><p>10V</p><p>DC Voltage</p><p>Pr55 output frequency</p></div><div><p>FM</p><p>2300Hz</p><p>1440Hz</p><p>Pulse Frequency</p><p>Pr55 output frequency</p><p>Pr56 output current</p></div></div> <p>(Note) The max possible output pulse frequency for FM functions is 2300Hz.</p>   |   |
| Pr81      | 0~20    | AM signal output magnification, Unit 0.01.<br>EX: Setting Pr54=1, Pr55=60Hz, Pr81=2.00, Make inverter runs as 30Hz, FM/AM-5 terminal outputs voltage from 5V to 10V.   |   |
| Pr191     | 0~50    | Step1: Setting Pr80=0.<br>Step2: Setting Pr54=0.<br>Step3: Terminal FM/AM—5 externally connect to a multifunctional current meter.<br>Step4: Set Pr191 until the voltage on the meter back to zero.  |   |
| Pr192     | 0~9998  | Step1: Terminal FM/AM externally connect to 「Current meter, scale as 1mA」, Set Pr54=0 (Extra external meters are used to indicate output frequency).<br>Step2: The rated frequency of the inverter is 60Hz, then start the motor.<br>Step3: After stabilization, Read setting value of Pr192, and the monitor displays the right revised constants.<br>Step4: Press ▲, the hand of the front of meter moves up, the revised constants on the monitor increases more and more.<br>Press ▼, the hand of the front of meter moves down, the revised constants on the monitor decreases more and more. |   |

## Pr57 Restart coasting time

## Pr58 Restart cushion time

| Parameter | Setting    | Description   |
|-----------|------------|---|
| Pr57      | 9999       | During operating, drive will stop output voltage after instantaneous power failure <sup>*1</sup> . There is NO RESTART after recovery.  |
|           | 0 to 5sec  | During operating, drive will stop output voltage after instantaneous power failure <sup>*1</sup> . Set the waiting time for drive-triggered restart after power failure. (Restart Coasting Time is set in Pr57). Inverter will restart automatically. |
| Pr58      | 0 to 60sec | Right after Motor Restart, output frequency is set running frequency but output voltage value is zero, then gradually ramp up to Proper voltage value. Time that required to ramp up is Restart Cushing time(Pr58).                                   |

\*1: Momentary power outage is that the CPU still working , and the PN voltage lower than the inverter can be running the operation voltage, in this state for some time the display will show "UVT".

## Pr60 Input signal filter constant

When reference of rated frequency is set from voltage signal or current signal, voltage/current must be converting by A/D to generate useful value. Due to above, Precision of components or signal interference influence, it results in external voltage or current signal furcating and it will also lead to rated frequency furcating. correspondingly, it will result unstable motor rotation.

For the parameter setting of Input Signal Filter Constant, its function is used to adjust and eliminate varying rated frequency that causes by component and the factor of interference. When the set value of Pr60 is higher, at the same time there will be better filtering ability and a bit of delay responding occurred.

## Pr61 Motor noise modulation selection


Motor noise modulation control is when the inverter varied its carrier frequency from time to time during operation, The metal noise that generates by motor is not a single frequency. This function selection is to improve the high peak single frequency noise.

| Setting Value | Noise Modulation Selection                          |
|---------------|---|
| 0             | <b><u>NO modulation control</u></b> (Initial Value) |
| 1             | <b><u>With modulation control</u></b>               |

## Pr64 Remote function selection

Even if the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.

| Parameter Number | Initial Value | Setting Range | Description   |                           |   |
|------------------|---------------|---------------|---------------|---------------------------|---|
|                  |               |               | Setting Value | Remote function selection | Frequency setting storage function                          |
| Pr64             | 0             | 0~3           | 0             | NO                        | ---   |
|                  |               |               | 1             | YES                       | YES   |
|                  |               |               | 2             |                           | NO  |
|                  |               |               | 3             |                           | NO<br>(Turning STF/STR off clears remotely- set frequency.) |




\*External operation frequency (other than multi-speed) or PU running frequency

## Remote setting function

1. Use Pr. 64 to select whether the remote setting function is used or not and whether the frequency setting storage function in the remote setting mode is used or not.

When Pr. 64 is set to any of "1 to 3" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).



Connection diagram for remote setting

2. When the remote function is used, the output frequency of the inverter can be compensated for as :

External operation....Frequency set with RH and RM operation + external operation frequency other than multi-speed

PU operation..... Frequency set by RH/RM operation + PU running frequency

## Frequency setting storage

The frequency setting storage function stores the remotely-set frequency (frequency set by RH/RM operation) into the memory (EEPROM). When power is switched off once, then on, operation is resumed with that output frequency value. (Pr. 64 = 1)


## Frequency setting storage conditions

1. Frequency at the point when the start signal (STF or STR) turns off
2. The remotely-set frequency is stored every one minute after one minute has elapsed since turn off (on) of both the RH (acceleration) and RM (deceleration) signals. (The frequency is written if the present frequency setting compared with the past frequency setting every one minute is different. The state of the RL signal does not affect writing.)

Note1. The range of frequency changeable by RH(acceleration) and RM (deceleration) is 0 to (maximum frequency – main speed setting) . The output frequency is limited by Pr.1.

Note2. When the acceleration or deceleration signal switches on. acceleration/deceleration is made in the time set to Pr. 7 and Pr. 8

Note3. When the RT signal is on , Pr44≠9999 and Pr45≠9999. acceleration/deceleration is made in the time set to Pr. 44(2nd acceleration time) and Pr. 45(2nd deceleration time)



## Pr65 Retry selection

## Pr67 Number of retries at alarm occurrence

## Pr68 Retry waiting time

## Pr69 Retry count Display erases

1. If alarm occurs, the drive resets itself automatically to restart (retry). Restart function is only available for OLT overload Alarm, or P-N over voltage alarm.
2. The inverter can roll back to previous status conditionally during operation . For example if alarm occurs, inverter reset itself for restart but in 30sec another alarm occurs, this type of alarm is “**Continues ALARM**. If continues alarm is occurred several times in a short period of time and exceeded some number, it means a major failure is occurred. This failure must be eliminated and at the same time NO RETRY will be this function is number of retries at alarm occurrence, Pr67.

3 Either overload alarm or P-N over voltage is not continued alarm, therefore the number of retries at alarm occurrence is not limited it retry number when alarm occurs.

4. In between the time of alarm occurrence and Inverter Retry is Retry Waiting Time.

| Parameter | Setting                   | Description   |
|-----------|---------------------------|---|
| Pr65      | 0                         | <b>No Retry function.</b> When alarm occurred, inverter stop to output voltage. All function will be locked when Alarm Indicator is lit.  |
|           | 1                         | When <b>Over voltage</b> is occurred between P-N, inverter stop to output voltage and after a short period of time(initial value in Pr68), inverter reset itself for retry.   |
|           | 2                         | When <b>Overload OLT・THM</b> occurs, inverter stop to output voltage and after a short Period of time (initial value in Pr68), inverter reset itself for retry.   |
|           | 3                         | When over voltage between <b>Over voltage・Overload OLT or THM</b> occurred, inverter stop itself to output voltage and after a short period of time (initial value in Pr68), inverter reset itself for retry.   |
| Pr67      | 0                         | No Restart  |
|           | 1 to 10<br>(1to10 times)  | If Continues Alarm occurs, and number of alarm is less than value in Pr67, inverter will reset itself for retry. In case the number of alarm occurs is more than value in Pr67, inverter won't be able to reset for retry. During Retry Waiting Time, indicator alarm is off. |
|           | 11 to 20<br>(1to10 times) | All function as above. The only difference is in "Retry Waiting Time", Alarm indicator is lit. After restart, Alarm indicator is off.   |
| Pr68      | 0 to 360sec               | Retry Waiting Time  |
| Pr69      | ---                       | Every time when Retry is made successfully, the value number is accumulated 1 automatically. Therefore the readout value is cumulative number of retry time made by retry.<br>If write in Pr69=0, retry history counts in CPU will be erased.                                 |



After the time that parameter Pr68 need to prepare rollback, the inverter will begin to rollback. Therefore, when the function is chosen, action may cause the operator danger , please handle with cautions and carefulness.

## Pr71 Brake option

| Parameter | Setting value | Description  |
|-----------|---------------|--|
| Pr71      | 0             | After pressing the stop button, the inverter voltage stops at the same time, the motor coasts to a stop. |
|           | 1             | After pressing the stop button, the motor will decelerate according to the curve to a stop.              |

## Pr72 Carrier frequency

1. When carrier frequency is higher, the mechanical noise of motor is smaller, but if current leakage chance is higher, the interference that generates by motor is larger.
2. When carrier frequency is getting higher, inverter consumes more energy, and heat of inverter is getting higher.
3. If there is any mechanical resonance occurs, the value number of Pr72 can be used to improve such issue.
4. If value set in Pr99=3, sensorless vector control, the range of carrier frequency is 2k~10kHz.



(Note) The value of Load Frequency is better having 10 times value more than rated frequency.




## Pr74 Starting terminals function selection

Input terminals of STF and STR is Starting Terminals. When inverter is in External Mode, or Combined Mode 1 and 3, there are different combination of START/STOP of Motor Rotation, detail as following chart:

| Parameter   | Pr74 |     |                        |     |     |                        |
|-------------|------|-----|------------------------|-----|-----|------------------------|
| Setting     | 0    |     |                        | 1   |     |                        |
| Description | STF  | STR | Motor Rotation         | STF | STR | Motor Rotation         |
|             | off  | off | STOP                   | off | off | STOP                   |
|             | off  | on  | Start Reverse Rotation | off | on  | STOP                   |
|             | on   | off | Start forward Rotation | on  | off | Start forward rotation |
|             | on   | on  | STOP                   | on  | on  | Start reverse rotation |

## Pr75 Reset Selection

| Pr75 Setting | RESET Selection                   | Disconnected PU Detection                                    | PU STOP Selection  |
|--------------|-----------------------------------|--|--|
| 0            | Under any condition reset enables | If the PU is disconnected operation will be continued as-is. | Pressing  decelerates the motor to a stop only in PU Mode and Combined Mode 2.  |
| 1            | When alarm occurs reset enables   |  |  |
| 2            | Under any condition reset enables | When the PU is disconnected, the inverter is shut off.       |  |
| 3            | When alarm occurs reset enables   |  |  |
| 4            | Under any condition reset enables | If the PU is disconnected operation will be continued as-is. | Pressing  decelerates the motor to a stop in any of operation mode.<br>(Note 1) |
| 5            | When alarm occurs reset enables   |  |  |
| 6            | Under any condition reset enables | When the PU is disconnected, the inverter is shut off.       |  |
| 7            | When alarm occurs reset enables   |  |  |

(Note 1) Pressing  decelerates the motor to a stop in External Mode and Combined Mode 1 and 3. Operation Panel display  and blocked all other function. Termination of Previous setting: Turn off STF or STR terminals, Press  return to Previous operation mode.

(Note 2) 1. In normal condition, enables reset by Pr997 setting.

2. When alarm occurs, pressing  to reset inverter.

(Note 3) Inside inverter there are 2 Program-simulated Thermal Relay, “Electronic type of Thermal Relay, and IGBT Modulated Thermal Relay. After inverter retry, the accumulated number of heat value of Electronic type Thermal Relay and IGBT Modulated Thermal Relay will be reset to “0”, please pay attention when in operation.



When Alarm occurs repeatedly, limit RESET number in Pr28 setting. If there is any other Alarm occurs, RESET will be invalid for operation. Please reboot the inverter and reset the ALARM, or contact certified technician for assistance.



### Pr77 Selection of prevention of parameter rewrite

| Parameter | Setting | Description   |
|-----------|---------|---|
| Pr77      | 0       | Write is enable only during a stop (Note 1)                 |
|           | 1       | Parameter write is not enabled (Note 2)                     |
|           | 2       | Parameter write is enabled during motor operating. (Note 3) |

(Note 1)When motor is operating , partial parameter write is enable , they are Pr4~Pr6, Pr24~Pr27, Pr54~Pr56 , Pr81~Pr82 ,Pr117~Pr120 , Pr126~Pr133 , Pr161~Pr164 , Pr192, Pr194~Pr197.

(Note 2)1.When motor is stop , partial parameter write is enable. they are Pr77 , Pr79 , Pr117~Pr119 , Pr192 , Pr194~Pr197 , Pr996~Pr999.

2.When motor is operating , partial parameter write is enable. They are Pr117~Pr119 , Pr192 , Pr194~Pr197.

(Note 3)1.When motor is at a stop, all parameter write is enabled.











甲、When motor is in operating, partial parameter write is not enabled, they are Pr22, Pr23, Pr32, Pr33, Pr34, Pr36, Pr38, Pr39, Pr48~Pr53, Pr61, Pr77, Pr79, Pr80, Pr84 , Pr99~Pr103, Pr105~Pr111, Pr115~Pr116, Pr125 , Pr160 , Pr165~Pr168 , Pr189 , Pr191, Pr994~Pr999.

### Pr78 Selection of prevention of reverse rotation of the motor

| Parameter | Setting | Description                                |
|-----------|---------|--|
| Pr78      | 0       | Both forward and reverse rotations allowed |
|           | 1       | Reverse rotation disabled                  |
|           | 2       | Forward rotation disallowed                |

### Pr79 Selection of operation mode

| Relate Parameter       | Setting Value | Description   |
|------------------------|---------------|---|
| Operation Mode<br>Pr79 | 0             | PU Mode, External Mode and JOG Mode enable switchover operation.                            |
|                        | 1             | PU Mode and JOG Mode enable switchover operation.   |
|                        | 2             | External Mode.(external frequency and start up)   |
|                        | 3             | Combined Mode 1. ( inner PU frequency and external start up)                                |
|                        | 4             | Combined Mode 2. ( external frequency and inner start up)                                   |
|                        | 5             | Combined Mode 3 ( inner PU frequency and external multi-speed frequency, external start up) |
|                        | 6             | Combined Mode 4 (RS485 Frequency and RS485 start up)  |
|                        | 7             | Combined Mode 5 (RS485 Frequency and External start up)                                     |
|                        | 8             | Combined Mode 6 (External Frequency or multi-speed and RS485 start up)                      |

| Pr79 setting value                            |               | Reference of rated frequency                             | Reference value for starting signal  |
|---|---------------|--|--|
| 0<br>(switchable<br>PU,External,<br>Jog,mode) | PU Mode       | Inner PU   | Inner PU  ,      |
|   | External mode | External current, voltage signal or external multi-speed | External STF,STR terminals   |
|   | JOG Mode      | Setting by parameter Pr15                                | Inner PU  ,      |
| 1<br>(switchable<br>PU,Jog,mode)              | PU Mode       | Inner PU   | Inner PU  ,      |
|   | JOG Mode      | Setting by parameter Pr15                                | Inner PU  ,      |
| 2<br>(External mode)                          |               | External current, voltage signal or external multi-speed | External STF,STR terminals   |
| 3<br>(Combined Mode 1)                        |               | Inner PU   | External STF,STR terminals   |
| 4<br>(Combined Mode2)                         |               | External current, voltage signal or external multi-speed | Inner PU  ,  |
| 5<br>(Combined Mode3)                         |               | Inner PU or external multi-speed                         | External STF,STR terminals   |
| 6<br>(Combined Mode4)                         |               | RS485 communication interface                            | RS485 communication interface activated, the motor rotate forward or reversely rotate  |
| 7<br>(Combined Mode5)                         |               | RS485 communication interface                            | External STF, STR terminals  |
| 8<br>(Combined Mode6)                         |               | External current, voltage signal or external multi-speed | RS485 communication interface activated, the motor rotate forward or reversely rotate  |

### Pr82 Set Frequency Gain Function

| Parameter Number | Setting value | Description  |
|------------------|---------------|--|
| Pr82             | 0             | Function disable.  |
|                  | 1~100%        | The operating frequency corresponding to the external analog input is scaled by the setting value of Pr82. |

(Note 1) When Pr82=0, this function is disabled. The operating frequency will return to the normal external voltage(current) signal operation: 0Hz~Pr38(Pr39) or Pr194~Pr195 (Pr196~Pr197).

(Note 2) To use Pr194~Pr197 to adjust user-defined frequency gain function curves, Pr82 must be set to 100%.

### ***I. 2-5 Terminal Voltage Input Signal:***

In the following description,  $V_{2-5}$  represents the external voltage input between 2-5 terminals.

$I_{4-5}$  represents the external current input between 4-5 terminals.  $V_{\max}$ ,  $V_{\min}$ ,  $V_{\text{mid}}$  represent the maximum, minimum, and middle voltage input between 2-5 terminals respectively.  $I_{\max}$ ,  $I_{\min}$ ,  $I_{\text{mid}}$  represent the maximum, minimum, and middle current input between 4-5 terminals respectively.

a. Pr73=0 (External 0-5V Input)

$$f = \text{Pr } 38 - \left[ 5V - (2.5V + (V_{2-5} - 2.5V) \times \text{Pr } 82) \right] \times \frac{\text{Pr } 38}{5V}$$

b. Pr73=1 (External 0-10V Input)

$$f = \text{Pr } 38 - \left[ 10V - (5V + (V_{2-5} - 5V) \times \text{Pr } 82) \right] \times \frac{\text{Pr } 38}{10V}$$

### ***II. 4-5 Terminal Current Input Signal:***

$$f = \text{Pr } 39 - \left[ 20\text{mA} - (12\text{mA} + (I_{4-5} - 12\text{mA}) \times \text{Pr } 82) \right] \times \frac{\text{Pr } 39}{16\text{mA}}$$

### ***III. 2-5 Terminal Voltage Input Signal using Pr194, Pr195 to redefine the curve :***

a. Pr194 Frequency  $\leq$  Pr195 Frequency

$$f = \text{Pr } 195 - \left[ V_{\max} - (V_{\text{mid}} + (V_{2-5} - V_{\text{mid}}) \times \text{Pr } 82) \right] \times \frac{\text{Pr } 195 - \text{Pr } 194}{V_{\max} - V_{\min}}$$

b. Pr194 Frequency  $>$  Pr195 Frequency

$$f = \text{Pr } 194 - \left[ (V_{\text{mid}} + (V_{2-5} - V_{\text{mid}}) \times \text{Pr } 82) - V_{\min} \right] \times \frac{\text{Pr } 194 - \text{Pr } 195}{V_{\max} - V_{\min}}$$

### ***IV. 4-5 Terminal Current Input Signal using Pr196, Pr197 to redefine the curve :***

a. Pr196 Frequency  $\leq$  Pr197 Frequency

$$f = \text{Pr } 197 - \left[ I_{\max} - (I_{\text{mid}} + (I_{4-5} - I_{\text{mid}}) \times \text{Pr } 82) \right] \times \frac{\text{Pr } 197 - \text{Pr } 196}{I_{\max} - I_{\min}}$$

b. Pr196 Frequency  $>$  Pr197 Frequency

$$f = \text{Pr } 196 - \left[ (I_{\text{mid}} + (I_{4-5} - I_{\text{mid}}) \times \text{Pr } 82) - I_{\min} \right] \times \frac{\text{Pr } 196 - \text{Pr } 197}{I_{\max} - I_{\min}}$$

**Example 1:**


Terminal AU ON, Pr82=100%. Set Pr196=0 when 4mA is applied to the 4-5 terminals and then set Pr197=60 when 20mA is applied to the 4-5 terminals.

The frequency values corresponding to 4mA and 20mA input when Pr82=1% can be obtained from the equations listed last page:

$$f_1 = 60Hz - \left[ 20mA - (12mA + (4mA - 12mA) \times 1\%) \right] \times \frac{60Hz}{20mA - 4mA} = 29.7Hz$$

$$f_2 = 60Hz - \left[ 20mA - (12mA + (20mA - 12mA) \times 1\%) \right] \times \frac{60Hz}{20mA - 4mA} = 30.3Hz$$

The frequency gain function curves when Pr82=100% and Pr82=1% are shown as follow:

**Example 2:**


Pr73=1, Pr82=100%. Set Pr194=80 when 0V is applied to the 2-5 terminals and then set Pr195=30 when 10V is applied to the 2-5 terminals.

The frequency values corresponding to 0V and 10V input when Pr82=50% can be obtained from the equations listed last page:

$$f_1 = 80Hz - \left[ (5V + (0V - 5V) \times 50\%) - 0V \right] \times \frac{80Hz - 30Hz}{10V} = 67.5Hz$$

$$f_2 = 80Hz - \left[ (5V + (10V - 5V) \times 50\%) - 0V \right] \times \frac{80Hz - 30Hz}{10V} = 42.5Hz$$

The frequency gain function curves when Pr82=100% and Pr82=50% are shown as follow:



## Pr84 FU/10 times frequency output terminal selection (requiring slot cover for switching)

Pr84 is the optional parameter when multi-functional output terminals and 10 times frequency function need to switch with each other. When Pr84 is zero, the output function of external terminal FU/10X is decided by Pr40 (refer to Pr40 function selection),

When Pr84 is not zero, the function of external terminal FU/10X is 10 times output function.


| Parameter   | Setting Value | Description   |
|-------------|---------------|---|
| <b>Pr84</b> | 0             | Output function of terminal is determined by Pr40.  |
|             | 1~10          | Running frequency will output Duty 50% impulse output according to the value of Pr84.(note) |

(Note)1. Function FU and 10X share the same hardware terminal, if they need to switch, 3 pin slot cover on the control board needs to switch at the same time. The initial position of the slot cover is at FU.

2. When setting Pr84 as non-zero value of 10 times frequency function, AM, FM functions are invalid.

### Operation Example:

Setting Pr84=5 and temporary running frequency as 20 Hz, it can be detected that output impulse wave of terminal FU/10X and SE is like below:



(Note)1. Pr84= 1 is 1 times output, inverter can provide 1 ~ 400Hz output that accuracy is 1%  
 2. When Pr84 and operation frequency is setting greater and greater ,the accuracy will deteriorate.  
 3. Resistor R must be greater than 330Ω ,otherwise terminal FU/10X may be damaged.

## Pr88 Auto Boost

## Pr89 Slip Compensation

| Parameter | Setting | Description  |
|-----------|---------|--|
| Pr88      | 0       | Enable the Auto Boost function                       |
|           | 1       | Disable the Auto Boost function                      |
| Pr89      | 0~3%    | The percentage of the slip compensation in V/F mode. |

(Note 1) Parameter Pr88、Pr89 are only valid at Pr99=0 under V/F mode.

(Note 2) Pr89 value is only valid at Pr88=1.

(Note 3) Properly adjust the motor torque boost so that the motor speed is more like setting speed.

## Pr90 Ground Current Leakage function selection

The fault caused by unbalanced current of Three-Phase Power Supply in inverter, current leakage occurs or grounding fault is Grounding Current Leakage.

| Parameter | Setting | Description                       |
|-----------|---------|-----------------------------------|
| Pr90      | 0       | Disable Grounding Current Leakage |
|           | 1       | Enable Grounding Current Leakage  |

## Pr91 to Pr96 Reshaping frequency

- In order to avoid mechanical resonance during motor operation, there are 3 values setting of frequency jump is Provided.

Pr91 & Pr92 is 1<sup>st</sup> pair of frequency jump.  
Pr93 & Pr94 is 2<sup>nd</sup> pair of frequency jump.  
Pr95 & Pr96 is 3<sup>rd</sup> pair of frequency jump.

- When Process setting, set

Pr91 < Pr92 < Pr93 < Pr94 < Pr95 < Pr96.

- Examples :


When Pr91=45 and Pr92=50

If rated frequency  $\leq$  45Hz, and then the stable output frequency=rated frequency

If 45Hz < rated frequency  $\leq$  50Hz and stable output frequency= 45Hz.

If 50Hz < rated frequency and then stable output frequency=rated frequency

Please see above right-sided diagram.



(Note 1) During deceleration phase, the output frequency of inverter will still perform through frequency jump.

(Note 2) When Pr91=9999 or Pr92=9999, 1<sup>st</sup> frequency jump is invalid.

When Pr93=9999 or Pr94=9999, 2<sup>nd</sup> frequency jump is invalid.

When Pr95=9999 or Pr96=9999, 3<sup>rd</sup> frequency is invalid.

## Pr99 Motor Control Mode Selection

| Parameter | Setting | Description  |
|-----------|---------|--|
| Pr99      | 0       | V/F Control (Initial Value)                                    |
|           | 1       | Motor Parameter Auto-Tuning(Motor won't rotate during tuning)  |
|           | 2       | Motor Parameter Auto-Tuning(Motor is in rotation while tuning) |
|           | 3       | Sensorless Vector Control                                      |
|           | 4       | Sensorless Torque Control                                      |

### 1. V/F Control:

There is no need for motor parameter auto-tuning, and the motor can work properly according to V/F curve.

### 2. Sensorless Vector Control:

By estimating the motor speed, use the closed-loop control method to achieve fast response and high-precision speed control. The motor parameters will affect the performance of sensorless vector control. Therefore recommend that before the sensorless vector control, first implementation motor parameters auto-tuning to increase control characteristics. Setting process please refer to Appendix 8

### 3. Sensorless Torque Control:

It is using the framework of sensorless vector control to carry out sensorless torque control. To be applied fixed torque control please set this control mode. Torque control parameters please refer to Pr115 ~ Pr120

### 4. Motor-parameter Auto-Tuning:

Motor parameter auto-tuning is divided into two kinds of tuning, one is static tuning (motor won't rotate during tuning) and the other is dynamic tuning (motor is in rotation while tuning). Before parameters auto-tuning, first should be enter the motor nameplate specification value: Motor capacity (Pr100), Motor pole number (Pr101), Motor rated voltage (Pr102), Motor rated frequency (Pr103)

#### a. Static tuning (Pr99=1):

When the motor has been hung in the belt, reducer, flywheel ... etc or in auto tuning didn't allow motor operation, please setting tuning mode as Static tuning. When using static tuning, first be setting the motor magnetic excited current (Pr105). General magnetic exciting current setting range is about 30 ~ 40% of motor rated current.

#### b. Dynamic tuning (Pr99=2):

In auto tuning if allow motor operation, please setting tuning as Dynamic tuning

When setting Pr99 = 1 or 2 to do motor parameter auto-tuning, after complete the tuning the Pr99 setting value will back to 0(V/F Control mode). If you need for high-precision sensorless vector control, please set Pr99 = 3. Setting process please refer to Appendix 2.(note)

### 5. For implementation of motor-parameter auto-tuning, only to set Pr99 = 1 or 2, and press the forward or the reverse button. Then the operation panel will display "TUN", if the measure fails, the operation panel flashes "FAL", and after three seconds return to normal display.

(note)

1. Motor capacity must be equal or less than inverter capacity.
2. when set Pr99 = 2 to do motor parameters auto-tuning, 11kW or more series please pick braking resistor, in order to avoid deceleration overvoltage.

**Pr100 Motor rated capacity**  
**Pr101 Motor Pole number**  
**Pr102 Motor rated voltage**  
**Pr103 Motor rated frequency**  
**Pr105 Motor exciting current**

**Pr106 Motor constant (R1)**  
**Pr107 Motor constant (R2)**  
**Pr108 Motor constant (L1)**  
**Pr109 Motor constant (L2)**  
**Pr110 Motor constant (Lm)**

| Parameter | Setting   | Function Description          |
|-----------|---|-------------------------------|
| Pr100     | Defined by Motor Specification  | Motor rated Volume.           |
| Pr101     |   | Motor Pole number.            |
| Pr102     |   | Motor rated voltage.          |
| Pr103     |   | Motor rated frequency         |
| Pr105     | 1. Pr99 = 1, To be manually set<br>Pr105.<br>2. Pr99=2, Automatically<br>detecting motor parameter. | Motor exciting current        |
| Pr106     |   | Motor Rs $\Omega$ .           |
| Pr107     |   | Motor Rr $\Omega$ .           |
| Pr108     |   | Motor Ls mH.                  |
| Pr109     |   | Motor Lr mH.                  |
| Pr110     |   | Motor magnetized inductor mH. |

(note)

1. When inverter use different grades of motor, make sure to confirm Rated voltage (Pr102) and correctly set the motor capacity (Pr100)。
2. Whatever using the static (Pr99 = 1) or dynamic (Pr99 = 2) motor parameter auto-tuning, before implementation auto tuning ,should be first to adjustments Pr100 ~ Pr103 that based on motor nameplate, to ensure more accurate measurement of parameters
3. If the motor parameters are known, you can directly enter the actual parameters of Pr105 ~ Pr110, implementation the parameter reset function (Pr997), and setting the Pr99 = 3 for sensorless vector control.
4. When the Pr105 ~ Pr110 parameter values have been manually changed, please do parameter reset function (Pr997) to re-load the new parameter values.
5. 5kW or above models Pr106 and Pr107 motor resistance unit is m $\Omega$ 。



## Pr113 Overvoltage stall protection selection

## Pr114 Overvoltage stall protection voltage

| Parameter | Value    | Description  |
|-----------|----------|--|
| Pr113     | 0        | Without Overvoltage stall protection function.     |
|           | 1        | With Overvoltage stall protection A.               |
|           | 2        | With Overvoltage stall protection B.               |
|           | 3        | With Overvoltage stall protection C.               |
| Pr114     | 110~140% | Setting Overvoltage stall protection voltage norm. |

During deceleration, for inertia reason, instant motor speed is faster than output frequencies which functions as generator and makes main circuit terminal P-N generate regenerative voltage, if no action is taken, regenerative voltage can damage the inverter.

### Overvoltage stall protection A: <sup>\*1</sup>

Overvoltage stall protection function will detect voltage between P-N during running, when voltage is higher than preset Pr114 value, inverter will stop output frequency until voltage is lower than preset Pr114 norm, then the inverter will continue to work.

### Overvoltage stall protection B: <sup>\*2</sup>


Overvoltage stall protection function will detect voltage between P-N during running, when voltage is higher than preset Pr114 value. inverter will be automatically calculated based on a suitable deceleration curve, to avoid the voltage between PN generate regenerative voltage

### Overvoltage stall protection C: <sup>\*2</sup>

Similar to Overvoltage stall protection B, applies to larger inertia systems, and can be greatly inhibited more effectively when P-N generate regenerative voltage is larger changes, But it will make the inverter output current severe. Long time continuous acceleration and deceleration will make motor overheat

\*1: This function still has its limit, when regenerative power is too much in short time, inverter will not response in time, therefore, clients are suggested to prolong the deceleration time or increase the brake resistor volume( The resistance goes down, Watts and brake will more efficient.)

\*2: In this function, inverter will automatically calculate the deceleration curve (see below), so that the original deceleration time Pr8 or Pr45 setting value will be invalid



**Pr115 Torque command source selection****Pr116 Speed limit selection****Pr117 Torque command value****Pr118 Forward rotation speed limit****Pr119 Reverse rotation speed limit****Pr120 Torque command gain**

※ Under mode of torque control (Pr99=4), Pr115~Pr120 are valid.

| Parameters | Value   | Description   |
|------------|---------|---|
| Pr115      | 0       | Analog input voltage of terminal 2-5 is torque command.   |
|            | 1       | Analog input current of terminal 4-5 is torque command.   |
|            | 2       | Value of Pr117 is torque command.   |
| Pr116      | 0       | The rated frequency of operation panel is limit of rotating speed.  |
|            | 1       | Analog input voltage of terminal 2-5 is limit of speed. If Pr115=0, 3Hz is the constrain value.                     |
|            | 2       | Analog input current of terminal 4-5 is limit of speed. If Pr115=1, 3Hz is the constrain value.                     |
|            | 3       | Terminals 2-5, 4-5 multi-speed phase combination input is the speed limit. If Pr115=0 or 1, 3Hz is constrain value. |
|            | 4       | Pr118 and Pr119 are speed limit.  |
| Pr117      | 0~100%  | Max output torque of inverter (Pr120=100%), Valid at Pr115=2.   |
| Pr118      | 0~120Hz | Forward rotation speed limit, valid at Pr116=4.   |
| Pr119      | 0~120Hz | Reverse rotation speed limit , valid at Pr116=4.  |
| Pr120      | 0~180%  | Reduce or add up max output torque of inverter.   |

(Note) Set terminals 2-5、4-5 as torque command, its analog input voltage is 0~5V(10V), input current 4~20mA accords with output torque command 0~100%.

Example:

$$1. \text{Pr115}=0、\text{Pr73}=0、\text{Pr120}=120\%, \text{ Max output torque} = \frac{V_{\text{terminal 2-5}}}{5V} \times 100\% \times \text{Pr120}$$

Therefore, the range of output torque is 0~120%(changing with terminal 2-5 input voltage).

$$2. \text{Pr115}=1、\text{Pr120}=80\%,$$

$$\text{Max output torque} = \frac{I_{\text{terminal 4-5}} (\geq 4\text{mA}) - 4\text{mA}}{16\text{mA}} \times 100\% \times \text{Pr120}, \text{ Therefore, the range of}$$

output torque is 0~80%(changing with terminal 4-5 input current).

$$3. \text{Pr115}=2、\text{Pr117}=90\%、\text{Pr120}=100\%, \text{ Max output torque} = \text{Pr117} \times \text{Pr120} = 90\%,$$

Max output torque fixes at 90%。

## Pr125 Digital Unit key tone selection

| Parameter | Setting | Description                   |
|-----------|---------|-------------------------------|
| Pr125     | 0       | Digital Unit without key tone |
|           | 1       | Digital Unit with key tone.   |

(Note) Pr125 is only applicable to a special Digital Unit that built-in buzzer series, generally Universal Digital Unit is invalid of this function .

## Pr160 PID operation selection

## Pr165 PID Output order limit

## Pr161 PID ratio increase

## Pr166 PID Alert value limit

## Pr162 PID integral increase

## Pr167 PID Alarm detection time

## Pr163 PID differential increase

## Pr168 PID Alarm solution

## Pr164 PID digital target value (PID application, please refer to appendix 5,Page 122)

| Pr160 setting | PID status      | Origin of target value | Origin of feedback | Description                               |
|---------------|-----------------|------------------------|--------------------|---|
| 0             | -               | -                      | -                  | PID function Pr161~Pr168 invalid.         |
| 1             | Negative action | 2-5Terminal            | 4-5Terminal        | -   |
| 2             | Negative action | 4-5Terminal            | 2-5Terminal        | -   |
| 3             | Negative action | Pr164 Setting value    | 4-5Terminal        | Pr164 value 0~100% stands for 4mA~20mA.   |
| 4             | Negative action | Pr164 Setting value    | 2-5Terminal        | Pr164 value 0~100% stands for 0V~5V(10V). |
| 5             | Positive action | 2-5Terminal            | 4-5Terminal        | -   |
| 6             | Positive action | 4-5Terminal            | 2-5Terminal        | -   |
| 7             | Positive action | Pr164 Setting value    | 4-5Terminal        | Pr164 value 0~100% stands for 4mA~20mA.   |
| 8             | Positive action | Pr164 Setting value    | 2-5Terminal        | Pr164 value 0~100% stands for 0V~5V(10V). |

| Parameter | Setting value | Function   |  |
|-----------|---------------|--|--|
| Pr161     | 0,0.1%~600%   | PID ratio increase Setting value, If the setting is 0, there is no such function.  |  |
| Pr162     | 0,0.1%~600%   | PID integral increase Setting value, If the setting is 0, there is no such function.   |  |
| Pr163     | 0,0.1%~600%   | PID differential increase Setting value, If the setting is 0, there is no such function.   |  |
| Pr164     | 0~100%        | PID digital target value, Only Pr160=3、4、7、8 is valid.   |  |
| Pr165     | 0~100%        | Output order limit, Max frequency=(Pr1×Pr165)/100 .  |  |
| Pr166     | 0,0.1%~100%   | If the setting is 0, there is no such function.<br>Max abnormal frequency=(Pr1×Pr166)/100 .  |  |
| Pr167     | 0,0.1~3600s   | If setting is 0, there will be no detection function. When operation frequency is equal to or more than Pr166 Max setting value for a while (Pr167), PID alarms. |  |
| Pr168     | 0~2           | 0:Terminal output alarms, motor will continue operating.   |  |
|           |               | 1: Terminal output alarms, motor will Decelerate.  | During operation, Operation panel will show”E.0” |
|           |               | 2:Terminal output alarms, motor will stop.   |  |
|           |               | Terminal output alarms, Set motor as Pr40.   |  |

**Pr170 Communication Protocol****Pr171 MODBUS Communication Address****Pr172 MODBUS Transmission Speed of the Communication****Pr173 MODBUS Data Format**

| Pr Number | Name                                    | Setting Range | Description  | Min Setting unit | Initial Value |
|-----------|---|---------------|--|------------------|---------------|
| Pr170     | Communication Protocol                  | 0~1           | 0 : Shihlin Protocol<br>1 : MODBUS Protocol  | 1                | 0             |
| Pr171     | Communication Address                   | 1~247         | Determine inverter communication address   | 1                | 1             |
| Pr172     | Transmission Speed of the Communication | 0~2           | 0 : 4800 bps<br>1 : 9600 bps<br>2 : 19200 bps  | 1                | 1             |
| Pr173     | MODBUS Data Format                      | 0~5           | 0 : (7,N,2) for ASCII<br>1 : (7,E,1) for ASCII<br>2 : (7,O,1) for ASCII<br>3 : (8,N,2) for RTU<br>4 : (8,E,1) for RTU<br>5 : (8,O,1) for RTU | 1                | 0             |

**●Computer Link:**

when the RS-485 series connection communication interface is utilized, every inverter has to pre-determine the communication address at Pr. 171, and thereafter, the computer will proceed with the control based on respective addresses.

**●MODBUS Communication Protocol:**

The Communication Protocol can be divided into ASCII mode and RTU mode, ASCII mode: every byte is composed of 2 ASCII words, RTU mode: the byte is not required to conversion, direct transmission.

The following will illustrate ASCII coding.


Example, if the numeric value is 73 Hex, the way to show it through the ASCII mode will be "73", which is composed respectively be "7" (37Hex) and "3" (33Hex).

| WORD       | "0" | "1" | "2" | "3" | "4" | "5" | "6" | "7" |
|------------|-----|-----|-----|-----|-----|-----|-----|-----|
| ASCII code | 30H | 31H | 32H | 33H | 34H | 35H | 36H | 37H |
| WORD       | "8" | "9" | "A" | "B" | "C" | "D" | "E" | "F" |
| ASCII code | 38H | 39H | 41H | 42H | 43H | 44H | 45H | 46H |


## ●Data Format:

10-bits character frame—For ASCII


(7, N, 2) Pr173=0



(7, E, 1) Pr173=1




(7, O, 1) Pr173=2




11-bit character frame—For RTU


(8, N, 2) Pr173=3



(8, E, 1) Pr173=4



(8, O, 1) Pr173=5



## 1. Communication Protocol:

### 1-1 Communication Data Frame

ASCII mode:

|           |  |
|-----------|--|
| STX       | Start character " : "(3AH)   |
| ADR1      | Communication address:<br>8-bit address consists of 2 ASCII codes                                |
| ADR0      |  |
| CMD1      | Command code:<br>8-bit command consists of 2 ASCII codes   |
| CMD0      |  |
| DATA(n-1) | Contents of data :<br>nx8-bit data consist of 2n ASCII codes<br>n<=25, maximum of 50 ASCII codes |
| .....     |  |
| DATA0     |  |
| LRC CHK 1 | LRC check sum :<br>8-bit check sum consists of 2 ASCII codes                                     |
| LRC CHK 0 |  |
| END 1     | End characters :<br>END 1=CR (0DH) , END 0=LF (0AH)  |
| END 0     |  |

RTU mode:

|           |  |
|-----------|--|
| START     | A silent interval of more than 10 ms                               |
| ADR       | Communication address :  |
| CMD       | Command code :   |
| DATA(n-1) | Contents of data:<br>$n \times 8\text{-bit data}, N \leq 25$       |
| .....     |  |
| DATA0     |  |
| CRC CHK 0 | CRC check sum :<br>16-bit check sum consists of 2 8-bit characters |
| CRC CHK 1 |  |
| END       | A silent interval of more than 10 ms                               |

### 1-2 Address (Communication Address)

01H: AC drive of address 01

02H: AC drive of address 02

32H: AC drive of address 50

:

:

F7H: AC drive of address 247

### 1-3 Command code and data characters

#### 1-3-1 Command code

03H: Multi read, read data from registers

06H: Write Single Register

08H: Diagnostics

10H: Write multiple data to registers

Command code: H03, Multi read, read data from registers

Example: When the address of the drive is set as 01H, read 2 data contents that exist successively within the register, as shown follows: the address of the start register is 0000H.

ASCII mode:

Command message

|                                |     |
|--------------------------------|-----|
| STX                            | ‘.’ |
| ADR1                           | ‘0’ |
| ADR0                           | ‘1’ |
| CMD1                           | ‘0’ |
| CMD0                           | ‘3’ |
| Starting data address          | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
| Number of data (count by word) | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘2’ |
| LRC CHK1                       | ‘F’ |
| LRC CHK0                       | ‘A’ |
| END1                           | CR  |
| END0                           | LF  |

Response message

|                                |     |
|--------------------------------|-----|
| STX                            | ‘.’ |
| ADR1                           | ‘0’ |
| ADR0                           | ‘1’ |
| CMD1                           | ‘0’ |
| CMD0                           | ‘3’ |
| Number of data (count by word) | ‘0’ |
|                                | ‘4’ |
| Data address1 0000H            | ‘0’ |
|                                | ‘0’ |
|                                | ‘3’ |
| Data address2 0001H            | ‘C’ |
|                                | ‘2’ |
|                                | ‘E’ |
|                                | ‘E’ |
| LRC CHK1 LRC CHK0              | ‘0’ |
|                                | ‘A’ |
| LRC CHK1 LRC CHK0              | ‘E’ |
|                                | ‘A’ |
| END1                           | CR  |
| END0                           | LF  |

Error response message

|            |     |
|------------|-----|
| STX        | ‘.’ |
| ADR1       | ‘0’ |
| ADR0       | ‘1’ |
| CMD1       | ‘8’ |
| CMD0       | ‘3’ |
| Error code | ‘0’ |
|            | ‘1’ |
| LRC CHK1   | ‘7’ |
| LRC CHK0   | ‘B’ |
| END1       | CR  |

RTU mode:

Command message

|                                |     |
|--------------------------------|-----|
| ADR                            | 01H |
| CMD                            | 03H |
| Starting data address          | 00H |
|                                | 00H |
| Number of data (count by word) | 00H |
|                                | 02H |
| CRC CHK0                       | C4H |
| CRC CHK1                       | 0BH |

Response message

|                          |     |
|--------------------------|-----|
| ADR                      | 01H |
| CMD                      | 03H |
| Data                     | 04H |
| Content of address 0000H | 00H |
|                          | 3CH |
| Count of address 0001H   | 2EH |
|                          | E0H |
| CRC CHK0                 | 26H |
| CRC CHK1                 | 17H |

Error response message

|                   |     |
|-------------------|-----|
| ADR               | 01H |
| CMD               | 83H |
| Error code        | 01H |
| CRC CHK0 CRC CHK1 | 80H |
|                   | F0H |



Command code: 06H, Write Single Register。

Example: Writing data 1770H to register 0001H. Starting data address is 01H。

ASCII mode:

| Command message                   |     | Response message                  |     | Error response message |     |
|-----------------------------------|-----|-----------------------------------|-----|------------------------|-----|
| STX                               | ‘.’ | STX                               | ‘.’ | STX                    | ‘.’ |
| ADR1<br>ADR0                      | ‘0’ | ADR1<br>ADR0                      | ‘0’ | ADR1<br>ADR0           | ‘0’ |
|                                   | ‘1’ |                                   | ‘1’ |                        | ‘1’ |
| CMD1<br>CMD0                      | ‘0’ | CMD1<br>CMD0                      | ‘0’ | CMD1<br>CMD0           | ‘8’ |
|                                   | ‘6’ |                                   | ‘6’ |                        | ‘6’ |
| Starting data<br>address          | ‘0’ | Starting data<br>address          | ‘0’ | Error code             | ‘0’ |
|                                   | ‘0’ |                                   | ‘0’ |                        | ‘2’ |
|                                   | ‘0’ |                                   | ‘1’ | LRC CHK1<br>LRC CHK0   | ‘7’ |
|                                   | ‘1’ |                                   | ‘1’ |                        | ‘7’ |
| Number of data<br>(count by word) | ‘1’ | Number of data<br>(count by word) | ‘1’ | END1<br>END0           | CR  |
|                                   | ‘7’ |                                   | ‘7’ |                        | LF  |
|                                   | ‘7’ |                                   | ‘0’ | LRC CHK1<br>LRC CHK0   | ‘7’ |
|                                   | ‘0’ |                                   | ‘1’ |                        | ‘1’ |
| LRC CHK1<br>LRC CHK0              | ‘7’ | END1<br>END0                      | CR  |                        |     |
|                                   | ‘1’ |                                   | LF  |                        |     |
| END1<br>END0                      | CR  |                                   |     |                        |     |
|                                   | LF  |                                   |     |                        |     |

RTU mode:

| Command message                   |     | Response message                  |     | Error response message |     |
|-----------------------------------|-----|-----------------------------------|-----|------------------------|-----|
| ADR                               | 01H | ADR                               | 01H | ADR                    | 01H |
| CMD                               | 06H | CMD                               | 06H | CMD                    | 86H |
| Starting data<br>address          | 00H | Starting data<br>address          | 00H | Error code             | 02H |
|                                   | 01H |                                   | 01H | CRC CHK 0<br>CRC CHK 1 | C3H |
| Number of data<br>(count by word) | 17H | Number of data<br>(count by word) | 17H |                        | A1H |
|                                   | 70H |                                   | 70H |                        |     |
| CRC CHK 0<br>CRC CHK 1            | D6H | CRC CHK 0<br>CRC CHK 1            | D6H |                        |     |
|                                   | 1EH |                                   | 1EH |                        |     |

Command code: 08H, Diagnostics, This command is used to detect if the communication between master device (PC or PLC) and inverter is normal. The inverter will send the received message to the master device.

Example: master device that address is 0001H send data 1770H to inverter. The inverter will send the received message to the master device.

ASCII mode:

| Command message                |     | Response message               |     | Error response message |     |
|--------------------------------|-----|--------------------------------|-----|------------------------|-----|
| STX                            | ‘.’ | STX                            | ‘.’ | STX                    | ‘.’ |
| ADR1                           | ‘0’ | ADR1                           | ‘0’ | ADR1                   | ‘0’ |
| ADR0                           | ‘1’ | ADR0                           | ‘1’ | ADR0                   | ‘1’ |
| CMD1                           | ‘0’ | CMD1                           | ‘0’ | CMD1                   | ‘8’ |
| CMD0                           | ‘8’ | CMD0                           | ‘8’ | CMD0                   | ‘8’ |
| Starting data address          | ‘0’ | Starting data address          | ‘0’ | Error code             | ‘0’ |
|                                | ‘0’ |                                | ‘0’ |                        | ‘3’ |
|                                | ‘0’ |                                | ‘0’ | LRC CHK1               | ‘7’ |
|                                | ‘0’ |                                | ‘0’ | LRC CHK0               | ‘4’ |
| Number of data (count by word) | ‘1’ | Number of data (count by word) | ‘1’ | END1                   | CR  |
|                                | ‘7’ |                                | ‘7’ |                        | LF  |
|                                | ‘7’ |                                | ‘7’ | END0                   | CR  |
|                                | ‘0’ |                                | ‘0’ |                        | LF  |
| LRC CHK1                       | ‘7’ | LRC CHK1                       | ‘7’ |                        |     |
| LRC CHK0                       | ‘0’ | LRC CHK0                       | ‘0’ |                        |     |
| END1                           | CR  | END1                           | CR  |                        |     |
| END0                           | LF  | END0                           | LF  |                        |     |

RTU mode:

| Command message                |     | Response message               |     | Error response message |     |
|--------------------------------|-----|--------------------------------|-----|------------------------|-----|
| ADR                            | 01H | ADR                            | 01H | ADR                    | 01H |
| CMD                            | 08H | CMD                            | 08H | CMD                    | 88H |
| Starting data address          | 00H | Starting data address          | 00H | Error code             | 03H |
|                                | 00H |                                | 00H | CRC CHK 0              | 06H |
| Number of data (count by word) | 17H | Number of data (count by word) | 17H | CRC CHK 1              | 01H |
|                                | 70H |                                | 70H |                        |     |
| CRC CHK 0                      | EEH | CRC CHK 0                      | EEH |                        |     |
| CRC CHK 1                      | 1FH | CRC CHK 1                      | 1FH |                        |     |

Command code: H10, Write multiple data to registers

Example: Write data 1388H、0FA0H to address 0005H to 0006H。

ASCII mode

Command message

|                                |     |
|--------------------------------|-----|
| STX                            | ‘.’ |
| ADR1                           | ‘0’ |
| ADR0                           | ‘1’ |
| CMD1                           | ‘1’ |
| CMD0                           | ‘0’ |
| Starting data address          | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘5’ |
| Number of data (count by word) | ‘0’ |
|                                | ‘0’ |
|                                | ‘2’ |
|                                | ‘0’ |
| Number of data (count by word) | ‘0’ |
|                                | ‘4’ |
|                                | ‘1’ |
|                                | ‘3’ |
| The first data content         | ‘8’ |
|                                | ‘8’ |
|                                | ‘0’ |
|                                | ‘F’ |
| The second data content        | ‘A’ |
|                                | ‘0’ |
|                                | ‘9’ |
|                                | ‘A’ |
| LRC CHK1                       | ‘9’ |
| LRC CHK0                       | ‘A’ |
| END1                           | CR  |
| END0                           | LF  |

Response message

|                                |     |
|--------------------------------|-----|
| STX                            | ‘.’ |
| ADR1                           | ‘0’ |
| ADR0                           | ‘1’ |
| CMD1                           | ‘1’ |
| CMD0                           | ‘0’ |
| Starting data address          | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘5’ |
| Number of data (count by word) | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘2’ |
| LRC CHK1                       | ‘E’ |
| LRC CHK0                       | ‘8’ |
| END1                           | CR  |
| END0                           | LF  |

Error response message

|            |     |
|------------|-----|
| STX        | ‘.’ |
| ADR1       | ‘0’ |
| ADR0       | ‘1’ |
| CMD1       | ‘9’ |
| CMD0       | ‘0’ |
| Error code | ‘0’ |
|            | ‘4’ |
| LRC CHK1   | ‘6’ |
| LRC CHK0   | ‘B’ |
| END1       | CR  |
| END0       | LF  |

RTU mode

Command message

|                                |     |
|--------------------------------|-----|
| ADR                            | 01H |
| CMD                            | 10H |
| Starting data address          | 00H |
|                                | 05H |
| Number of data (count by word) | 00H |
|                                | 02H |
| Number of data (count by word) | 04H |
| The first data content         | 13H |
|                                | 88H |
| The second data content        | 0FH |
|                                | A0H |
| CRC CHK 0                      | B2H |
| CRC CHK 1                      | B6H |

Response message

|                                |     |
|--------------------------------|-----|
| ADR                            | 01H |
| CMD                            | 10H |
| Starting data address          | 00H |
|                                | 05H |
| Number of data (count by word) | 00H |
|                                | 02H |
| CRC CHK0                       | 51H |
| CRC CHK1                       | C9H |

Error response message

|            |     |
|------------|-----|
| ADR        | 01H |
| CMD        | 90H |
| Error code | 04H |
| CRC CHK0   | 4DH |
| CRC CHK1   | C3H |

### 1-3-2 Check sum

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum

Example : Reading 2 word from address 0000H of the inverter with address 01H.

|                                |     |
|--------------------------------|-----|
| STX                            | ‘.’ |
| ADR1                           | ‘0’ |
| ADR0                           | ‘1’ |
| CMD1                           | ‘0’ |
| CMD0                           | ‘3’ |
| Starting data address          | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
| Number of data (count by word) | ‘0’ |
|                                | ‘0’ |
|                                | ‘0’ |
|                                | ‘2’ |
| LRC CHK1                       | ‘F’ |
| LRC CHK0                       | ‘A’ |
| END1                           | CR  |
| END0                           | LF  |

$01H+03H+00H+00H+00H+02H=06H$ , the 2's-complement negation of 06H is FAH

RTU mode: Uusing the CRC check sum, from Address to Data Content ,CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

The following is an example of CRC generation using C language:

```

unsigned char* data // a pointer to the message buffer
unsigned char length // the quantity of bytes in the message buffer
unsigned int crc_chk(unsigned char* data, unsigned char length)
{
    int j;
    unsigned int reg_crc=0xffff;
    while(length--)
    {
        reg_crc^=*data++;
        for(j=0;j<8;j++)
        {
            if(reg_crc & 0x01)
            {
                /*LSB(b0)=1*/
                reg_crc=(reg_crc >>1) ^ 0xa001;
            }
            else
            {
                reg_crc=reg_crc >> 1;
            }
        }
    }
    return reg_crc;
}

```

#### 1-4 Address list

| Read / write states | Function        | Address                | Data Content   |
|---------------------|-----------------|------------------------|--|
| Read / write        | Parameter       | 0000H-00C7H<br>(0-199) | Pr0-Pr199 corresponds to address 0000H-00C7H<br>(Please refer to appendix 7) |
| Read Only<br>(03H)  | Operation Mode  | 1000H<br>(4096)        | 0000H:DU/PU Communication Operation  |
|                     |                 |                        | 0001H:EXT Communication Operation  |
|                     |                 |                        | 0002H:JOG Communication Operation  |
|                     |                 |                        | 0003H:Combined Operation 1   |
|                     |                 |                        | 0004H:Combined Operation 2   |
|                     |                 |                        | 0005H:Combined Operation 3   |
|                     |                 |                        | 0006H:Combined Operation 4   |
|                     |                 |                        | 0007H:Combined Operation 5   |
|                     |                 |                        | 0008H:Combined Operation 6   |
|                     | Inverter States | 1001H<br>(4097)        | b0:Operation   |
|                     |                 |                        | b1:Forward Rotation  |
|                     |                 |                        | b2:Reverse Rotation  |

|                     |                   |                 |  |           |             |
|---------------------|-------------------|-----------------|--|-----------|-------------|
|                     |                   |                 | b3:Frequency Achieved  |           |             |
|                     |                   |                 | b4:Overload  |           |             |
|                     |                   |                 | b5:Key tone  |           |             |
|                     |                   |                 | b6:Frequency Detection   |           |             |
|                     |                   |                 | b7:Alarm Occurrence  |           |             |
|                     |                   |                 | b8:RES ON  |           |             |
|                     |                   |                 | b9:STF ON  |           |             |
|                     |                   |                 | b10:STR ON   |           |             |
|                     |                   |                 | b11:When is in external operation, Press STOP key on Control panel |           |             |
|                     |                   |                 | b12~b15:Reserved   |           |             |
|                     | Frequency Setting | 1002H(4098)     | 0000H~9C40H (0~400Hz)  |           |             |
|                     | Output Frequency  | 1003H(4099)     | 0000H~9C40H (0~400Hz)  |           |             |
|                     | Output Current    | 1004H(4100)     | 0000H~FFFFH  |           |             |
|                     | Output Voltage    | 1005H(4101)     | 0000H~FFFFH  |           |             |
|                     | Message           | 1006H<br>(4102) | 00H : No Display   |           |             |
|                     |                   |                 | 10H : TUN  |           |             |
|                     |                   |                 | 11H : FAL  |           |             |
|                     |                   |                 | 12H : RET  |           |             |
|                     |                   |                 | 13H : SL   |           |             |
|                     |                   |                 | 14H : LV   |           |             |
|                     |                   |                 | 15H : OV   |           |             |
|                     |                   |                 | 16H : OL   |           |             |
|                     | Error Code        | 1007H<br>(4103) | 00H : No Err   | 32H : NTC | 70H : BE    |
|                     |                   |                 | 10H : OC1  | 33H : SCR | 80H : GF    |
|                     |                   |                 | 11H : OC2  | 40H : EEP | 90H : OHT   |
|                     |                   |                 | 12H : OC3  | 41H : FAN | A0H : OPT   |
|                     |                   |                 | 20H : OV1  | 42H : PID | B0H : PE    |
|                     |                   |                 | 21H : OV2  | 50H : UVT | B1H : PUE   |
|                     |                   |                 | 22H : OV3  | 51H : OP1 | B2H : RET   |
|                     |                   |                 | 30H : THT  | 52H : IPF | C0H : CPU   |
|                     |                   |                 | 31H : THM  | 60H : OLT | Other : SPE |
| Write Only<br>(06H) | Operation Mode    | 1000H<br>(4096) | 0000H : DU/PU Communication Operation                              |           |             |
|                     |                   |                 | 0001H : EXT Communication Operation                                |           |             |
|                     |                   |                 | 0002H : JOG Communication Operation                                |           |             |
|                     | Operation Command | 1001H<br>(4097) | b0: Inverter stop output (MRS)                                     |           |             |
|                     |                   |                 | b1:Forward Rotation (STF)  |           |             |
|                     |                   |                 | b2:Reverese Rotation (STR)   |           |             |

|  |                                    |             |   |
|--|------------------------------------|-------------|---|
|  |                                    |             | b3:Low Speed (RL)   |
|  |                                    |             | b4:Medium Speed (RM)  |
|  |                                    |             | b5:High Speed (RH)  |
|  |                                    |             | b6:Multi-Speed (REX)  |
|  |                                    |             | b7:2 <sup>nd</sup> Functions (RT)   |
|  |                                    |             | b8~b15:Reserved   |
|  |                                    |             | (note) In the RS-485 communication mode, the external terminal MRS, RT function is still valid. |
|  | Operation<br>Frequency<br>Write In | 1002H(4098) | 0000H~9C40H (0~400Hz)   |
|  | Inverter<br>RESET                  | 1101H(4353) | 9696H : Pr997   |
|  | Parameter<br>Error Code<br>erased  | 1102H(4354) | A5A5H : Pr996   |
|  |                                    | 1103H(4355) | 9966H : Pr998   |
|  |                                    | 1104H(4356) | 5A5AH : Pr999   |
|  |                                    | 1105H(4357) | 55AAH:Except communication parameter ,all parameter must be back to initial value.              |

#### 1-5 Exception response:

If errors occurred when the drive is conducting the communication connection, the drive will respond to this error and send the Command code to the master control system so that the system will be informed of the error. In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

For example: Command code is 10H, if errors occurred the most significant bit of the original command code is set to 1 and become 90H.

#### ASCII Error response message

|            |     |
|------------|-----|
| STX        | ‘.’ |
| ADR1       | ‘0’ |
| ADR0       | ‘1’ |
| CMD1       | ‘9’ |
| CMD0       | ‘0’ |
| Error code | ‘0’ |
|            | ‘4’ |
| LRC CHK1   | ‘6’ |
| LRC CHK0   | ‘B’ |
| END1       | CR  |
| END0       | LF  |

#### RTU Error response message

|            |     |
|------------|-----|
| ADR        | 01H |
| CMD        | 90H |
| Error code | 04H |
| CRC CHK 0  | C3H |
| CRC CHK 1  | 4DH |


#### 1-5-1 The explanation of Error codes:

| Error code | Name                    | Explanation   |
|------------|-------------------------|---|
| 01         | Data Contents Error     | If the value of the data contents is great, it is then not recognizable by the drive. |
| 02         | Parameter Address Error | Parameter addresses not recognizable by the drive                                     |
| 03         | Data value Error        | The data value received in the command message is not available for the inverter.     |
| 04         | Other errors            | Other unexpected error occurred   |

#### Pr180 Proportional Gain of Speed Controller

#### Pr181 Integral Gain of Speed Controller

#### Pr187 Bandwidth of Speed Controller



| Parameter | Control mode                        | Setting value | Function Description   |
|-----------|-------------------------------------|---------------|--|
| Pr180     | Pr99=3<br>Sensorless Vector Control | 0~100%        | Increase setting value will increase the speed response , and speed up the load-carrying ability             |
| Pr181     |                                     | 0~100%        | Decrease Setting value,will decrease the Steady-state error ,and reduce the recovery time when load-carrying |
| Pr187     |                                     | 20~120        | Increase setting value will increase the speed response  |



## Pr182 Slip Compensation

Slip is defined as the electrical rotor speed ( $\omega_e$ ) minus the rotor speed ( $\omega_r$ ). In sensorless vector control mode, the rotor speed is obtained by the estimation method. Therefore, there is a modicum of estimation error. For this reason, the estimated rotor speed and actual rotor speed can be compensated by Pr182. Let rotor speed be equal to electrical speed.


| Parameter | Control mode                        | Setting value | Function Description                           |
|-----------|-------------------------------------|---------------|--|
| Pr182     | Pr99=3<br>Sensorless Vector Control | 0~50%         | Increase setting value will decrease the slip. |

## Pr183 Speed Compensation Coefficient


It is used to compensate for no-load speed estimation error that caused by sensorless vector control.

| Parameter | Control mode                        | Setting value | Function Description  |
|-----------|-------------------------------------|---------------|---|
| Pr183     | Pr99=3<br>Sensorless Vector Control | 0~100%        | Increase setting value will increase the compensation speed error |

For example: For 4-pole motor. When the target frequency is 5Hz but the actual speed was at 140 rpm, you can increase the Pr183 settings value to change the speed command and let speed reach 150 rpm. On the contrary, if the speed is over 150 rpm you can reduce Pr183 settings value to lower the speed command. Pr183 Setting method as follows Figure



- Pr184 Low Speed Excited Rate**  
**Pr185 High Speed Excited Rate**  
**Pr186 High Speed Excited Curve**



Pr184 ~ Pr185 is magnetic flux parameters of sensorless vector control, On above diagram it displayed the relation of flux command. Pr184 is the low speed excited rate between 0 ~ 20Hz. Pr185 is high speed excited rate when motor is in 55Hz. Pr186 is different kinds of excited curve.

| Parameter | Control mode                        | Setting value | Function Description  |
|-----------|-------------------------------------|---------------|---|
| Pr184     | Pr99=3<br>Sensorless Vector Control | 0~100%        | Increase Setting value will increase the load carrying ability but it also increase no-load current in low speed range                              |
| Pr185     |                                     | 0~100%        | Decrease setting value will avoid the exception occurred but it will decrease load-carrying ability at high speed                                   |
| Pr186     |                                     | 0、1、2         | Increase setting value will promote the field-weakening response and it can avoid the exception occurred at high speed acceleration or deceleration |

## Pr189 50Hz/60Hz system switchover

| Parameter | Setting Value | Description                 |
|-----------|---------------|-----------------------------|
| Pr189     | 0             | 60Hz system (initial value) |
|           | 1             | 50Hz system                 |

(Note) Clients can set the parameter by motor operation frequency. This parameter has to follow the function Pr998 after its setting up, then it is able to reload counterpart parameter initial value to new frequency system. Pr3,Pr20,Pr38,Pr39,Pr55,Pr66,Pr103,Pr118,Pr119,Pr195,Pr197.

## Pr194 Frequency Setting Voltage Bias

## Pr195 Frequency Setting Voltage Gain


When inverter is in Pr79=2 External Mode or Pr79=4 Combined Mode 2, it is allowed to add voltage signal 0-5V or 0-10V among analog input terminal 2-5. So make the frequency adjust by the changing of voltage signal to revise the corresponding value of frequency and voltage signal. Procedures of Calibration:

Step1. Make sure current signal is wired with terminal 2-5.

Step2. If preset condition is “when voltage signal is 1V, Expected start frequency is 20 Hz”, and write value of 20 into Pr194.

Step3. If Preset condition is “when voltage signal is 4V, Expected rated frequency is 60 Hz”, and write value 60 into Pr195.

Step4. After finishing step 1-3, When the voltage changes among 1-4V, The frequency will fluctuate among 20 to 60 Hz.



(Note) 1. After rewrite parameter values into Pr194 and Pr195, the curve of Pr38 will be invalid.

2. Voltage signal value  $\leq 1V$  ( $\geq 4V$ ) , but will be stable at Pr194(Pr195) Setting value, as above graph.

## Pr196 Frequency setting current bias

## Pr197 Frequency setting current gain

When inverter is in Pr79=2 External Mode or Pr79=4 Combined Mode 2, it is allowed to add current signal 4-20mA among analog input terminal 4-5. So make the frequency adjust by the changing of current signal to revise the corresponding value of frequency and current signal.


Procedures of Calibration:

Step1. Make sure current signal is wired with terminal 4-5.

Step2. If preset condition is “when current signal is 5mA, expected start frequency is 20Hz”, and write value of 20 into Pr196.

Step3. If Preset condition is “when current signal is 15mA, expected rated frequency is 60Hz”, and write value 60 into Pr197.

Step4. After finishing step 1-3, When the current signal changes among 5-15mA, The frequency will fluctuate among 20 to 60 Hz.



(Note)1. After Pr196 and Pr197 reset, the curve of Pr39 will be invalid.

2. Current signal value  $\leq 5\text{mA}$  ( $\geq 15\text{mA}$ ), but will be stable at Pr196(Pr197) Setting value, as above graph.

## Pr199 Software edition

Parameter is not writable and only readable.

## Pr994 Parameter copy readout

## Pr995 Parameter copy write-in

When set value into Pr994, Pr995, Motor rotation must be in a stop, this parameter value is only valid when Pr77=0 and in PU mode. When using same parameters for several inverter value setting. Use Pr994 and Pr995 to perform duplication value to other inverter rapidly.

Procedures of parameter copy:

Step1. When 1<sup>st</sup> inverter is in PU mode, the value of Pr994 is readout (the monitor displayed  $P r . \bar{C} P$ ) and then press “Write”, at the same time monitor screen is flickering, it means that the parameter copy from inverter to control panel is in process. When no more flickering on monitor screen is means the parameter copy is done.

Step2. When 2<sup>nd</sup> inverter is in PU mode, the value of Pr995 is readout (the monitor displays  $P r . \bar{C} R$ ) and then press “write” at the same time, then the monitor is flickering it means the parameter copy from Digital Unit to inverter EEPROM is in process. When the screen is no more flickering, the parameter copy is done.

(Note 1) Regarding parameter copy function in Pr994 and Pr995, it is only available on SH-PU series of Inverters.

(Note 2) When parameter copy is in process, the value of Pr0 to Pr190 will be copied and duplicate into Digital Unit and inverter.

### **Pr996 Alarm histories erase**

Readout Pr996 value, **Er.LL** is displays on the screen of Digital Unit, and then press “Write” key to erase all ALARM History record.

### **Pr997 Inverter Reset**

When the value of Pr997 is read out, **r.ESt** is display on screen of Digital Unit, then press “Write” key for inverter reset. After inverter reset, The record in thermal relay, and IGBT modulated thermal relay will be reset to zero.

### **Pr998 All Parameters Restore to initial Value**

When value of Pr998 is readout, **ALL.L** is display on screen of Digital Unit and then press “Write” key to restore factory default value.( Except Pr189)

### **Pr999 Partial Parameters Restore to initial value**

When value of Pr999 is readout, **Pr.Lr** is display on screen, and then press “Write”, all parameters will be restored to factory default initial value, except Pr32 to Pr36 , Pr48 to Pr53, Pr189 , Pr192 , Pr194 to Pr197.

## **Chapter 4 Maintenance and Troubleshooting**

Environmental factors of temperature, oil mist, dust, vibration, humidity may cause component aging and component aging may lead to inverter malfunction and public security incident. When inverter is in operation, penetrative maintenance of Daily Inspection and Periodical should be carried out routinely.

(Note) Only certified technician is allowed to perform installation, wiring, disassembly, and maintenance.

### **4-1 Daily Inspection Items**

1. Make sure if the surrounding of installation location is normal environment (Temperature around inverter, humidity, dust, etc.
2. Make sure the voltage of power supply is normal during operation.
3. Make sure all wiring is secured.
4. Check for irregular cooling system during operation.(check if any irregular fan noise during operation)
5. Check if LED is normal during operation. (Check if LED on Digital Unit, LED Indicator on Digital Unit, LED Screen on Digital Unit is normal.)
6. Make sure the operation as expected.
7. Check if any irregular vibration, sounds, peculiar smell during operation.
8. Check if any leakage on filter capacitor on PCB board.

### **4-2 Regular Inspection (Off-line inspection) Items:**

1. Check if connector and cable for wiring is correct? (Check if any damage or the connector and wire are firmly secured between Main Circuit and Control Panel)
2. Make sure to clean the dust and unclean objects in inverter.
3. Inspection on insulated resistors.
4. Check if cooling system is normal. (All wiring secured? Please do clean air filter and wind tunnel)
5. Check if device is fixed and make sure to fix screw tightly.
6. Check if external cable and terminal receptacle is broken.

### 4-3 Periodic Parts Replacement


| Part Name        | Standard replacement Interval | Description   |
|------------------|-------------------------------|---|
| Cooling Fan      | 2 years                       | The life of the cooling fan bearing is usually 10,000-35000 hours. If operation is 24 hours then the cooling fan must be replaced every 2 years.  |
| Filter Capacitor | 5 years                       | Filter Capacitor is type of electrolytic capacitors, the physical characteristics of capacitor may deteriorated after continuously use. The deterioration is decides by operation environment. In general, change the capacitors every 5 years. |
| Relays           | ---                           | Any contact fault occurs, relays must be replaced.  |

(Note) When there is a need to replace parts, please send back to factory for replacement.

# APPENDIX

## Appendix 1 Communication Protocol 〈Communication sequence〉

### 1. Communication sequence as following:



- ① PC Communication Request      ④ PC Processing Time  
 ② Inverter Processing      ⑤ PC Responding Time  
 ③ Inverter Responding      Note: ② Should more than 500μs

### 2. Communication type with or without data format:

| Item No. | Description   |                             | Operation Command | Operation Frequency | Write Parameter | Restart | Monitoring | Read Out Parameter |
|----------|---|-----------------------------|-------------------|---------------------|-----------------|---------|------------|--------------------|
| ①        | Computer send out communication request to inverter |                             | A                 | A                   | A               | A       | B          | B                  |
| ②        | Inverter Data Processing time                       |                             | yes               | yes                 | yes             | NA      | yes        | yes                |
| ③        | Data responded From inverter                        | No error (request accepted) | C                 | C                   | C               | NA      | E          | E                  |
|          |   | Error (request rejected)    | D                 | D                   | D               | NA      | F          | F                  |
| ④        | Computer data processing time                       |                             | NA                | NA                  | NA              | NA      | G          | G                  |
| ⑤        | About ③, Data Responded from PC                     | No error (no process)       | NA                | NA                  | NA              | NA      | G          | G                  |
|          |   | Error (output ③)            | NA                | NA                  | NA              | NA      | H          | H                  |



### 3. Communication format: ( note: CR, LF Setting by Pr51)

#### (a) Communication Request from PC to Inverter

Format A: (Write data to Inverter)

| ENQ | Station Number |   | Command Code | Waiting Time | Data |   |   |   |    | SUM CHECK |    | CR | (LF) |
|-----|----------------|---|--------------|--------------|------|---|---|---|----|-----------|----|----|------|
| 1   | 2              | 3 | 4            | 5            | 6    | 7 | 8 | 9 | 10 | 11        | 12 | 13 | 14   |

Format B: (Read data from Inverter)

| ENQ | Station Number |   | Command code |   | Waiting Time | SUM CHECK |   | CR | (LF) |
|-----|----------------|---|--------------|---|--------------|-----------|---|----|------|
| 1   | 2              | 3 | 4            | 5 | 6            | 7         | 8 | 9  | 10   |

#### (b) Computer transmit data to inverter, inverter response data

Format C: (Data W/O Error)

| ACK | Station Number |   | CR | (LF) |
|-----|----------------|---|----|------|
| 1   | 2              | 3 | 4  | 5    |

Format D: (Data Error)

| NAK | Station Number |   | Error Code | CR | (LF) |
|-----|----------------|---|------------|----|------|
| 1   | 2              | 3 | 4          | 5  | 6    |

#### (c) Computer readout data from Inverter, inverter response data

Format E: (Data W/O Error)

| STX | Station number |   | Readout Data |   |   |   | Unit<br>*Note 1 | ETX | SUM<br>CHECK |    | CR | (LF) |
|-----|----------------|---|--------------|---|---|---|-----------------|-----|--------------|----|----|------|
| 1   | 2              | 3 | 4            | 5 | 6 | 7 | 8               | 9   | 10           | 11 | 12 | 13   |

Format F: (Data Error)

| NAK | Station Number |   | Error Code | CR | (LF) |
|-----|----------------|---|------------|----|------|
| 1   | 2              | 3 | 4          | 5  | 6    |

#### 【Note 1】

| Single Digit | 0 | 1   | 2    | 3     |
|--------------|---|-----|------|-------|
| Min. Unit    | 1 | 0.1 | 0.01 | 0.001 |

#### (d) When computer is in data reading, responding data after data receipt from inverter.

Format G: (Data W/O Error)

| ACK | Station Number |   | CR | (LF) |
|-----|----------------|---|----|------|
| 1   | 2              | 3 | 4  | 5    |

Format H: (Data Error)

| NAK | Station Number |   | CR | (LF) |
|-----|----------------|---|----|------|
| 1   | 2              | 3 | 4  | 5    |

### (1). Description of Control Code(ASCII CODE)

| Control Code | ASCII Code | Description                |
|--------------|------------|----------------------------|
| STX          | H02        | Starting Data Transmission |
| ETX          | H03        | End Data Transmission      |
| ENQ          | H05        | Communicating Request      |
| ACK          | H06        | Accuracy Check             |
| LF           | H0A        | Line sent out              |
| CR           | H0D        | Line change                |
| NAK          | H15        | Error data                 |

### (2). SUM CHECK Description

(Example 1)

| ENQ | Station Number |     | Command Code |     | Waiting Time | Data |     |     |     | SUM CHECK |     |
|-----|----------------|-----|--------------|-----|--------------|------|-----|-----|-----|-----------|-----|
|     | 0              | 1   | E            | 1   | 1            | 0    | 7   | A   | D   | F         | 4   |
| H05 | H30            | H31 | H45          | H31 | H31          | H30  | H37 | H41 | H44 | H46       | H34 |

$$\xleftrightarrow{\quad\quad\quad\downarrow\quad\quad\quad}\text{H30+H31+H45+H31+H31+H30+H37+H41+H44=H1F4}$$

(Example 2)

| STX | Station Number |     | Readout Data |     |     |     | Unit | ETX | SUM CHECK |     |
|-----|----------------|-----|--------------|-----|-----|-----|------|-----|-----------|-----|
|     | 0              | 1   | 1            | 7   | 7   | 0   |      |     | 6         | 0   |
| H02 | H30            | H31 | H31          | H37 | H37 | H30 | H30  | H03 | H36       | H30 |

$$\xleftrightarrow{\quad\quad\quad\downarrow\quad\quad\quad}\text{H30+H31+H31+H37+H37+H30+H30=H160}$$

### (3). Error Code

| Code | Error Content      | Code | Error Content   | Code | Error Content   |
|------|--------------------|------|-----------------|------|-----------------|
| H0   | Operator NAK Error | H1   | Parity Error    | H2   | SUM CHECK error |
| H3   | Protocol error     | H4   | Frame Error     | H5   | Over run error  |
| H6   | reserved           | H7   | Character Error | H8   | reserved        |
| H9   | reserved           | HA   | Mode Error      | HB   | Command Error   |
| HC   | Data Range Error   | HD   | reserved        | HE   | reserved        |
| HF   | reserved           |      |                 |      |                 |

# 〈Setting Item and data〉

| No  | Item           |                      | Command         | Data Content   | Byte Number |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|-----|----------------|----------------------|-----------------|--|-------------|------|---------|---|---|---|---|-------------------------|---|---|---|---|---|---|---|---|---|---|-----------------------|--|--|--|--|--|--|--|-------------------------|--|--|--|--|--|--|--|------|---------|------|---------|-----|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|-----|-----|--|--|-----|-----|--|--|-----|-----|----------------------|--|--------|
| 1   | Operation Mode | Read Out             | H7B             | H0000: DU/PU communication operation<br>H0001: EXT communication operation<br>H0002: JOG communication operation<br>H0003~ H0008: Combined operation 1~6   | 4Bytes      |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                | Write                | HFB             | H0000: DU/PU communication operation<br>H0001: EXT communication operation<br>H0002: JOG communication operation   | 4Bytes      |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| 2   | Monitoring     | Output Frequency     | H6F             | H0000~H9C40  | 4Bytes      |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                | Rated frequency      | H73             | H0000~H9C40  | 4Bytes      |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                | Output current       | H70             | H0000~HFFFF  | 4Bytes      |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                | Output voltage       | H71             | H0000~HFFFF  | 4Bytes      |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                | Alarm item           | H74<br> <br>H77 | H0000~HFFFF: Last 2 alarm code<br><br>ex: Alarm Code of H74 as follow<br><table><tr><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td colspan="8">Last Alarm Code (FAN)</td><td colspan="8">Recent Alarm Code (OPT)</td></tr></table><br><table><tr><td>Data</td><td>Content</td><td>Data</td><td>Content</td></tr><tr><td>H00</td><td>No Fault</td><td>H51</td><td>OP1</td></tr><tr><td>H10</td><td>OC1</td><td>H52</td><td>IPF</td></tr><tr><td>H11</td><td>OC2</td><td>H60</td><td>OLT</td></tr><tr><td>H12</td><td>OC3</td><td>H70</td><td>BE</td></tr><tr><td>H20</td><td>OV1</td><td>H80</td><td>GF</td></tr><tr><td>H21</td><td>OV2</td><td>H90</td><td>OHT</td></tr><tr><td>H22</td><td>OV3</td><td>HA0</td><td>OPT</td></tr><tr><td>H30</td><td>THT</td><td>HB0</td><td>PE</td></tr><tr><td>H31</td><td>THM</td><td>HB1</td><td>PUE</td></tr><tr><td>H32</td><td>NTC</td><td>HB2</td><td>RET</td></tr><tr><td>H33</td><td>SCR</td><td>HC0</td><td>CPU</td></tr><tr><td>H40</td><td>EEP</td><td></td><td></td></tr><tr><td>H41</td><td>FAN</td><td colspan="2"></td></tr><tr><td>H42</td><td>PID</td><td colspan="2"></td></tr><tr><td>H50</td><td>UVT</td><td colspan="2">Other error code SPE</td></tr></table> |             |      | 0       | 1 | 0 | 0 | 0 | 0                       | 0 | 1 | 1 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | Last Alarm Code (FAN) |  |  |  |  |  |  |  | Recent Alarm Code (OPT) |  |  |  |  |  |  |  | Data | Content | Data | Content | H00 | No Fault | H51 | OP1 | H10 | OC1 | H52 | IPF | H11 | OC2 | H60 | OLT | H12 | OC3 | H70 | BE | H20 | OV1 | H80 | GF | H21 | OV2 | H90 | OHT | H22 | OV3 | HA0 | OPT | H30 | THT | HB0 | PE | H31 | THM | HB1 | PUE | H32 | NTC | HB2 | RET | H33 | SCR | HC0 | CPU | H40 | EEP |  |  | H41 | FAN |  |  | H42 | PID |  |  | H50 | UVT | Other error code SPE |  | 4Bytes |
|     |                |                      |                 | 0  | 1           | 0    | 0       | 0 | 0 | 0 | 1 | 1                       | 0 | 1 | 0 | 0 | 0 | 0 | 0 |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                |                      |                 | Last Alarm Code (FAN)  |             |      |         |   |   |   |   | Recent Alarm Code (OPT) |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                |                      |                 | Data   | Content     | Data | Content |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                |                      |                 | H00  | No Fault    | H51  | OP1     |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
|     |                |                      |                 | H10  | OC1         | H52  | IPF     |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H11 | OC2            |                      |                 | H60  | OLT         |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H12 | OC3            |                      |                 | H70  | BE          |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H20 | OV1            |                      |                 | H80  | GF          |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H21 | OV2            |                      |                 | H90  | OHT         |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H22 | OV3            | HA0                  | OPT             |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H30 | THT            | HB0                  | PE              |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H31 | THM            | HB1                  | PUE             |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H32 | NTC            | HB2                  | RET             |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H33 | SCR            | HC0                  | CPU             |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H40 | EEP            |                      |                 |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H41 | FAN            |                      |                 |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H42 | PID            |                      |                 |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |
| H50 | UVT            | Other error code SPE |                 |  |             |      |         |   |   |   |   |                         |   |   |   |   |   |   |   |   |   |   |                       |  |  |  |  |  |  |  |                         |  |  |  |  |  |  |  |      |         |      |         |     |          |     |     |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |    |     |     |     |     |     |     |     |     |     |     |     |     |     |     |  |  |     |     |  |  |     |     |  |  |     |     |                      |  |        |

| No   | Item                                      |          | Command | Data Content  | Byte Number |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
|------|---|----------|---------|---|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|------|---------|------|---------|-----|------------|-----|----|-----|-----|-----|----|-----|-----|-----|----|-----|-----|-----|----|--------|
| 3    | Message display                           |          | H78     | <div>H0000~HFFFF</div> <div><table><tr><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>1</td></tr></table><div></div><div>Message Code (TUN)</div><table><tr><td>Data</td><td>content</td><td>Data</td><td>content</td></tr><tr><td>H00</td><td>No display</td><td>H13</td><td>SL</td></tr><tr><td>H10</td><td>TUN</td><td>H14</td><td>LV</td></tr><tr><td>H11</td><td>FAL</td><td>H15</td><td>OV</td></tr><tr><td>H12</td><td>RET</td><td>H16</td><td>OL</td></tr></table></div> | 0           | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | Data | content | Data | content | H00 | No display | H13 | SL | H10 | TUN | H14 | LV | H11 | FAL | H15 | OV | H12 | RET | H16 | OL | 4Bytes |
| 0    | 0   | 0        | 1       | 0   | 0           | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| Data | content                                   | Data     | content |   |             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| H00  | No display                                | H13      | SL      |   |             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| H10  | TUN                                       | H14      | LV      |   |             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| H11  | FAL                                       | H15      | OV      |   |             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| H12  | RET                                       | H16      | OL      |   |             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 4    | Operation Command                         |          | HFA     | <div>H0000~HFFFF</div> <div>b0:Output ceased   b1:FWD Rotation(STF)<br/>b2:REV Rotation(STR)   b3:Low Speed(RL)<br/>b4:Mid Speed(RM)   b5:High Speed (RH)<br/>b6:multi-speed (REX)<br/>b7:2nd Acceleration/Declaration Selection(RT)<br/>b8~b15:reserved<br/>(Note) In the communication mode RS485, functions of external terminal MRS、RT is still available.</div>  | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 5    | Inverter State                            |          | H7A     | <div>H0000~HFFFF</div> <div>b0:Operation   b1:Forward rotation   b2:reverse rotation<br/>b3:Frequency achieved   b4:Overload   b5:Key tone<br/>b6:Frequency detection   b7:Alarm Occurrence<br/>b8:RES ON   b9:STF ON   b10:STR ON<br/>b11:When is in external operation, Press STOP key on Control panel<br/>b12~b15:reserved</div>  | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 6    | Operation Frequency Write In              |          | HEE     | H0000~H9C40   | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 7    | Inverter Reset                            |          | HFD     | H9696   | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 8    | Inverter Parameter and error code erased. |          | HFC     | <div>H5A5A----Pr999</div> <div>H9966----Pr998</div> <div>HA5A5----Pr996</div> <div>H55AA----Except communication parameter ,all parameter must be back to initial value.</div>  | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 9    | Parameter Read Out                        |          | H00~H63 | Data Length: Please refer to <Communication Parameter Codes List>   | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 10   | Parameter Write In                        |          | H80~HE3 |   | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
| 11   | Write/Read Parameter/page change          | Read Out | H7F     | <div>H00~H63, H80~HE3 shift</div> <div>H0000----Pr0~Pr99 Read/Write</div> <div>H0001----Pr100~Pr199 Read/Write</div>  | 4Bytes      |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |
|      |   | Write In | HFF     |   |             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |      |         |      |         |     |            |     |    |     |     |     |    |     |     |     |    |     |     |     |    |        |

## <Communication Parameter Codes List>

| Function           | Pr Number | Name  | Setting Range | Min Setting unit | Initial Value        | Parameter Codes |       |
|--------------------|-----------|---|---------------|------------------|----------------------|-----------------|-------|
|                    |           |   |               |                  |                      | Read            | Write |
| Basic function     | Pr0       | Manual Torque Boost                           | 0~30%         | 0.1%             | 6%( Note7)           | H00             | H80   |
|                    | Pr1       | Maximum frequency                             | 0~120Hz       | 0.01Hz           | 120Hz                | H01             | H81   |
|                    | Pr2       | Minimum frequency                             | 0~120Hz       | 0.01Hz           | 0Hz                  | H02             | H82   |
|                    | Pr3       | Base Frequency                                | 0~400Hz       | 0.01Hz           | 60Hz                 | H03             | H83   |
|                    | Pr4       | 1(High Speed )                                | 0~400Hz       | 0.01Hz           | 60Hz                 | H04             | H84   |
|                    | Pr5       | 2(middle speed)                               | 0~400Hz       | 0.01Hz           | 30Hz                 | H05             | H85   |
|                    | Pr6       | 3(low speed)                                  | 0~400Hz       | 0.01Hz           | 10Hz                 | H06             | H86   |
|                    | Pr7       | Acceleration Time                             | 0~3600sec     | 0.1sec           | 5sec (Note1)         | H07             | H87   |
|                    | Pr8       | Deceleration Time                             | 0~3600sec     | 0.1sec           | 5sec (Note1)         | H08             | H88   |
|                    | Pr9       | Electronic thermal O/L replay                 | 0~300A        | 0.01A            | Rated Output current | H09             | H89   |
| DC injection brake | Pr10      | DC injection brake operation frequency        | 0~120Hz       | 0.01Hz           | 3Hz                  | H0A             | H8A   |
|                    | Pr11      | DC injection brake operation time             | 0~10sec       | 0.1sec           | 0.5sec               | H0B             | H8B   |
|                    | Pr12      | DC injection brake operation ability          | 0~30%         | 0.1%             | 6%( Note8)           | H0C             | H8C   |
| Deceleration       | Pr13      | Starting Frequency                            | 0~60Hz        | 0.01Hz           | 0.5Hz                | H0D             | H8D   |
| ---                | Pr14      | Load Pattern selection                        | 0、1、2、3       | 1                | 0                    | H0E             | H8E   |
| JOG rotation       | Pr15      | JOG frequency                                 | 0~400Hz       | 0.01Hz           | 5Hz                  | H0F             | H8F   |
| JOG rotation       | Pr16      | JOG Acceleration/Deceleration time            | 0~3600 sec    | 0.1sec           | (Note 2)             | H10             | H90   |
| Basic function     | Pr17      | External electronic thermal replay selection  | 0~2           | 1                | 0                    | H11             | H91   |
|                    | Pr18      | High speed maximum frequency                  | 120~400Hz     | 0.01Hz           | 120Hz                | H12             | H92   |
|                    | Pr19      | Base frequency voltage                        | 0~1000V、9999  | 0.1V             | 9999                 | H13             | H93   |
| Acceleration       | Pr20      | Acceleration/Deceleration reference frequency | 1~400Hz       | 0.01Hz           | 60Hz                 | H14             | H94   |

| Function                   | Pr Number | Name   | Setting Range  | Min Setting unit | Initial Value | Parameter Codes |       |
|----------------------------|-----------|--|----------------|------------------|---------------|-----------------|-------|
|                            |           |  |                |                  |               | Read            | Write |
| Preventing lost speed      | Pr21      | Stall deceleration time during running                               | 0~3600sec      | 0.1sec           | 2Sec          | H15             | H95   |
|                            | Pr22      | Stall prevention operation level                                     | 0~200%         | 0.1%             | 185%          | H16             | H96   |
|                            | Pr23      | Stall prevention operation level compensation factor at double speed | 0~200%         | 0.1%             | 200%          | H17             | H97   |
| Multi-speed setting        | Pr24      | 4th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          | H18             | H98   |
|                            | Pr25      | 5th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          | H19             | H99   |
|                            | Pr26      | 6th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          | H1A             | H9A   |
|                            | Pr27      | 7th speed  | 0~400Hz、9999   | 0.01Hz           | 9999          | H1B             | H9B   |
| ---                        | Pr28      | Limitation for alarm reset times                                     | 0、1~10         | 1                | 3             | H1C             | H9C   |
| AC/Deceleration            | Pr29      | Acceleration/Deceleration curve pattern selection                    | 0、1、2          | 1                | 0             | H1D             | H9D   |
| Regenerative brake         | Pr30      | Regenerative brake function selection                                | 0、1            | 1                | 0             | H1E             | H9E   |
| Shihlin Communication      | Pr32      | Communication speed (baud rate)                                      | 0、1、2 (Note 3) | 1                | 1             | H20             | HA0   |
|                            | Pr36      | Station number   | 0~31           | 1                | 0             | H24             | HA4   |
| ---                        | Pr37      | Speed Display  | 0、1~9998       | 1                | 0             | H25             | HA5   |
| ---                        | Pr38      | Frequency/5V(10V)  | 1~400Hz        | 0.01Hz           | 60Hz          | H26             | HA6   |
| ---                        | Pr39      | Frequency /20mA  | 1~400Hz        | 0.01Hz           | 60Hz          | H27             | HA7   |
| ---                        | Pr40      | Multifunction terminal selection                                     | 0~6666         | 1                | 5102          | H28             | HA8   |
| Output frequency detection | Pr41      | Output frequency detection   | 0~100%         | 0.1%             | 10%           | H29             | HA9   |
|                            | Pr42      | Output frequency detection for forward rotation                      | 0~400Hz        | 0.01Hz           | 6Hz           | H2A             | HAA   |
|                            | Pr43      | Output frequency detection for reverse rotation                      | 0~400Hz、9999   | 0.01Hz           | 9999          | H2B             | HAB   |
| Second function            | Pr44      | 2nd acceleration time  | 0~3600sec、9999 | 0.1sec           | 9999          | H2C             | HAC   |
|                            | Pr45      | 2nd deceleration time  | 0~3600sec、9999 | 0.1sec           | 9999          | H2D             | HAD   |
|                            | Pr46      | 2nd torque boost   | 0~30%、9999     | 0.1%             | 9999          | H2E             | HAE   |
|                            | Pr47      | 2nd base frequency   | 0~400Hz、9999   | 0.01Hz           | 9999          | H2F             | HAF   |

| Function              | Pr Number | Name  | Setting Range    | Min Setting unit | Initial Value        | Parameter Codes |       |
|-----------------------|-----------|---|------------------|------------------|----------------------|-----------------|-------|
|                       |           |   |                  |                  |                      | Read            | Write |
| Shihlin Communication | Pr48      | Data length   | 0、1              | 1                | 0                    | H30             | HB0   |
|                       | Pr49      | Stop bit length   | 0、1              | 1                | 0                    | H31             | HB1   |
|                       | Pr50      | Parity check presence/absence                           | 0、1、2            | 1                | 2                    | H32             | HB2   |
|                       | Pr51      | CR、LF presence/absence                                  | 1、2              | 1                | 1                    | H33             | HB3   |
|                       | Pr52      | Number of communication retries                         | 0~10             | 1                | 0                    | H34             | HB4   |
|                       | Pr53      | Communication check time interval                       | 0、0.1~999.8、9999 | 0.1sec           | 9999                 | H35             | HB5   |
| Surveillance function | Pr54      | FM/AM function selection                                | 0~6              | 1                | 1                    | H36             | HB6   |
|                       | Pr55      | Frequency Monitoring reference                          | 0~400Hz          | 0.01Hz           | 60Hz                 | H37             | HB7   |
|                       | Pr56      | Current monitoring reference                            | 0~500A           | 0.01A            | Rated Output Current | H38             | HB8   |
| Reboot                | Pr57      | Restart coasting time                                   | 0~5sec、9999      | 0.1sec           | 9999                 | H39             | HB9   |
|                       | Pr58      | Restart cushion time                                    | 0~60sec          | 0.1sec           | 0.5sec               | H3A             | HBA   |
| ---                   | Pr59      | Multifunction terminals selection                       | 0~9999           | 1                | 9999                 | H3B             | HBB   |
| Wave filter Figure    | Pr60      | Input filter time constant                              | 1~16             | 1                | 1                    | H3C             | HBC   |
| Tone change           | Pr61      | Key Tone Selection                                      | 0、1              | 1                | 0                    | H3D             | HBD   |
| Output frequency test | Pr62      | Zero current detection level                            | 0~200%、9999      | 0.1%             | 5%                   | H3E             | HBE   |
|                       | Pr63      | Zero current detection time                             | 0.05~1sec、9999   | 0.01sec          | 0.5sec               | H3F             | HBF   |
| ---                   | Pr64      | Remote function selection                               | 0、1、2、3          | 1                | 0                    |                 |       |
| Function recovery     | Pr65      | Retry Selection   | 0、1、2、3          | 1                | 0                    | H41             | HC1   |
| Stall prevention      | Pr66      | Stall prevention operation reduction starting frequency | 0~400Hz          | 0.01Hz           | 60Hz                 | H42             | HC2   |
| Function recovery     | Pr67      | Number of retries at alarm occurrence                   | 0、1~10、11~20     | 1                | 0                    | H43             | HC3   |
|                       | Pr68      | Retry waiting time                                      | 0~360sec         | 0.1sec           | 1sec                 | H44             | HC4   |
|                       | Pr69      | Retry count display erase                               | 0                | 1                | 0                    | H45             | HC5   |

| Function           | Pr Number | Name  | Setting Range | Min Setting unit | Initial Value      | Parameter Codes |       |
|--------------------|-----------|---|---------------|------------------|--------------------|-----------------|-------|
|                    |           |   |               |                  |                    | Read            | Write |
| Regenerative brake | Pr70      | Special regenerative brake duty               | 0~30%         | 0.1%             | 0%                 | H46             | HC6   |
| ---                | Pr71      | Brake method selection                        | 0、1           | 1                | 1                  | H47             | HC7   |
| ---                | Pr72      | Load Frequency                                | 0.7~15kHz     | 0.1KHz           | 5kHz               | H48             | HC8   |
| ---                | Pr73      | Voltage Signal Selection                      | 0、1           | 1                | 0                  | H49             | HC9   |
| ---                | Pr74      | Starting terminal function selection          | 0、1           | 1                | 0                  | H4A             | HCA   |
| ---                | Pr75      | Reset   | 0~7           | 1                | 4                  | H4B             | HCB   |
| ---                | Pr77      | Parameter writing prevention selection        | 0、1、2         | 1                | 0                  | H4D             | HCD   |
| ---                | Pr78      | Prevention forward/reverse rotation selection | 0、1、2         | 1                | 0                  | H4E             | HCE   |
| ---                | Pr79      | Operation Mode selection                      | 0~8           | 1                | 0                  | H4F             | HCF   |
| ---                | Pr80      | FM/AM output terminal selection               | 0、1           | 1                | 0                  | H50             | HD0   |
| ---                | Pr81      | AM Signal output magnification                | 0~20          | 0.01             | 1                  | H51             | HD1   |
| ---                | Pr82      | Set frequency gain                            | 0、1~100%      | 1                | 0                  | H52             | HD2   |
| ---                | Pr84      | FU/10 times output terminals selection        | 0、1~10        | 1                | 0                  | H54             | HD4   |
| ---                | Pr88      | Auto voltage Boost selection                  | 0、1           | 1                | 0                  | H58             | HD8   |
| ---                | Pr89      | Slip Compensation                             | 0~3%          | 0.1%             | 0%                 | H59             | HD9   |
| ---                | Pr90      | Grounding Leakage Selection                   | 0、1           | 1                | 1                  | H5A             | HDA   |
| Avoid frequency    | Pr91      | Frequency Jump 1A                             | 0~400Hz、9999  | 0.01Hz           | 9999               | H5B             | HDB   |
|                    | Pr92      | Frequency Jump 1B                             | 0~400Hz、9999  | 0.01Hz           | 9999               | H5C             | HDC   |
|                    | Pr93      | Frequency Jump 2A                             | 0~400Hz、9999  | 0.01Hz           | 9999               | H5D             | HDD   |
|                    | Pr94      | Frequency Jump 2B                             | 0~400Hz、9999  | 0.01Hz           | 9999               | H5E             | HDE   |
|                    | Pr95      | Frequency Jump 3A                             | 0~400Hz、9999  | 0.01Hz           | 9999               | H5F             | HDF   |
|                    | Pr96      | Frequency Jump 3B                             | 0~400Hz、9999  | 0.01Hz           | 9999               | H60             | HE0   |
| ---                | Pr99      | Motor operation mode selection                | 0~4           | 1                | 0                  | H63             | HE3   |
| Motor constants    | Pr100     | Motor capacity                                | 0~30KW        | 0.01             | Depend on Capacity | H00             | H80   |
|                    | Pr101     | Motor Pole number                             | 2~12          | 1                | 4                  | H01             | H81   |
|                    | Pr102     | Rated Motor Voltage                           | 0~1000V       | 1V               | 220/440 V          | H02             | H82   |
|                    | Pr103     | Rated Motor frequency                         | 0~ 400 Hz     | 0.01 Hz          | 60 Hz              | H03             | H83   |



| Function            | Pr Number | Name                                   | Setting Range | Min Setting unit | Initial Value      | Parameter Codes |       |
|---------------------|-----------|--|---------------|------------------|--------------------|-----------------|-------|
|                     |           |  |               |                  |                    | Read            | Write |
| Motor constants     | Pr105     | Motor excitation current               | 0~150 A       | 0.01 A           | Depend on Capacity | H05             | H85   |
|                     | Pr106     | Motor constant R1                      | 0.01~60Ω      | 0.01Ω            | Depend on Capacity | H06             | H86   |
|                     | Pr107     | Motor constant R2                      | 0.01~60Ω      | 0.01Ω            | Depend on Capacity | H07             | H87   |
|                     | Pr108     | Motor constant L1                      | 0.1~1500mH    | 0.1 mH           | Depend on Capacity | H08             | H88   |
|                     | Pr109     | Motor constant L2                      | 0.1~1500mH    | 0.1 mH           | Depend on Capacity | H09             | H89   |
|                     | Pr110     | Motor constant Lm                      | 0.1~1500mH    | 0.1 mH           | Depend on Capacity | H0A             | H8A   |
| Protective function | Pr113     | Overvoltage stall protection selection | 0、 1          | 1                | 0                  | H0D             | H8D   |
|                     | Pr114     | Overvoltage stall protection voltage   | 110~140%      | 0.1%             | 120%               | H0E             | H8E   |
| Torque control      | Pr115     | Torque command source selection        | 0~2           | 1                | 0                  | H0F             | H8F   |
|                     | Pr116     | Speed limit selection                  | 0~4           | 1                | 0                  | H10             | H90   |
|                     | Pr117     | Torque command value                   | 0~100%        | 0.1%             | 50%                | H11             | H91   |
|                     | Pr118     | Forward rotation speed limit           | 0~120Hz       | 0.01Hz           | 60Hz               | H12             | H92   |
|                     | Pr119     | Reverse rotation speed limit           | 0~120Hz       | 0.01Hz           | 60Hz               | H13             | H93   |
| Torque control      | Pr120     | Torque command gain                    | 0~180%        | 0.1%             | 100%               | H14             | H94   |
| ---                 | Pr125     | Digital Unit key tone selection        | 0、 1          | 1                | 1                  | H19             | H99   |
| Multi-speed setting | Pr126     | 8th Speed                              | 0~400Hz、 9999 | 0.01Hz           | 9999               | H1A             | H9A   |
|                     | Pr127     | 9th Speed                              | 0~400Hz、 9999 | 0.01Hz           | 9999               | H1B             | H9B   |
|                     | Pr128     | 10th Speed                             | 0~400Hz、 9999 | 0.01Hz           | 9999               | H1C             | H9C   |
|                     | Pr129     | 11th Speed                             | 0~400Hz、 9999 | 0.01Hz           | 9999               | H1D             | H9D   |
|                     | Pr130     | 12th Speed                             | 0~400Hz、 9999 | 0.01Hz           | 9999               | H1E             | H9E   |

| Function            | Pr Number | Name                                  | Setting Range | Min Setting unit | Initial Value | Parameter Codes |       |
|---------------------|-----------|---------------------------------------|---------------|------------------|---------------|-----------------|-------|
|                     |           |                                       |               |                  |               | Read            | Write |
| Multi-speed setting | Pr131     | 13th Speed                            | 0~400Hz、9999  | 0.01Hz           | 9999          | H1F             | H9F   |
|                     | Pr132     | 14th Speed                            | 0~400Hz、9999  | 0.01Hz           | 9999          | H20             | HA0   |
|                     | Pr133     | 15th Speed                            | 0~400Hz、9999  | 0.01Hz           | 9999          | H21             | HA1   |
| PID performance     | Pr160     | PID operation selection               | 0、1~8         | 1                | 0             | H3C             | HBC   |
|                     | Pr161     | PID ratio increase                    | 0、0.1~600%    | 0.1%             | 90%           | H3D             | HBD   |
|                     | Pr162     | PID integral increase                 | 0、0.1~600%    | 0.1%             | 10%           | H3E             | HBE   |
|                     | Pr163     | PID differential increase             | 0、0.1~600%    | 0.1%             | 0%            | H3F             | HBF   |
|                     | Pr164     | PID digital target value              | 0~100%        | 0.1%             | 0%            | H40             | HC0   |
|                     | Pr165     | PID Output order limit                | 0~100%        | 0.1%             | 50%           | H41             | HC1   |
|                     | Pr166     | PID Alert value limit                 | 0、0.1~100%    | 0.1%             | 0%            | H42             | HC2   |
|                     | Pr167     | PID Alarm detection time              | 0、0.1~3600s   | 0.1s             | 0s            | H43             | HC3   |
|                     | Pr168     | PID Alarm solution                    | 0~2           | 1                | 0             | H44             | HC4   |
| Vector Control      | Pr180     | Proportional Gain of Speed Controller | 0~100%        | 1%               | 50%           | H50             | HD0   |
|                     | Pr181     | Integral Gain of Speed Controller     | 0~100%        | 1%               | 50%           | H51             | HD1   |
|                     | Pr182     | Slip Compensation                     | 0~50%         | 0.1%             | 35%           | H52             | HD2   |
|                     | Pr183     | Speed Compensation Coefficient        | 0~100%        | 0.1%             | 50%           | H53             | HD3   |
|                     | Pr184     | Low Speed Exited Rate                 | 0~100%        | 0.1%             | 50%           | H54             | HD4   |
|                     | Pr185     | High Speed Exited Rate                | 0~100%        | 0.1%             | 100%          | H55             | HD5   |
|                     | Pr186     | High Speed Exited Curve               | 0、1、2         | 1                | 1             | H56             | HD6   |
|                     | Pr187     | Bandwidth of Speed Controller         | 20~120        | 1                | 60            | H57             | HD7   |
| ---                 | Pr189     | 50Hz/60Hz system switchover           | 0、1           | 1                | 0             | H59             | HD9   |
| ---                 | Pr191     | FM terminal output revision           | 0~50          | 1                | 25            | H5B             | HDB   |

| Function              | Pr Number | Name                                       | Setting Range |         | Min Setting unit | Initial Value |      | Parameter Codes |       |
|-----------------------|-----------|--|---------------|---------|------------------|---------------|------|-----------------|-------|
|                       |           |  |               |         |                  |               |      | Read            | Write |
| Calibration functions | Pr192     | FM Terminal calibration                    | 0~9998        |         | 1                | 166           |      | H5C             | HDC   |
|                       | Pr194     | Voltage setting Bias                       | 0~10V         | 0~60Hz  | 0.01Hz           | 0V            | 0Hz  | H5E             | HDE   |
|                       | Pr195     | Voltage setting Gain                       | 0~10V         | 1~400Hz | 0.01Hz           | 5V            | 60Hz | H5F             | HDF   |
|                       | Pr196     | Current setting Bias                       | 0~20mA        | 0~60Hz  | 0.01Hz           | 4mA           | 0Hz  | H60             | HE0   |
|                       | Pr197     | Current setting Gain                       | 0~20mA        | 1~400Hz | 0.01Hz           | 20mA          | 60Hz | H61             | HE1   |
| ---                   | Pr199     | Software version                           | Viewing only  |         | —                | (Note 6)      |      | H63             | —     |
| Parameter copy        | Pr994     | Parameter copy/read                        | —             |         | —                | (Note 4)      |      | —               | —     |
|                       | Pr995     | Parameter copy/write                       | —             |         | —                | (Note 4)      |      | —               | —     |
| Alert record clear    | Pr996     | Alarm history clear                        | —             |         | —                | —             |      | —               | —     |
| Parameter reset       | Pr997     | Reset                                      | —             |         | —                | —             |      | —               | —     |
| Parameter recovery    | Pr998     | All parameter recover to initial value     | —             |         | —                | —             |      | —               | —     |
|                       | Pr999     | Partial parameter recover to initial value | —             |         | —                | —             |      | —               | —     |

(Note1) Factory default value of Parameter Pr7、Pr8: 0.75K~7.5K (1HP~10HP) product series is 5sec , 11K~15K (15HP~20HP) product series is 10sec, 18.5K~22K (25HP~30HP) product series is 15sec.

(Note2) Factory default value of Parameter Pr16: 0.75K~3.7K (1HP~5HP) product series is 0.5sec , 5.5K~15K (7.5HP~20HP) product series is 1sec. 18.5K~22K (25HP~30HP) product Series is 1.5sec.

(Note3) When Pr32=0, the Baud Rate is 4800bps; when Pr32=1, the Baud Rate is 9600bps; when Pr32=2, the Baud Rate is 19200bps.

(Note 4) The function related to parameter copy in Pr994 and Pr995 is only available in Digital Unit of SH-PU.

(Note 5) When parameter value is 9999, the operation panel of SH-PU series shows as “9999”, but for DU series shows as “99999”.

(Note 6) For massive quantity manufacture versions are all standardized, parameter functions all apply to market demand. For the reason of special demand, other exclusive version will be made.

(Note7) Factory default value of Parameter Pr0: 0.75K(1HP) product series is 6%, 1.5K~3.7K (2HP~5HP) product series is 4%, 5.5K~7.5K (7.5HP~10HP) product series is 3%, 11K~22K (15HP~30HP) product series is 2%.

(Note8) Factory default value of Parameter Pr12: 0.75K~3.7K (1HP~5HP) product series is 6%, 5.5K~7.5K (7.5HP~10HP) product series is 4%, 11K~22K (15HP~30HP) product series is 2%.

## Examples:

Example 1: Computer communication to read Pr126

Step 1. Inputting page changing into computer, applying Format A:

| ENQ | Station number<br>0 0 | Instruction code<br>HFF | Waiting time | Data<br>H0001   | Sum check | CR  |
|-----|-----------------------|-------------------------|--------------|-----------------|-----------|-----|
| H05 | H30 H30               | H46 H46                 | H30          | H30 H30 H30 H31 | H44 H44   | H0D |



Pr.126 is in Page 1

Step 2. After inverter receives the information and processes without error, and then it replies, applying Format C:

| ACK | Station number<br>0 0 | CR  |
|-----|-----------------------|-----|
| H06 | H30 H30               | H0D |

Step 3. Referring to Whether or not computer runs inverter page changing value correctly, applying Format B:

| ENQ | Station number<br>0 0 | Instruction code<br>H7F | Waiting time | Sum check | CR  |
|-----|-----------------------|-------------------------|--------------|-----------|-----|
| H05 | H30 H30               | H37 H46                 | H30          | H30 H44   | H0D |

Step 4. After inverter receives the information and processes without error, then it transfers the value of page changing to computer, applying Format E:

| STX | Station number<br>0 0 | Read data<br>H0001 | Unit | ETX | Sum check | CR  |
|-----|-----------------------|--------------------|------|-----|-----------|-----|
| H02 | H30 H30               | H30 H30 H30 H31    | H30  | H03 | H36 H31   | H0D |

Step 5. After computer receives the above step information and process without error, then it replies to inverter, applying Format G:

|     |                       |     |
|-----|-----------------------|-----|
| ACK | Station number<br>0 0 | CR  |
| H06 | H30 H30               | H0D |

Step 6. Computer sends information to inverter and requires value of Pr126,  
Applying Format B:

|     |                       |                         |                 |              |     |
|-----|-----------------------|-------------------------|-----------------|--------------|-----|
| ENQ | Station number<br>0 0 | Instruction code<br>H1A | Waiting<br>time | Sum<br>check | CR  |
| H05 | H30 H30               | H31 H41                 | H30             | H30 H32      | H0D |



126 minus 100 equals 26, then invert 26 to hexadecimal H1A, and convert 1、A to ASCII CODE H31、H41.

Step 7. After inverter receives the information and processes without error, it sends value of Pr126 to computer, applying Format E:

|     |                       |                          |      |     |              |     |
|-----|-----------------------|--------------------------|------|-----|--------------|-----|
| STX | Station number<br>0 0 | Read data<br>H1770(60Hz) | Unit | ETX | Sum<br>check | CR  |
| H02 | H30 H30               | H31 H37 H37 H30          | H32  | H03 | H36 H34      | H0D |

Step 8. After inverter receives the information and processes without error, it replies to inverter, applying Format G:

|     |                       |     |
|-----|-----------------------|-----|
| ACK | Station number<br>0 0 | CR  |
| H06 | H30 H30               | H0D |

Example 2: Change value of Pr126 to 50(initial value is 60)

Step 1. After completing all steps of example 1

Step 2. Inputting 50 into inverter by computer, applying format A:

| ENQ | Station number<br>0 0 | Instruction code<br>H9A | Waiting time | Data<br>H1388   | Sum check | CR  |
|-----|-----------------------|-------------------------|--------------|-----------------|-----------|-----|
| H05 | H30 H30               | H39 H41                 | H30          | H31 H33 H38 H38 | H44 H45   | H0D |



126 minus 100 equal 26, then convert 26 to hexadecimal H1A, H1A+H80=H9A.



Minimum unit of Pr126 is 0.01, therefore 50\*100=5000, then convert 5000 to hexadecimal H1388, and convert 1,3,8,8 to ASCII CODE to send out.

Step 3. After inverter receives the information and processes without error, it replies to computer, applying Format C:

| ACK | Station number<br>0 0 | CR  |
|-----|-----------------------|-----|
| H06 | H30 H30               | H0D |

Example 3: Input 500 as the value of Pr126 (Parameter range 0~400)

Step 1. After completing all steps of example 1


Step 2. Inputting 500 into inverter by computer, applying Format A:

| ENQ | Station number<br>0 0 | Instruction code<br>H9A | Waiting time | Data<br>HC350   | Sum check | CR  |
|-----|-----------------------|-------------------------|--------------|-----------------|-----------|-----|
| H05 | H30 H30               | H39 H41                 | H30          | H43 H33 H35 H30 | H45 H35   | H0D |

Step 3. After processing, for information out of range, inverter replies to computer that this information is incorrect, applying Format F:

| NAK | Station number<br>0 0 | Error code<br>HC | CR  |
|-----|-----------------------|------------------|-----|
| H15 | H30 H30               | H43              | H0D |

## Appendix 2 Motor Parameter Auto-Tuning Procedures



### Appendix 3 Alarm Code

| Code   | Operation Panel Display | Description   | Corrective action  |
|--|-------------------------|---|--|
| ERROR  | Error                   | <ul style="list-style-type: none"> <li>• RESET Terminal is setting On.</li> <li>• Contactor failure between operation panel and inverter</li> <li>• Internal circuit malfunction</li> <li>• CPU Failure.</li> </ul> | <ul style="list-style-type: none"> <li>• Switch off the Restart switch.</li> <li>• Make sure if operation panel is connected with inverter.</li> <li>• Replace Inverter.</li> <li>• Restart Inverter.</li> </ul>   |
| 0  | 0                       | <ul style="list-style-type: none"> <li>• Wrong operation procedures</li> </ul>  | <ul style="list-style-type: none"> <li>• Follow standard operation procedures</li> </ul>   |
| OC1<br>Overcurrent shut-off during acceleration                      | OC 1                    | <ul style="list-style-type: none"> <li>• Output current exceeds its maximum allowable level.</li> </ul>   | <ul style="list-style-type: none"> <li>• Increases acceleration time if there is rapid fast/slow acceleration.</li> <li>• Prevention load increases rapidly.</li> <li>• Check if any short circuit on UVW terminals.</li> </ul>  |
| OC2<br>Overcurrent shut-off during constant speed                    | OC 2                    |   |  |
| OC3<br>Overcurrent shut-off during deceleration or stop              | OC 3                    |   |  |
| OV1<br>Regenerative overvoltage shut-off during acceleration         | OV 1                    | <ul style="list-style-type: none"> <li>• DC bus voltage exceeds its maximum allowable value.</li> </ul>   | <ul style="list-style-type: none"> <li>• If there is rapid acceleration /deceleration, please extend the acceleration/deceleration time.</li> <li>• Check if brake resistor is detached between main circuit terminals of P-PR.</li> <li>• Check the setting value of Pr30 and Pr70 .</li> <li>• Check the setting value of Pr113 and Pr114 .</li> </ul> |
| OV2<br>Regenerative overvoltage shut-off during constant speed       | OV 2                    |   |  |
| OV3<br>Regenerative overvoltage shut-off during deceleration or stop | OV 3                    |   |  |
| THT<br>IGBT Module Over temperature                                  | THT                     | <ul style="list-style-type: none"> <li>• Inverter overload shut-off</li> <li>• IGBT Module Over Current</li> </ul>  | <ul style="list-style-type: none"> <li>• To prevent long-time overload operation of Inverter.</li> <li>• Reduced carrier frequency.</li> </ul>   |
| THM<br>Overload  | THO                     | <ul style="list-style-type: none"> <li>• Electronic thermal relay function</li> </ul>   | <ul style="list-style-type: none"> <li>• Check setting value of Pr9.</li> <li>• Decreased load or increased combined the capability of Inverter and Motor.</li> </ul>  |



| Code                                       | Operation<br>Panel Display | Description  | Corrective action  |
|--|----------------------------|--|--|
| FAN<br>Cooling Fan Alarm                   | <i>FAN</i>                 | <ul style="list-style-type: none"> <li>• Cooling Fan Failure</li> </ul>  | <ul style="list-style-type: none"> <li>• Cooling fan damaged, please replace a new fan.</li> <li>• If fan is blocked by any objects, please remove it.</li> <li>• Check if Fan wiring is broken /loose, or need to replace new fan.</li> </ul> |
| OLT<br>Overload                            | <i>OLT</i>                 | <ul style="list-style-type: none"> <li>• Stall prevention for long time operation</li> </ul>   | <ul style="list-style-type: none"> <li>• Check the setting value of Pr22.</li> <li>• Decreased load.</li> <li>• Increased capacity of inverter and motor.</li> </ul>   |
| BE<br>Brake transistor<br>alarm detection  | <i>BE</i>                  | <ul style="list-style-type: none"> <li>• Brake transistor alarm</li> </ul>   | <ul style="list-style-type: none"> <li>• Send back for Repair.</li> </ul>  |
| OHT<br>External thermal<br>relay operation | <i>OHT</i>                 | <ul style="list-style-type: none"> <li>• Operation of External Thermal Relay</li> </ul>  | <ul style="list-style-type: none"> <li>• Check external thermal relay and motor capacity.</li> <li>• Decreased load</li> </ul>   |
| PUE<br>Operation Panel<br>is detached      | <i>PUE</i>                 | <ul style="list-style-type: none"> <li>• Operation Panel is detached</li> </ul>  | <ul style="list-style-type: none"> <li>• Make sure operation panel is firmly connected with inverter.</li> </ul>   |
| GF<br>Grounding Failure<br>Protection      | <i>GF</i>                  | <ul style="list-style-type: none"> <li>• Over current between inverter output side with grounding wire</li> </ul>  | <ul style="list-style-type: none"> <li>• Check if motor insulation resistance is too low.</li> <li>• Check if any short-circuit between motor wiring.</li> <li>• Check if any mistake on wiring</li> </ul>                                     |
| OPT<br>Communication<br>option alarm       | <i>OPT</i>                 | <ul style="list-style-type: none"> <li>• Communication Alarm. Retry count excess.</li> <li>• Communication disconnection, the communication interval exceeded the permissible time.</li> </ul> | <ul style="list-style-type: none"> <li>• Make sure communication parameter setting value.</li> </ul>   |
| EEP<br>EEPROM alarm                        | <i>EEP</i>                 | <ul style="list-style-type: none"> <li>• EEPROM failure</li> </ul>   | <ul style="list-style-type: none"> <li>• Send back for repair.</li> </ul>  |
| NTC<br>Overheat                            | <i>NTC</i>                 | <ul style="list-style-type: none"> <li>• Fan cooling failure.</li> <li>• Installation location cooling failure.</li> </ul>   | <ul style="list-style-type: none"> <li>• Check air flow.</li> <li>• Please check ventilation condition of installation location.</li> </ul>  |

| Code                                  | Operation<br>Panel Display | Description   | Corrective action  |
|---------------------------------------|----------------------------|---|--|
| UVT<br>Undervoltage                   | <i>UvF</i>                 | <ul style="list-style-type: none"> <li>• Input voltage is too low</li> </ul>                                  | <ul style="list-style-type: none"> <li>• Check the power supply system equipment such as the power supply.</li> </ul>  |
| IPF<br>Instantaneous<br>power failure | <i>IPF</i>                 | <ul style="list-style-type: none"> <li>• Instant stop is too long</li> <li>• Abnormal power supply</li> </ul> | <ul style="list-style-type: none"> <li>• Please check power supply system</li> </ul>   |
| CPU<br>CPU alarm                      | <i>CPU</i>                 | <ul style="list-style-type: none"> <li>• CPU failure</li> </ul>   | <ul style="list-style-type: none"> <li>• Send back for repair.</li> </ul>  |
| PID<br>PID malfunctions               | <i>PId</i>                 | <ul style="list-style-type: none"> <li>• PID feedback signal error</li> </ul>                                 | <ul style="list-style-type: none"> <li>• Check the feedback terminal connection</li> <li>• Make sure the voltage or current transforming ratio for external signal transformer.</li> </ul> |
| RET<br>Retry count excess             | <i>rEr</i>                 | <ul style="list-style-type: none"> <li>• Retry count exceeded Pr67 continuously</li> </ul>                    | <ul style="list-style-type: none"> <li>• Check setting value of Pr67.</li> </ul>   |


## Appendix 4 Troubleshooting and Solution

| Alarm                                | Content of Confirmation   |  |
|--------------------------------------|---|--|
| Motor Won't Rotate                   | Main Circuit  | <ul style="list-style-type: none"> <li>• Check the voltage between terminals R-S-T if correct?</li> <li>• Check if POWER indicator is lit?</li> <li>• Check If wiring between Inverter and Motor is correct?</li> </ul>  |
|                                      | Overload  | <ul style="list-style-type: none"> <li>• Overload too heavy?</li> <li>• Check if Motor Rotator is locked?</li> </ul>   |
|                                      | Pr Setting  | <ul style="list-style-type: none"> <li>• Check if set value of Starting Frequency is too high?(Pr13)</li> <li>• Check if Operation Mode(Pr17) is correct?</li> <li>• Check if set value of Max Frequency value(Pr10) is Zero?</li> <li>• Check if Reverse Rotation(Pr78) is limited?</li> <li>• Check if signal bias and gain(Pr194~Pr197)is correct?</li> <li>• Check if frequency jump is correct (Pr91~Pr96) is correct?</li> </ul>   |
|                                      | Control Circuit   | <ul style="list-style-type: none"> <li>• Check if there is signal feed into MRS terminal?</li> <li>• Check if there is signal feed into RES terminal?</li> <li>• Check if external Thermal Relay is tripping?</li> <li>• Check if Alarm Occurrence (ALARM indicator is lit) but no reset for retry.</li> <li>• Check if wiring of voltage/current signal is current?</li> <li>• Check if input terminal STF and STR is correct?(Pr74)</li> <li>• Check if control circuit wiring is tripping or not or loose contact?</li> </ul> |
| Motor Rotation in apposite direction | <ul style="list-style-type: none"> <li>• Check if wiring UVW is correct?</li> <li>• Check if STF and STR wring is correct?</li> </ul>   |  |
| Motor Torque can not be ramping up   | <ul style="list-style-type: none"> <li>• Check if load is too heavy?</li> <li>• Check if stall prevention level is correct (Pr22)?</li> <li>• Check if Torque Boost (Pr0) is too high?</li> <li>• Check if it is limited by Max Frequency (Pr1)?</li> </ul>                     |  |
| Unsteady Acceleration/Deceleration   | <ul style="list-style-type: none"> <li>• Check if acceleration/deceleration (Pr7, Pr8) is correct?</li> <li>• Check if acceleration/deceleration pattern (Pr29) is correct?</li> <li>• Check if fluctuation of voltage/current signal is influenced by interference?</li> </ul> |  |
| Motor Overcorrect                    | <ul style="list-style-type: none"> <li>• If load is too heavy?</li> <li>• If capacity matching for Inverter and Motor?</li> <li>• Check if Torque Boost (Pr0) is too high?</li> </ul>   |  |
| Torque is shifting during rotation   | <ul style="list-style-type: none"> <li>• Check if any fluctuation occurs by the interference of voltage/current signal?</li> <li>• Check if there is any load change in motor?</li> <li>• Check if main circuit wiring is too long?</li> </ul>                                  |  |

## Appendix 5 PID Parameter adjustment Principle

The matching of three parameter PID affects a lot to precision which clients demand. Therefore, brief methods of adjustment is introduced so that clients can be familiar with the operation.

1. Any parameter of PID changes, do not let output curve vary from symmetry, stop output first to secure it.
2. Set proportional gain P: Increase value P to the rapid responding time you want, but overshoot will be more.
3. Set I: Increase value I, until no error, However, the overshoot and fluctuation may be increased.
4. Set D: Increase value D, reduce overshoot in acceptable range, but climbing time will increase.




5. According to the above procedure, if any adjustment needed, follow the below instruction.

| Parameter adjustment | Reducing overshoot | Reducing Error | Rapidly obtain response | Reducing fast vibration |
|----------------------|--------------------|----------------|-------------------------|-------------------------|
| P                    | Decrease           | Increase       | Increase                | Decrease                |
| I                    | Decrease           | Increase       | Increase                | Decrease                |
| D                    | Increase           | N/A            | Decrease                | Increase                |

(Note) When D reaches critical level, overshoot will increase, hence the value can not be enhanced without limitation.

6. Whole system drawing below :



## **Appendix 6 European Standardized compatibility introduction**

**(This inverter with CE logo complies with the requirement of LVD 73/23/EEC,93/68/EEC and EMC 2004/108/EC)**

### **A. Electromagnetic compatible order(EMC):**

#### **(1).EMC compatible description**

For the whole system, inverter is not dependent functioning device, it is usually one part of the control trunk and cooperate with other devices to control machines, therefore, Our company does not agree that all EMC orders need to apply to inverter directly, For above reasons, Logo CE has no extension of its meaning.

#### **(2).Compatibility**

Not all EMC orders apply to inverter, but for some devices which cooperate with inverter and apply to EMC orders, these devices must have CE logo, Our company has EMC qualified certificate and operation manual so that the machines including inverter can achieve the requested EMC standard with precise accessories.

#### **(3).Installation instruction**

Follow the reminders below to install inverters.

1. Use noise filter which accords to European standard(CE).
2. For wiring between motor and inverter, please store with shield line or metal inductive wire, and grounding the common terminal of motor and inverter.
3. Please install inverter in a grounding metal trunk to isolate radiation.
4. Power supply terminal applies wire to wire noise filter and control lines applies magnetic metal core to suppress noise.

All information and the specification of European standardized filter is introduced in the manual. Please contact your agent.

### **B. Low voltage demand(LVD) :**

#### **(1) LVD compatibility description**

The inverter is compatible to LVD.

#### **(2) Compatibility**

The company self-announces that inverter complies with LVD standard.

#### **(3) Description**

1. Do not use leakage protector to prevent electric shock only, do make the grounding.
2. For individual inverter, make the individual grounding,( No more than 2 grounding line)
3. Use NFB and MRC that complied with EN or IEC standard.
4. Use our inverter under condition of over voltage level 2 and contamination level 2 or better condition.
5. About wires size of input and output sides ,please apply the recommended specification that is in manual.

## CE DECLARATION

### CE EU Declaration of Conformity CE

The product herewith complies with the requirement of the Low Voltage Directive 73/23/EEC , 93/68/EEC, the EMC Directive 2004/108/EC and the CE marking accordingly.

Declares that the product described :

Product Name : AC Motor Drives

Model :

SH020-0.75K , SH020-1.5K , SH020-2.2K , SH020-3.7K  
SH020-5.5K , SH020-7.5K , SH020-11K , SH020-15K  
SH020-18.5K , SH020-22K , SH040-0.75K , SH040-1.5K  
SH040-2.2K , SH040-3.7K , SH040-5.5K , SH040-7.5K  
SH040-11K , SH040-15K , SH040-18.5K , SH040-22K

Conforms to the following Product Specification :

EMC :

IEC 61800-3(Second edition 2004-8)  
Adjustable speed electrical power drive systems  
Part3 : EMC product standard including specific test methods

Safety :

IEC 61800-5-1(First edition 2003-02)  
Adjustable speed electrical power drive systems  
Part 5-1 : Safety requirements-Electrical,thermal and energy

Manufacturer Name :

Shihlin Electric & Engineering Corporation Automation Division

Manufacturer Address :

No.234, ChungLun, HsinFun, HsinChu, Taiwan 304

Signature of representative for the Manufacturer :

Pai-Sung Wang *Pai-Sung Wang*  
(Automation Division Development Dept. Manager)  
Date : September 2006




 **Shihlin**

## APPENDIX 7 MODBUS Parameter list

| Parameter list |      |         |      |         |      |         |      |
|----------------|------|---------|------|---------|------|---------|------|
| Decimal        | Hex  | Decimal | Hex  | Decimal | Hex  | Decimal | Hex  |
| Pr[000]        | 0000 | Pr[050] | 0032 | Pr[100] | 0064 | Pr[150] | 0096 |
| Pr[001]        | 0001 | Pr[051] | 0033 | Pr[101] | 0065 | Pr[151] | 0097 |
| Pr[002]        | 0002 | Pr[052] | 0034 | Pr[102] | 0066 | Pr[152] | 0098 |
| Pr[003]        | 0003 | Pr[053] | 0035 | Pr[103] | 0067 | Pr[153] | 0099 |
| Pr[004]        | 0004 | Pr[054] | 0036 | Pr[104] | 0068 | Pr[154] | 009A |
| Pr[005]        | 0005 | Pr[055] | 0037 | Pr[105] | 0069 | Pr[155] | 009B |
| Pr[006]        | 0006 | Pr[056] | 0038 | Pr[106] | 006A | Pr[156] | 009C |
| Pr[007]        | 0007 | Pr[057] | 0039 | Pr[107] | 006B | Pr[157] | 009D |
| Pr[008]        | 0008 | Pr[058] | 003A | Pr[108] | 006C | Pr[158] | 009E |
| Pr[009]        | 0009 | Pr[059] | 003B | Pr[109] | 006D | Pr[159] | 009F |
| Pr[010]        | 000A | Pr[060] | 003C | Pr[110] | 006E | Pr[160] | 00A0 |
| Pr[011]        | 000B | Pr[061] | 003D | Pr[111] | 006F | Pr[161] | 00A1 |
| Pr[012]        | 000C | Pr[062] | 003E | Pr[112] | 0070 | Pr[162] | 00A2 |
| Pr[013]        | 000D | Pr[063] | 003F | Pr[113] | 0071 | Pr[163] | 00A3 |
| Pr[014]        | 000E | Pr[064] | 0040 | Pr[114] | 0072 | Pr[164] | 00A4 |
| Pr[015]        | 000F | Pr[065] | 0041 | Pr[115] | 0073 | Pr[165] | 00A5 |
| Pr[016]        | 0010 | Pr[066] | 0042 | Pr[116] | 0074 | Pr[166] | 00A6 |
| Pr[017]        | 0011 | Pr[067] | 0043 | Pr[117] | 0075 | Pr[167] | 00A7 |
| Pr[018]        | 0012 | Pr[068] | 0044 | Pr[118] | 0076 | Pr[168] | 00A8 |
| Pr[019]        | 0013 | Pr[069] | 0045 | Pr[119] | 0077 | Pr[169] | 00A9 |
| Pr[020]        | 0014 | Pr[070] | 0046 | Pr[120] | 0078 | Pr[170] | 00AA |
| Pr[021]        | 0015 | Pr[071] | 0047 | Pr[121] | 0079 | Pr[171] | 00AB |
| Pr[022]        | 0016 | Pr[072] | 0048 | Pr[122] | 007A | Pr[172] | 00AC |
| Pr[023]        | 0017 | Pr[073] | 0049 | Pr[123] | 007B | Pr[173] | 00AD |
| Pr[024]        | 0018 | Pr[074] | 004A | Pr[124] | 007C | Pr[174] | 00AE |
| Pr[025]        | 0019 | Pr[075] | 004B | Pr[125] | 007D | Pr[175] | 00AF |
| Pr[026]        | 001A | Pr[076] | 004C | Pr[126] | 007E | Pr[176] | 00B0 |
| Pr[027]        | 001B | Pr[077] | 004D | Pr[127] | 007F | Pr[177] | 00B1 |
| Pr[028]        | 001C | Pr[078] | 004E | Pr[128] | 0080 | Pr[178] | 00B2 |
| Pr[029]        | 001D | Pr[079] | 004F | Pr[129] | 0081 | Pr[179] | 00B3 |
| Pr[030]        | 001E | Pr[080] | 0050 | Pr[130] | 0082 | Pr[180] | 00B4 |
| Pr[031]        | 001F | Pr[081] | 0051 | Pr[131] | 0083 | Pr[181] | 00B5 |
| Pr[032]        | 0020 | Pr[082] | 0052 | Pr[132] | 0084 | Pr[182] | 00B6 |
| Pr[033]        | 0021 | Pr[083] | 0053 | Pr[133] | 0085 | Pr[183] | 00B7 |
| Pr[034]        | 0022 | Pr[084] | 0054 | Pr[134] | 0086 | Pr[184] | 00B8 |
| Pr[035]        | 0023 | Pr[085] | 0055 | Pr[135] | 0087 | Pr[185] | 00B9 |
| Pr[036]        | 0024 | Pr[086] | 0056 | Pr[136] | 0088 | Pr[186] | 00BA |
| Pr[037]        | 0025 | Pr[087] | 0057 | Pr[137] | 0089 | Pr[187] | 00BB |
| Pr[038]        | 0026 | Pr[088] | 0058 | Pr[138] | 008A | Pr[188] | 00BC |
| Pr[039]        | 0027 | Pr[089] | 0059 | Pr[139] | 008B | Pr[189] | 00BD |
| Pr[040]        | 0028 | Pr[090] | 005A | Pr[140] | 008C | Pr[190] | 00BE |
| Pr[041]        | 0029 | Pr[091] | 005B | Pr[141] | 008D | Pr[191] | 00BF |
| Pr[042]        | 002A | Pr[092] | 005C | Pr[142] | 008E | Pr[192] | 00C0 |
| Pr[043]        | 002B | Pr[093] | 005D | Pr[143] | 008F | Pr[193] | 00C1 |
| Pr[044]        | 002C | Pr[094] | 005E | Pr[144] | 0090 | Pr[194] | 00C2 |
| Pr[045]        | 002D | Pr[095] | 005F | Pr[145] | 0091 | Pr[195] | 00C3 |
| Pr[046]        | 002E | Pr[096] | 0060 | Pr[146] | 0092 | Pr[196] | 00C4 |
| Pr[047]        | 002F | Pr[097] | 0061 | Pr[147] | 0093 | Pr[197] | 00C5 |
| Pr[048]        | 0030 | Pr[098] | 0062 | Pr[148] | 0094 | Pr[198] | 00C6 |
| Pr[049]        | 0031 | Pr[099] | 0063 | Pr[149] | 0095 | Pr[199] | 00C7 |

## Appendix 8 Sensorless Vector Control Setting Procedures





## Appendix 9 Manual change record list

| Release date   | Version                     | Content change   |
|----------------|-----------------------------|--|
| January,2006   | SH020/040 V1.01             | First edition  |
| February, 2007 | SH020/040 V1.02             | Add 18.5k/22k specification  |
| June, 2007     | SH020/040 V1.03             | Add up functions of AM 、 10 times 、 Set frequency gain and torque control description.   |
| February, 2008 | SH020/040 V1.04             | Add up description of Pr21 、 communication parameter codes list and the correction of Pr80 、 Pr82 description and the correction of Pr0 、 Pr12 、 Pr22 initial value. |
| June,2009      | SH020/040 V1.05<br>Unissued | 1.Graphics and descriptions amendments<br>2.Add up Pr.64.  |
| October,2009   | SH020/040 V1.06             | Add up MODBUS Communication  |
| November,2009  | SH020/040 V1.07             | Add up Sensorless Function   |
|                |                             |  |

## Memo

- - - - -

## Memo

- - - - -

## Memo

- - - - -