
## Vigor V Series

Configuration for the RS-232 connection is shown in Figure 1.



HMI terminal cable connector

Wiring Diagram

PLC terminal cable connector

Fig. 1 Vigor V Series Connection

## Recommended serial setup:

Туре	Baud Rate (Bps)	Parity	Data Length (Bit)	Stop Bit (Bit)	PLC Station NO.
V series	19200	Even	7	1	N/A